SP05

User Manual

Please review this manual thoroughly before operating your device. In order to avoid unnecessary injuries, please do not Disassemble this product by yourself, and please use a standard charger.

Product Contains

Open ear Earbuds x2





Charging Case x1






User Manual x1

USB Charging Cable x1

Product Specification

Driver: 16.2mm Support Profile: HFP / AVRCP / A2DP Earbuds Charging Time: Up to 1.5 Hour Charging case Charging Time: Up to 1.5 Hours Working Voltage: 5V Transmission Range: Up to 10m

Working Temperature: -10°- 55°



Power On / off



First Pairing

Setp1:Please turn on the bluetooth function on your cellphone/laptop.

Step2:Open the charging case, take out the earbuds the red and blue lights flash on earbud.



Step3:Select "SP05" on your phone/laptop and connect the device, the red and blue lights off when you connect successfully (The earbuds will automatically turn off if not connected the device within 5 minutes.)

Reset Earbuds

If only one earbud connects to phone / earbuds can not pair together. Please try the reset steps: Step 1:Take out the earbuds from changing case, make sure earbuds don't connect the cellphone. Step 2: Quickly touch 5 times MFB button(both right and left), the blue and red light for 1 second, the earbuds will turn off and reset.

Step 3: When the red light off and power off, which means reset successfully, please put earbuds back to charging case and take out again to connect the device again.

TWS Paring

If it still has some problems with your earbuds, you can try paring two earbuds again.

- 1. Make sure the earbuds power on and not connect with cellphone.
- 2.Touch 2 times MFB button(left and right) to pair either other, the red and blue light on one earbud which means pairing successfully.

Product Wear



Step1: Take out the earbuds from charging case. Step2: Hang the earbuds on your ears.

Product Control



Œ, button once

Reject call

Long press the touch button for 2 seconds

Voice Assistant

Short press the touch button three times to call voice assistant.



(K)

Volume Up Short press Right touch

button once Volume Down

Short press Left touch button once

End a call Long press the touch button for 2 seconds



Play/Pause Short press the touch

button twice



Previous Song Long press Left touch





Next Song Long press Right touch button for 2 seconds

Extended Warranty

For your better consumer experience, we provide you with anextended warranty. Please scan the following OR code:



https://accounts.psier.com/register-order

Technical Support

If you encounter any issues while using our products, please feel free to contact us via following emailaddress.Our experienced customer support representative will get back to you, and provide technical support. Support@psier.com

Product Charging

1)Put the earbuds back in the charging case to charging earbuds. 2)Plug the USB type-C to charging the charging case.





Warranty

The warranty covers your device, including accessories against manufacturing defects for 1 year from the date of purchase.

1) Earbuds will auto power on and connect when you take out earbuds from charging case.

3) If you take out earbuds but earbuds don't power on, please charge the charging case.

4) If you put back earbuds but earbuds don't power off, please charge the charging case.

5) If you wearing earbuds without changing case, please long touch MFB button 3 seconds to

2)Earbuds will auto power off and disconnect when you put the earbuds back to charging case.

Certification

"This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation." FCC ID:2A5LA-SP05

Safety For You

- Do not expose device to liquids, moisture or Do not expose device to liquids, moisture or humidity. It has electronics and a battery in it.

 Don't try to disassemble your device. There are no user serviceable parts inside it.
- Neither of them likes getting wet. Don't use abrasive cleaning solvents to clean Try not to drop your device and keep it away from sharp objects such as keys in your pockets. your device. Wipe them down with a slightly damp cloth if and when necessary.
- Remove and clean the earbuds tips regularly, A Only charge your device from 5V USB ports such to ensure that you always enjoy the best sound \forall as phone chargers and laptops or PCs.
- possible from your device. Do not expose device to extremely high or low temperatures as this may damage the battery permanently damage your hearing temperatures as this may damage the battery
- or even deform the plastic parts. On't throw yours device in a fire to dispose it. The internal battery may explode.
- permanently damage your hearing.
 - Pay attention to your surroundings and never wear any headphones while riding, driving or walking in traffic. You do not come with any warranty.