







Step 2

Step 3

the basket.

in each pod.

Step 4

the grow tray.

Insert a soaked sponge in each basket.

Put 1-3 seeds into each sponge in

Tips: 1. For larger seeds, use a knife to cut

and expand the seed hole of the sponge for a

better fit. 2. During the seedling period,


keep those that grow well in the pod and

pull out or cut off those with poor growth, leaving only one plant that grows the best

Put the basket into the pod hole of









Please scan the QR code for the "button operations" in video format.


10

Please turn to the next page for the "button operations" in text format.



















Specification		
Specification		
Model Number	HS02/Z216	
Water Tank Capacity	10L	
Recommended Water Level	6-7L (Please keep the water level between the 6-7L lines throughout the growing process	
Power	24-28.5W (Light Tray: 24W)	
Power Adapter	Power Adapter Input: 100-240V ~ 50/60H Power Adapter Output: 24V === 1500mA	

Water Tank Capacity	10L
Recommended Water Level	6-7L (Please keep the water level between the 6-7L lines throughout the growing process.)
Power	24-28.5W (Light Tray: 24W)
Power Adapter	Power Adapter Input: 100-240V ~ 50/60Hz Power Adapter Output: 24V === 1500mA
as locked. Please first disable the child lock by	he child lock icon at the bottom left of the screen will show
	annot be resolved, please contact our customer support for
assistance. Q: How does the light timer work? A: After plugging in and turning on the machine to keep on for 16 hours first and then keep off	e, it will default to vegetable mode, and the lights will default
Q: How does the light timer work? A: After plugging in and turning on the machine to keep on for 16 hours first and then keep off The lighting duration can be adjusted(24h max page 11 for the button operation texts. Q: How does the fan timer work? Is the session of the sessi	e, it will default to vegetable mode, and the lights will default for 8 hours. And the cycle repeats like this. x). Please turn to page 10 for the button operation video or
Q: How does the light timer work? A: After plugging in and turning on the machine to keep on for 16 hours first and then keep off. The lighting duration can be adjusted (24h max page 11 for the button operation texts. Q: How does the fan timer work? Is the A: After turning on the fan, the fan will work for cycle repeats and cannot be programmed.	e, it will default to vegetable mode, and the lights will default for 8 hours. And the cycle repeats like this. x). Please turn to page 10 for the button operation video or the fan speed adjustable? r 30 minutes and then stop working for 30 minutes. The





A: The real-time environmental temperature shows at the bottom left of the screen. The unit is °C and

A: The time on the screen adopts 24-hour time format, no 12-hour time format option.

wind-pollinated, adding the fans to the machine is a great plus.

Q: How to read the temperature on the screen?

Q: Which time format? 12 or 24-hour time format?

cannot be switched to °F.