

YOU ARE NOW READY TO PLAY!

Made In China Franklin Sports Inc. Stoughton, MA 02072









CUSTOMER SERVICE COMMITMENT

Thank you for purchasing this Franklin® product! In the event that the product you've purchased has missing or damaged parts, please contact us at:

parts@franklinsports.com

or

Visit our website at: franklinsports.com/instructions

If possible, please include product part number and parts description so we can best assist you.

WE'RE HERE FOR YOU!

PLEASE DO NOT RETURN THIS PRODUCT TO THE STORE IT WAS PURCHASED FROM.


WE ARE COMMITTED TO FULFILLING ALL REPLACEMENT PART NEEDS IMMEDIATELY.

Thank you for your continued support, and welcome to the #FranklinFamily!

1

franklin* ITEM#: 24847

PARTS LIST





ASSEMBLY INSTRUCTIONS

- GENERAL NOTES

· Remove all parts from the display box to ensure that you have all of the parts listed.

2





- GENERAL NOTES

 To adjust height, twist upper post counterclockwise to release locking mechanism and adjust upper post to the preferred height. Twist upper post clockwise to lock into place.

Franklin ITEM#: 24847