



## SC-100L Battery Activation Procedure

### **\*\* QUICK START TIP \*\***

1. Remove and set aside the 4 small screws on the Operator plate.
2. Gently pull the Operator plate 4" - 5" away to reveal the intercom assembly.
3. Detach the wiring harness from the battery board.
4. Remove the intercom assembly from the aluminum cylinder.
5. Find the toggle switch on the battery board with the flat battery attached.
6. Flip the toggle on the battery board from "**OFF**" to "**ON**" to activate the battery.
7. **Please do not change any other settings.**
8. Reassemble carefully—avoid pinching wires. The intercom is now ready to install or use.
9. To charge, plug the power converter into a wall socket, then insert the barrel plug into the barrel jack on the Operator plate. **Charge for 12 hours before first battery use.**
10. On Operator plate: **GREEN LED = running charger plugged in. RED LED = battery power.**
11. **For assistance, please call 888-853-4643 or 951-854-1800.**

