


Walkie Talkies

Model: YG-819




User Manual

Caution

- 1.1 This product contains small parts that may cause suffocation if allowed by children.
- 1.2 Do not use the device if the antenna is damaged in any way.
- 1.3 Do not use the device near the radio to avoid interference.
- 1.4 The device cannot be used to contact emergency services.
- 1.5 Please do not disassemble or assemble it by yourself.
- 1.6 To avoid electromagnetic interference or electromagnetic compatibility problems, please turn off the walkie-talkie when there is a "please turn off the walkie-talkie" sign.
- 1.7 Turn off the walkie-talkie before entering the flammable and explosive environment.
- 1.8 Do not charge the battery in a flammable or explosive environment.



Product Description



***PTT (Push to Talk)** : Push to Talk, release to listen


***Power Button**: Long press to Power On or Off

***USB-C**: Connect the charging cable to fast charging

***Display**: Light up different lights when working

Before Use

- Please charge it before using it for the first time, please use a 5V 1A/2A charger.



How to Use

1. Power on or off

Power On: To power on the walkie-talkie, long press the power button . You will hear a power-on tone, and the screen will briefly flash the white dot.

Power Off: To power off the walkie-talkie, long press the power button  again. You will hear a power-off tone, and the screen will briefly flash the white dot.

2. Press PPT to talk

Hold the walkie-talkie 2-3 inches (5-7 cm) away from your mouth, press the PPT button, the screen will light up the white dot and you can speak.

Other walkie-talkies will receive the signal and the screen will light up with the green dot.

Don't cover the microphone when you're talking, and when you're finished, release the PTT (Push to talk, release to listen).

Warranty

The manufacturer's warranty is void under the following circumstances but not limited to:

Improper or inadequate maintenance or modification.
Accident, misuse, abuse, contamination, or other external causes.

The use of unspecified adapter and accessories, Loss or damage in transit.

Damages occur as a result of one's failure to follow the instructions.

This warranty does not apply to expendable or consumable parts.

Customer Service:

We have a customer service team that guarantees hassle-free solutions to any issue you might have within 24 business hours.

FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Compliance and Control Guidelines and Operating Instructions

To control your exposure and ensure compliance with the General Population/Uncontrolled Exposure environmental exposure limits, always adhere to the following procedures.

Guidelines:

Do not remove the RF Exposure Label from the device.

User awareness instructions should accompany device when transferred to other users.

Do not use this device if the operational requirements described herein are not met.

Operating Instructions:

Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the Push-To-Talk (PTT)

key. To receive calls, release the PTT key. Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).

Keep the radio unit at least 2.5 cm away from the face.

Keeping the radio at the proper distance is important as RF exposure decreases with distance from the antenna. The antenna should be kept away from the face and eyes.


When worn on the body, always place the radio in a approved holder, holster, case, or body harness or by use of the correct clip for this product. Use of non-approved accessories may result in exposure levels which exceed the ISED's General Population/Uncontrolled Exposure environmental RF exposure limits.

Use of non-approved antennas, batteries, and accessories causes the radio to exceed the ISED RF exposure guidelines. Contact your local dealer for the optional accessories of the product.

Attention

- 6+ AGES ♻️ 0-3 PLEASE RECYCLE C € ~~WASTE~~ ~~WASTE~~ FC IC

Description du produit



***PTT (Push to Talk):** appuyez pour parler, relâchez pour écouter


***Bouton d'alimentation:** appuyez longuement pour allumer ou éteindre

***USB-C:** connectez le câble de charge à la charge rapide

***Affichage:** allumez différentes lumières lorsque vous travaillez

Français Avant utilisation

- Veuillez le charger avant de l'utiliser pour la première fois, veuillez utiliser un chargeur 5V 1A/2A.



Mode d'emploi

1. Allumer ou éteindre

Allumer : pour allumer le talkie-walkie, appuyez longuement sur le bouton d'alimentation  . Vous entendrez une tonalité de mise sous tension et l'écran fera brièvement clignoter le point blanc.

Éteindre : pour éteindre le talkie-walkie, appuyez longuement sur le bouton d'alimentation  .

Vous entendrez une tonalité de mise hors tension.

2. Appuyez sur PPT pour parler

Tenez le talkie-walkie à 5-7 cm (2-3 pouces) de votre bouche, appuyez sur le bouton PPT, l'écran allumera le point blanc et vous pourrez parler.

D'autres talkies-walkies recevront le signal et l'écran s'allumera avec le point vert.

Ne couvrez pas le microphone lorsque vous parlez, et lorsque vous avez terminé, relâchez le PTT (Appuyez pour parler, relâchez pour écouter).

Garantie

La garantie du fabricant est nulle dans les circonstances suivantes, sans s'y limiter :

Entretien ou modification inappropriés ou inadéquats.
Accident, mauvaise utilisation, abus, contamination ou autres causes externes.

Utilisation d'un adaptateur et d'accessoires non spécifiés, perte ou dommage pendant le transport.

Les dommages surviennent en raison du non-respect des instructions.

Cette garantie ne s'applique pas aux pièces consommables.

Service client :

Nous disposons d'une équipe de service client qui garantit des solutions sans tracas à tout problème que vous pourriez rencontrer dans les 24 heures ouvrables.

ISED Statement

This device complies with Innovation, Science and Economic Development Canada Compliance licence-exempt RSS standard (s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Directives et directives d'utilisation concernant la conformité et le contrôle de l'exposition aux RF .

Pour contrôler votre exposition et garantir le respect des limites d'exposition environnementales de la population générale/ exposition non contrôlée, respectez toujours les procédures suivantes.

Lignes directrices :

Ne retirez pas l'étiquette d'exposition RF de l'appareil.

Les instructions de sensibilisation de l'utilisateur doivent accompagner l'appareil lorsqu'il est transféré à d'autres utilisateurs.

Ne transmettez pas plus que le facteur de service nominal de 50 % du temps. Pour transmettre (parler), appuyez sur la touche Push-To-Talk (PTT). Pour recevoir des appels, relâchez la touche PTT. Transmettre 50 % du temps, ou moins, est important parce que la radio génère une énergie RF mesurable uniquement lors de la transmission (en termes de mesure de conformité aux normes).

Maintenez l'unité radio à au moins 2,5 cm du visage. Il est important de garder la radio à la bonne distance parce que l'exposition aux RF diminue avec la distance par rapport à l'antenne. L'antenne doit être gardée loin du visage et des yeux.

Lorsqu'elle est portée sur le corps, placez toujours la radio dans un support, un étui, un boîtier ou un harnais de sécurité approuvé ou en utilisant le clip adapté à ce produit.

L'utilisation d'accessoires non approuvés peut entraîner des niveaux d'exposition dépassant les limites d'exposition RF de la population générale/environnement d'exposition non contrôlée.

L'utilisation d'antennes, de batteries et d'accessoires non approuvés entraîne un dépassement des limites d'exposition aux RF de l'ISED.

Communiquez avec votre détaillant local pour les accessoires optionnels du produit.