






Spare Parts Catalog of Comfortline inverter (Heating Only) - 2024 Season




(BPNR07~BPNR24)

CONTENTS


Spare Parts Picture	03-04
BPNR07	05-06
BPNR09	07-08
BPNR13	09-10
BPNR17	11-12
BPNR21	13-14
BPNR24	15-16

 ①	 ②	 ③	 ④
Inverter board	LED controller (Heat)	Oval LED (Heat)	Power filter plate
 ⑤	 ⑥	 ⑦	 ⑧
Reactor	Electronic expansion valve	4-way valve	Water flow switch
 ⑨	 ⑩	 ⑪	 ⑫
Fan motor	Fan motor capacitor	Full set of sensors	Compressor
 ⑬	 ⑭	 ⑮	 ⑯
Titanium heat exchanger (Heat)	Evaporator	High pressure protection switch	low pressure protection switch
 ⑰	 ⑱	 ⑲	 ⑳
Low pressure valve	Water union	Water union gasket	Fan




②1

Drainage kit




Position	Spare parts	Part number
1	Inverter board	033091370400
2	PC board (Heat)	033090310400H38
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092350000
5	Reactor	041301090000
6	Electronic expansion valve	006121000001
7	4-way valve	006110080001
8	Water flow switch	040060620000
9	Fan motor	032020250000
10	Fan motor capacitor	041010020001
11	Full set of sensors	Z35043000400
12	Compressor	031034050000
13	Titanium heat exchanger(Heat)	001031160002
14	Evaporator	Z01011270000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010010000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041650000
23	Top cover	002021340615
24	Front Panel	002021340315
25	Right Up Panel	002020621715
26	Right Down Panel	002020621815
27	Back Panel	002021360215
28	Bottom board	Z02021340100
29	Pole	002020800215




Position	Spare parts	Part number
1	Inverter board	033091370400
2	PC board (Heat)	033090310400H56
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092350000
5	Reactor	041301090000
6	Electronic expansion valve	006121000001
7	4-way valve	006110080001
8	Water flow switch	040060620000
9	Fan motor	032020450000
10	Fan motor capacitor	041010020001
11	Full set of sensors	Z35043000400
12	Compressor	031034050000
13	Titanium heat exchanger(Heat)	001031080002
14	Evaporator	Z01011230000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010020000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041650000
23	Top cover	002021300615
24	Front Panel	002021300315
25	Right Up Panel	002020621715
26	Right Down Panel	002020621815
27	Back Panel	002021301715
28	Bottom board	Z02021300100
29	Pole	002020800215




Position	Spare parts	Part number
1	Inverter board	033091390400
2	PC board (Heat)	033090310400H88
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092330000
5	Reactor	041301080000
6	Electronic expansion valve	006121000001
7	4-way valve	006110080001
8	Water flow switch	040060620000
9	Fan motor	032020550000
10	Fan motor capacitor	041010030001
11	Full set of sensors	Z35043000400
12	Compressor	031084030000
13	Titanium heat exchanger(Heat)	001031180002
14	Evaporator	Z01011490000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010140000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041660000
23	Top cover	002021300615
24	Front Panel	002021300315
25	Right Up Panel	002020621715
26	Right Down Panel	002020621815
27	Back Panel	002021321215
28	Bottom board	Z02021321000
29	Pole	002020800215



Position	Spare parts	Part number
1	Inverter board	033091310000
2	PC board (Heat)	033090310400H11
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092330000
5	Reactor	041301100000
6	Electronic expansion valve	006121000001
7	4-way valve	006110210001
8	Water flow switch	040060620000
9	Fan motor	032020900000
10	Fan motor capacitor	041010030001
11	Full set of sensors	Z35043000400
12	Compressor	031084010000
13	Titanium heat exchanger(Heat)	001031110002
14	Evaporator	Z01011260000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010030000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041680000
23	Top cover	002020750515
24	Front Panel	002021330215
25	Right Up Panel	002020621715
26	Right Down Panel	002020621815
27	Back Panel	002021330915
28	Bottom board	Z02021330100
29	Pole	002020800215



Position	Spare parts	Part number
1	Inverter board	033091410400
2	PC board (Heat)	033090310400H13
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092340000
5	Reactor	041301100000
6	Electronic expansion valve	006121010001
7	4-way valve	006110210001
8	Water flow switch	040060620000
9	Fan motor	032020900000
10	Fan motor capacitor	041010030001
11	Full set of sensors	Z35043000400
12	Compressor	031084010000
13	Titanium heat exchanger(Heat)	001031130002
14	Evaporator	Z01011280000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050002
20	Fan	007010030000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041680000
23	Top cover	002020750515
24	Front Panel	002021350115
25	Right Up Panel	002020621715
26	Right Down Panel	002021350515
27	Back Panel	002021351115
28	Bottom board	Z02021330100
29	Pole	002020770615



Position	Spare parts	Part number
1	Inverter board	033091420400
2	PC board (Heat)	033090310400H148
3	Oval LED (Heat)	034090260000
4	Power filter plate	033092370000
5	Reactor	041301110000
6	Electronic expansion valve	006123010001
7	4-way valve	006113020001
8	Water flow switch	040060620000
9	Fan motor	032051700000
10	Fan motor capacitor	/
11	Full set of sensors	Z35043000400
12	Compressor	031084010000
13	Titanium heat exchanger(Heat)	001031220002
14	Evaporator	Z01010650000
15	High pressure protection switch	040050630000
16	Low pressure protection switch	040050130000
17	Low Pressure valve	006080500000
18	Water union (black,50mm)	003990020000
19	Water union gasket	004980050003
20	Fan	007010170000
21	Drainage kit	Z03991700000
22	Compressor insulation cap	004041680000
23	Top cover	002020591100
24	Front Panel	002020770200
25	Right Up Panel	002020592500
26	Right Down Panel	002020591300
27	Back Panel	002020590700
28	Bottom board	002020772200
29	Pole	002020770600