

Instruction Manual of Indoor Thermo-hygrometer

Features

Comfort Index Display: COMFORT, WET, DRY.

Simultaneous Indication: Temperature, Humidity, CLOCK.

Temperature Indication: °C / °F

Max. /Min.Temperature and humidity data store function.

Calendar function, HOUR BEEP function, alarm clock, and 12/24 hour display.

Temperature Range: -50°C~70°C (-58°F~158°F)

Temperature Accuracy: ±1.0°C (1.8°F)

Temperature Resolution: 0.1°C (0.1°F)

Humidity Range: 10%RH~99%RH

Humidity Accuracy: ±5% (35%~75%), and else ±10%

Battery: AAA 1.5V

1. Basic Function Button:

[MODE/SET] is used to shift between the alarm and clock and set the time, alarm and calendar;

[ADJ] is used to adjust the values, turn on/off the alarm and display date;






[MAX/MIN/CLEAR] is used to indicate the MAX and MIN values of temperature and humidity;

[°C/°F] is used to select the unit of temperature between °C and °F;

[RESET] is used to clear the all records, and reset to factory defaults.

- 2. Time and Date Adjustment:** Press the [MODE/SET] for three seconds the digit on “second” will start to flash, then press [ADJ] to adjust. Press [MODE/SET] again, the digit on “hour” will start to flash, then press [ADJ] to adjust. Press [MODE/SET] again it can show 12/24 hour system, and then press [ADJ] to choose. Press [MODE/SET] again, and then press [ADJ] to choose month. Press [MODE/SET] again, and then press [ADJ] to choose

date. Press [MODE/SET] one more time to confirm all the settings.

- 3. Alarm Adjustment:** Press [MODE/SET] to show the alarm time, and press [MODE/SET] for three seconds the digit on “second” start to flash, and then press [ADJ] to adjust. Press [MODE/SET] again the digit on “hour” will start to flash, then press [ADJ] to adjust. Continually press [MODE/SET] twice to confirm.
- Alarm on/off: Press [MODE/SET] to show the alarm time, and press [ADJ] to show the symbol of “” and then press [ADJ] again to show the symbol of “”. Press [ADJ] again, two symbols will be shown together. Continually press [ADJ] can turn on or off those functions, and at last press [MODE/SET] to confirm. When the alarm is ringing, press any button will stop the alarm.
- 4. Calendar Display:** When clock display press [ADJ] can show the date and it will back to clock display in 3 seconds.
- 5. MAX/ MIN Temperature and Humidity Display:** Press [MAX/MIN/CLEAR] to show the MAX/ MIN values of temperature and humidity. Continuously press [MAX/MIN/CLEAR] for 2 seconds can clear all the memory.
- 6. Comfort Index Display:** Temperature between 20°C~26°C (68°F~78.8°F), relative humidity between 50%~70%RH, it will show “ COMFORT”. Under any temperature, it will show “ WET”, as long as the relative humidity is over 70%RH. Under any temperature, it will show “ DRY”, as long as the relative humidity is lower than 50%RH. There is no comfort index display when the temperature is lower than 20°C(68°F) or higher than 26°C(78.8°F) and the relative humidity is between 50%~70%RH.

NOTE:

1. When the digital get blurred, please replace the battery. Please put the used battery into the recycling bin.

2. Operation Environment: 0°C~50°C

3. This thermo-hygrometer is not suitable for industrial usage. It is suitable for household.

1T-00