

INSTRUCTION FOR CORRECT INSTALLATION AND USE WARNING!

- The safety of this fitting can only be guaranteed if these instructions are observed, during both installation and use. Please retain these instructions safety.

REMARKS:

- When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
 - The appliance may in no way be modified or tampered with, any modification may compromise safety causing the appliance to become dangerous.
- Ariel Zuckerman Studio declines all responsibility for products that are modified.
- This appliance must be connected to an efficient grounding system in order to work safely and correctly.
 - Should the external trailing cable get damaged, it must be replaced by qualified personnel in order to avoid any danger.
 - Fixture installation must be done by licensed electrician.


CLEANING INSTRUCTIONS

- Use only a soft cloth to clean the appliance, mild cleanser if needed for resistant dirt.
- Warning: do not use alcohol or other solvents.


O'R // PENDANT




- 1 Turn of electric power
and screw the ceiling bracket



- 2 Connect the wires to the pendant lamp



- 3 screw the ceiling rose



- 4 You can adjust the length of the cable

