

OPERATING THE DRYROBE® ADVANCE ZIP


The dryrobe® Advance features a chunky YKK® two-way reversible zip, which enables you to operate it with your arms either inside or outside of the change robe. You can also partially un-zip it from the bottom to allow more movement if needed for changing, walking, sitting or driving. There's also an easy to grab, branded pull tag too.

How to operate when closing

- ① Pull the upper slider down until it touches the bottom slider.
- ② Insert the separable pin to the very bottom slider. Make sure it's completely inserted.
- ③ Pull up the upper slider to close the zip.

How to operate when opening

- ① Completely pull down the top slider until it touches the bottom slider.
- ② Gently pull out the separable pin.



 **dryrobe®**