### **SwitchBot** Pan/Tilt Cam 2K User Manual




Package Contents

Micro USB Cable

(2 m [6.6 ft.]) × 1

Please read this user manual carefully before using Sticker x 1

# List of Components



# Specifications

Product Name: SwitchBot Pan/Tilt Cam 2K Model: W3101100

Power Input: 5 V = 2 A Video Resolution: 2K

Image Compression: H.264 Field of View: 100° diagonal

Storage: Supports up to 256 GB microSD card,

Operating Temperature: -15 °C to 45 °C

(5 °F to 113 °F)

FAT32 format

Operating Humidity: ≤95 % RH

Network Connectivity: 802.11b/g/n, 2.4 GHz

### Instructions

### Add Device to the SwitchBot App

• Connect the device to a power supply Connect the camera to power supply using cable. The light indicator on the camera will flash red when power is connected.



Download and install the SwitchBot app Download the SwitchBot app on App Store or Google Play Store.






#### Add the camera • Open our app, create a SwitchBot account or

- sign in directly if you already have one. Put the camera closer to the router and ensure
- that the camera is powered on.
- Tap "+" at the top right of the Home page, find the Pan/Tilt Cam 2K icon and select, then follow the instructions to add your camera.

#### Precautions


- 1. When letting your camera scan the QR code on your phone to access the internet, please make sure that your phone screen is brighter than the surrounding environment.
- 2. Make sure the anti-rub function of your Wi-Fi is turned off. Turning on this function may lead to a connection failure.
- 3. Please make sure your camera is connected to a 802.11b/g/n, 2.4GHz, IPV4 wireless network.

### How to Install



② Install on a ceiling or wall


want to install on.



① Put on a table



Attach the sticker to a ceiling/wall surface you



### Features

Then install the base at the place of the sticker.

Attach the camera firmly on the base.

If you are installing the camera on a ceiling, go to


Pan/Tilt Cam 2K > Settings > Basic Settings in the


app and turn on the Flip Screen function.

### 1. Pan-Tilt Control

Pan-Tilt Control consists of vertical and horizontal control. The vertical visual angle is 115° and horizontal visual angle is 360°. You may control its direction and view images from different angles remotely via the app.







www.switch-bot.com V2.0-2205

### 2. Motion Detection

When Motion Detection is turned on, Pan/Tilt Cam 2K will take a photo and record a video (requires a memory card and Recording to be turned on) of any moving object detected and send you notifications (requires Allow Notifications to be turned on).

#### 3. Motion Tracking

When Motion Tracking is turned on, Pan/Tilt Cam 2K will follow the objects as they move, and rotate horizontally or vertically to keep them in the middle of the screen. It will also take a photo and record a video of the event (requires a memory card and Recording to be turned on).

#### 4. Third-Party Integration

Pan/Tilt Cam 2K can connect to Amazon Alexa and Google Assistant for voice control.

 After adding the device, please ensure your phone has a normal network connection.

 Go to Pan/Tilt Cam 2K> Settings > Cloud Services in the app and link the third-party services to your SwitchBot account.

#### Alexa, show my Pan/Tilt Cam. ` Resetting Factory Settings

• (Hey Google, show my Pan/Tilt Cam. )

the dark scene more clearly.

When Night Vision is turned on, Pan/Tilt Cam 2K

will turn on infrared light and change the video

to black and white. You can set this mode as Auto.

so when the camera senses the surrounding is

dark. Night Vision will auto turn on for you to see

When Privacy Mode is turned on, Pan/Tilt Cam 2K

will enter hibernation and the camera lens will

rotate to the inside. You will not be able to watch

live videos via the app and features related to


images like Motion Detection/Tracking will also

5. Night Vision

6. Privacy Mode

Find the reset hole, hold down the reset button at the bottom with the reset pin for around 5 seconds until you hear a prompt tone. Now your camera has been reset and is ready for network reconfiguration.





## LED Indicator Light

LED Indicator Light

LED Indicator Light		Description
• Red	Stays lit up	Device starting
Red	Flashes rapidly (0.25 s/ flash)	Ready to configure Wi-Fi
<ul><li>Green</li></ul>	Flashes slowly (1.5 s/ flash)	Connecting to Wi-Fi router
<ul><li>Green</li></ul>	Flashes rapidly (0.25 s/ flash)	Connected to Wi-Fi router and now connecting to the internet
<ul><li>Green</li></ul>	Stays lit up	Decive is online
<ul><li>Red</li><li>F</li><li>Green</li></ul>	Flashes rapidly alternately (0.25 s/ flash)	Connected to Wi-Fi router but failed to connect to the internet
<ul><li>Red</li><li>Green</li></ul>	Flashes slowly alternately (1.5 s/ flash)	Error in network connection

Description

## Return & Refund Policy

This product has a three-year warranty which begins from date of purchase. Should the following situations occur, your warranty and/or your eligibility for a return or refund may not be valid.

- Warranty expires. Intended damage or abuse.
- Inappropriate storage (including dropping or
- soaking in water). Unauthorized modifying or repair of product.
- Natural wear of product.
- Natural disasters.

#### Contact & Support

Setup and Troubleshooting: support.switch-bot.com

Support Email: support.switch-bot.com

Feedback: If you have any concerns or problems when using our products, please send feedback via our app through the Profile > Feedback page.

## Safety Information

- This camera is for indoor use only.
- Keep the device away from water, fire, humid • Unplug this device if there is lightening storms
- or when unused for a long period. • Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers apart from those recommended.

or hot environments.

- Do not use in places where wireless devices are not allowed.
- Adapter shall be installed near the equipment and shall be easily accessible.

declares that the radio equipment type W3101100 is in compliance with UK Radio Equipment Regulations (SI 2017/1206). The full text of the UK declaration of conformity is available at the following internet address:

This product can be used in EU member states and

### CE Warning

To comply with RF exposure requirements, a minimum separation distance of 20 cm must be maintained between the user's body and the device, including the antenna. Use only the supplied or an approved antenna. This device is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU. All essential radio test suites have been carried

Hereby, Woan Technology (Shenzhen) Co., Ltd. declares that the radio equipment type W3101100 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: support.switch-bot.com

#### UKCA DOC

Hereby, Woan Technology (Shenzhen) Co., Ltd. support.switch-bot.com

Address: Room 1101, Qiancheng Commercial Center, No. 5 Haicheng Road, Mabu Community, Xixiang Subdistrict, Bao'an District, Shenzhen, Guangdong, P.R.China, 518100

Manufacturer: Woan Technology (Shenzhen) Co., Ltd.

Importer Name: Amazon Services Europe

Importer Address: 38 Avenue John F Kennedy, L-1855 Luxembourg,

Art4-EURep@amazon.com Operation frequency (Max power)

Wi-Fi: 2412 MHz to 2472 MHz (14.78 dBm)

### FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received. including interference that may cause undesired

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate

in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television. reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the

radio frequency energy and, if not installed and used

following measures:

- Reorient or relocate the receiving antenna. - Increase the separation between the equipment

and receiver. - Connect the equipment into an outlet on a circuit

different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV

technician for help.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

#### KCC Warning 인증받은자의 상호: Woan Technology (Shenzhen) Co., Ltd.

제품명/모델명: SwitchBot Pan Tilt Cam 2K/W3101100 특정소출력 무선기기(무선데이터통신시스템용 무선기기)/ W3101100 제조자 및 제조국가: Woan Technology (Shenzhen) Co., Ltd. /

제조년월: 2022.07

인증번호: R-R-Woa-W3101100

이 장치는 보안성이 없으므로 통신보안에 위배되는 사항의 통신을 금지하며 운용 중

China

#### NCC Warning

取得審驗證明之低功率射頻器材,非經核准,公司、商號 或使用者均不得擅自變更頻率、加大功率或變更原設計 之特性及功能。

低功率射頻器材之使用不得影響飛航安全及干擾合法 涌信:經發現有干擾現象時,應立即停用,並改善至無干 擾時方得繼續使用。前述合法通信,指依電信管理法規

電波輻射性電機設備之干擾。

定作業之無線電通信。 低功率射頻器材須忍受合法通信或工業、科學及醫療用