




BLE5.0 Asynchronous Wireless Controller

Dimensions:




Connection:




Wireless sensor installation:

A


Recessed installation




1




2



3




4




B


Surface Mounted installation




1



















Screw installation



Double-sided tape installation



Wireless sensor function description :

Door sensor Distance range:0-12cm	
  	
Dimming& CCT variable sensor	
	  Control color temperature Control brightness
Side IR sensor Distance range:3-12cm	
 On/Off Swipe once 	 Hold for 2s  Brightness control
PIR sensor	
 On 	 
Touch sensor	
 Press once  On/Off	Press and hold   Brightness control
Front IR sensor Distance range:3-12cm	
 Swipe once 	 Hover  Brightness control
Side IR-Touch sensor Distance range:3-12cm	
 On/Off Swipe once 	Press once  On/Off  Long press brightness control

Controller match code:

1



Red light flashing (Connected, lights flash 3 times)

Press and hold for 3~5S(Reset)

Power Unplug

2

①

Press 2 times...7 times


Press and hold for 3~5S(Reset)



Please finish matching within 20s

②

Press once



You can only match the same type of door sensor after matching one door sensor, Or it will cause unsuccessful matching. Use the same type of sensor and try again.




Scan the code to view the operation manual

Press 7 times Press 6 times Press 5 times Press 4 times Press 3 times Press 2 times

output6 output5 output4 output3 output2 output1

Monochrome




Each channel is selected, the corresponding indicator light is

Press 3 times

Press 2 times

output2 output1


CCT



The output load light is on

③

Red light flashing (Connected, lights flash 3 times)



5 Sensor Max