
# INSTRUCTION MANUAL Zigbee Curtain Module






### TECHNICAL SPECIFICATIONS

Product type	Zigbee Curtain Module
Voltage	AC100-240V 50/60Hz
Max. load	3A
Operation frequency	2.405GHz-2.480GHz IEEE802.15.4
Operation temp.	-10℃ + 40℃
Protocol	Zigbee 3.0
Operation range	<100m
Dims (WxDxH)	39.2x39.2x18 mm
IP rating	IP20
Warranty	2years
Certificates	CE ROHS

## with mounting clip





# INSTALLATION

### ▲ Warnings:

 Installation must be carried out by a qualified electrician in accordance with local regulations.

- 2. Keep the device out of reach of children.
- Keep the device away from water , damp or hot environment.
- Install the device away from strong signal sources such as microwave oven that may cause signal interruption resulted to abnormal operation of the device.
- Obstruction by concrete wall or metallic materials may reduce the effective operation range of the device and should be avoided.
- Do NOT attempt to disassemble,repair or modify the device.





### Wiring Instructions and Diagrams

- Turn off the power supply before carrying out any electrical installation work.
- 2.Connect wires according to the wiring diagram.
- 3.Insert the module into the junction box.
- Turn on the power supply and follow switch modul e con guration instructions.

Global international operation Whenever & Wherever





### Inhouse local operation



### MANUAL OVERRIDE

The Curtain module terminal reserves the access of manual override function fort he end-user to switch on/

If you have connected the wall push-button, check its work. Single pressing ofthe "down" button / "up"

button, will cause that the roller shutters moves in the desired direction to the end position. If the ele-ctric shutter goes in the opposite direction to the expected, select "motor reversal" in the "More" op-tion. When the electric shutter is moving up, press-ing "up button switches causes that the shutter will stop immediately; when the electric shutter is moving down, pressing "down" button switches causes that the shutter will stop immediately.

#### Note

- Both the adjustm ent on App and Curtani can overwrite each other, hte last adjusmten t rem ains ni memory .
- The App control is synchronized with the manual switch.
- Traditional switch selection button type.

### FAQ

- Q1: What should I do if I can't configure the switch module?
- a. Please check whether device is powered on.
- b. Make sure the Zigbee Gateway is available.
- c. Whether it's in good internet conditions.
- d. Make sure the password entered in App is correct.
   e. Make sure the wiring is correct.
- e. Wake sure the willing is correct
- Q2: What device can be connected to this Zigbee switch module?
- Q3: What happens if the WIFI goes off?
- Most of your household electrical appliances,
- such as lamps, laundry machine, coffe maker, etc.
  You can still control the device connected the switch
  module with your traditional switch and once WIFI is
  active again the device connected to module will
- connect automatically to your WIFI network.

  Q4: What should I do if I change the WIFI network or change the password?
- You have to re-connect our Zigbee switch module to the new Wi-Fi network accordingly as per the App User Q5: How do I reset the device?
- 1. Power on/off device for 5 times until the indicator light flash.
- Switch on/off the traditional switch for 5 times until the indicator light flash.
- Press the reset key for about 10 seconds until the indicator light flash.

### APP USER MANUAL



IOS APP / Android APP



Scan the QR code to download Tuya Smart App, or you can also search keyword "Tuya Smart" at App Store or Googleplay to download App.





Log in or register your account with your mobile number or e-mail address. Type in the verification code sent to your mobile or mail box, then set your login password. Click "Create Family" to enter into the APP.




The connecting will take about 10–120 seconds to complete depending on your network condition.



Open the control panel of the ZigBee

Before making the reset operation, pls make sure the Zigbee Gateway is added and installed to the WIFI network. Ensure that the product is within the range of Zigbee Gateway Network.



After the wiring of switch module is done, press the reset key or the traditional switch for about 10 seconds until the indicator light inside the module is flashing quickly for pairing.



Click "+" (Add sub-device) to select the suitable product gateway and follow the on-screen instruction for paring.



When pairing is done, the Zigbee curtain will be shown on the  $\ensuremath{\mathsf{App}}.$ 




Connect to amazon alexa or Google Assistant for voice control, or share the devices with your families or friends.

### SYSTEM REQUIREMENTS

WIFI<sup>®</sup> Router ZigBee gateway iPhone, iPad (iOS 7.0 or higher) Android 4.0 or higher



# INSTRUCTION MANUAL WIFI Curtain Module






### TECHNICAL SPECIFICATIONS

Product type	WIFI Curtain Module
Voltage	AC100-240V 50/60Hz
Max. load	3A
Operation frequency	2.412GHz-2.484GHz
Operation temp.	−10°C + 40°C
Protocol	WIFI IEEE 802.11b/g/n
Operation range	<100m
Dims (WxDxH)	39.2x39.2x18 mm
IP rating	IP20
Warranty	2years
Certificates	CE ROHS

## with mounting clip



### Global international operation Whenever & Wherever You are.All-in-one Mobile App



Inhouse local operation



### INSTALL ATION

### ▲ Warnings:

- 1. Installation must be carried out by a qualified electrician in accordance with local regulations.
- Keep the device out of reach of children.
- 3. Keep the device away from water , damp or hot environment.
- 4. Install the device away from strong signal sources such as microwave oven that may cause signal interruption resulted to abnormal operation of the device
- 5. Obstruction by concrete wall or metallic materials may reduce the effective operation range of the device and should be avoided.
- 6. Do NOT attempt to disassemble, repair or modify the device.

### FAQ

- Q1: What should I do if I can't configure the switch
- a. Please check whether device is powered on.
- b. Make sure your mobile and switch module are under the same 2.4 Ghz WIFI network.
- c. Whether it's in good internet conditions.
- d. Make sure the password entered in App is correct.
- e. Make sure the wiring is correct.

O2: What device can be connected to this Wi-Fi switch module?

Most of your household electrical appliances can be, such as lamps, laundry machine, coffe maker, etc.

Q3: What happens if the WIFI goes off?

You can still control the device connected the switch module with your traditional switch and once WIFI is active again the device connected to module will connect automatically to your WIFI network.

Q4: What should I do if I change the WIFI network or change the password?

You have to re-connect our Wi-Fi switch module to the new Wi-Fi network accordingly as per the App User Manual.

Q5: How do I reset the device?

Power on/off device for 5 times until the indicator light flash.

# MANUAL OVERRIDE

The Curtain module terminal reserves the access of manual override function fort he end-user to switch on/

· If you have connected the wall push-button, check its work. Single pressing ofthe "down" button / "up" button, will cause that the roller shutters moves in the desired direction to the end position. If the ele-ctric shutter goes in the opposite direction to the expected select "motor reversal" in the "More"op-tion. When the electric shutter is moving up, press-ing "up" button switches causes that the shutter will stop immediately; when the electric shutter is moving down, pressing "down" button switches causes that the shutter will stop immediately.

### Notes:


- 1) Both the adjustm ent on App and Curtani can overwrite each other, hte last adjusmten t rem ains ni memory .
- 2) The App control is synchronized with the manual switch
- Traditional switch selection button type.


### Wiring Instructions and Diagrams

- 1. Turn off the power supply before carrying out any electrical installation work.
- 2. Connect wires according to the wiring diagram.
- 3.Insert the module into the junction box.
- 4. Turn on the power supply and follow switch module configuration instructions.

Notes: Take your smartphone close to the switch module when you're configuring, and make sure you have min. 50% Wi-Fi signal.







### APP USER MANUAL



IOS APP / Android APP


1

6





Log in or register your account with your mobile number or e-mail address. Type in the verification code sent to your mobile or mail box, then set your login password. Click "Create Family" to enter into the APP.



After the wiring of switch module is done, press the reset key or the traditional switch for about 10 seconds until the indicator light inside the module is flashing quickly for pairing.



1,Support multi–protocol matching: WIFI/Bluetooth. 2,Turn on Bluetooth,Click "+", follow the on–screen instruction for paring.



The connecting will take about 10–120 seconds to complete depending on your network condition.




6

Finally, you can control the device via your mobile phone.





Connect to amazon alexa or Google Assistant for voice control, or share the devices with your families or friends.



Enjoy your smart life of home automation for lighting control by using our All-in-one mobile app wherever you are in the world or simply by voice control when you are sitting at home comfortably.