



## Lateral rest platform

Art.-No. for left: 836779 and art.-no. for right: 836762

Assembly instructions




Version 1.0 © 2025 | KRAUSE-Werk

[www.krause-systems.com](http://www.krause-systems.com)



**QUALITY**  
Since 1900



Art.-No: 836779



Art.-No: 836762

### Intended use



- These lateral rest platforms may only be connected to the KRAUSE steel fixed ladder.
- **Attachment to the aluminium fixed ladder is prohibited!**
- These lateral rest platforms may only be used on fixed ladders in accordance with DIN EN 18799-1.
- The corresponding KRAUSE fixed ladder assembly and usage instructions must also be observed.
- Installation may only be carried out with these verified wall holders at the standard maximum fixing distance of 1,960 mm:  
**Art.-No.: 835239, Art.-No.: 835192, Art.-No.: 835208, Art.-No.: 835215, Art.-No.: 837561, Art.-No.: 837554, Art.-No.: 835086, Art.-No.: 835093, Art.-No.: 837646**
- At least M12, 8.8 screws must be used in all holes of the holders for fastening!
- Use only anchoring devices approved by the building authorities which can transfer the loads into the anchoring base.
- Depending on the anchoring substrate, it must be ensured that the occurring forces can be transferred to the substructure. If necessary, this must be checked and verified by the structural engineer.
- The substrate must have sufficient load-bearing capacity.






















### IMPORTANT! READ CAREFULLY BEFORE USE



Keep for future reference!

Subject to technical modifications, printing errors and mistakes; in cases of doubt, the original German text should be consulted. The specified dimensions and weights have been determined on the basis of the technical drawings; the actual dimensions and weights may deviate due to tolerances and rounding. None of the accessories, EXTRAS or work equipment shown are included in the scope of supply. No liability shall be accepted for improper use. Only use genuine KRAUSE replacement parts.





Assembly of art.-no.: 836762 (art.-no.: 836779 mirror-imaged)




	1 x
	1 x
	1 x
	1 x
	1 x
	1 x (M8 x 45 mm)
	2 x
	4 x 1,500 mm




	15 x M8 x 20 mm
	33 x M8 x 20 mm
	50 x 8,4 mm
	8 x
A 	1 x M8 x 65 mm
B 	10 x M8 x 45 mm
	2 x
	4 x
	3 x
	1 x
	1 x M8 x 25 mm




Not included in the scope of delivery:

	9 mm
	2 x 13 mm
	Nm
	2 x


	10 Nm
	1 x
	1 x





c)





d)




2.




1.





2.





2.




3.



3.




1.




5 x

2.




4 x

2.






4 x

3.




3 x

4.



2 x



2 x

