



RAINBOW *Lite*

NAME OF EACH PART

Indicator

View button

Menu button

LT

RT

LB

RB

LS

A/B/X/Y

Left joystick

LED1

LED4

LED2

LED3

Triangle button

HOME button

D-pad

Right joystick

RS

USB port

M2 Remappable button

M1 Remappable button

FN button

3.5mm
headphone jack



Type-C
data cable

PACKAGE CONTENTS	BIGBIG WON RAINBOW LITE*1 / User Manual*1 Qualified Certification*1 / 1.8m Ultra-light soft braided data cable*1
SUPPORTED PLATFORM	win10/11 / Switch

CONNECTION

This controller is a wired controller, so you only need to use a Type-c data cable to connect the controller to the console.

Note: This controller supports Xinput and Switch modes. After connecting with the console, you need to switch to the correct mode. The default setting is Xinput.

Steam: To connect to Steam, you need to check the "Xbox Configuration Support" in the "Settings - Controller -GENERAL CONTROLLER SETTINGS" of Steam. Otherwise, it may cause unrecognized issues within the game.

Switch: After connecting the Switch, you need to turn on "System Settings - Controllers and Sensors - Pro Controller Wired Communication".

MODE SWITCH

This controller supports two modes: Xinput and Switch. After connecting, you need to switch to the corresponding mode to use it normally.

The setting method is as follows:

Hold the B+HOME button for 3 seconds until the indicator turns green, which means switching to Xinput mode;

Hold the A+HOME button for 3 seconds until the indicator turns red, which means switching to Switch mode.

LIGHT EFFECT

This controller has a variety of built-in lighting effects. Double-click the FN button to switch or turn off the light.

REMAP

This controller comes has two remappable back buttons and supports changing key values. The setting methods are as follows:

Remap:

Press FN + (M1/M2), and the indicator will breathe in green, indicating that it has entered the remapping mode;

Then press the front button that needs to be mapped, and the indicator will flashes twice in green, indicating that the key mapping is successful.

Clear key value:

Press and hold the "button need to cancel the key mapping(M1/M2)", and double-click FN, and the indicator will flashes twice in green, indicating that the cancellation is successful.

TURBO

This controller supports Turbo, and the supported buttons include A/B/X/Y/LT/RT/LB/RB eight buttons.

The setting methods are as follows:

Set TURBO:

Hold FN + the "key need to be set", the indicator will flash in orange, which means it is successfully turned on.

When the TURBO is opened, the 2nd and 3rd LED lights will flash according to the TURBO frequency.

Cancel TURBO:

Hold the "button need to cancel TURBO" and double-click the FN button, the indicator will flash twice in orange, which means the cancellation is successful.

TURBO frequency:

Hold FN + ← to cycle between 5/s, 10/s, and 20/s three frequencies, the default is 5/s.

MACRO RECORDING

This controller supports the MACRO recording function, each set of MACRO must be bound with a remappable back button (M1/M2) as the trigger. The buttons support recording: A/B/X/Y, ↑ / ↓ / ← / →, LT/RT/LB/RB, RS/LS, and eight directions of the joystick.

The setting methods are as follows:

MACRO recording:

Hold FN + (M1/M2) for 3 seconds, the indicator will breathe in red, indicating that it has entered the MACRO recording mode. Press the buttons of the controller to record the MACRO. After finishing the recording, clicks FN once to end the MACRO recording. The indicator will flash twice in red. During the execution of the MACRO, the four LEDs will flash from left to right until the MACRO ends.

Clear MACRO:

Hold the "button need to cancel the macro (M1/M2)" and double-click, the indicator will flash twice in red, indicating that the cancellation is successful.

DEADZONE OF JOYSTICK

This controller is made for pro-competitive, so the deadzone of the joystick is 0 in the factory default configuration. This will allow players to get greater control accuracy,

but will also result in slight drift in games without dead zones. To take care of more players, we have set 0/10 dead zones for different players. The changing methods are as follows:

Hold FN + the left or right joysticks down (LS/RS) to switch between 0/10 for the deadzone of the left or right joysticks respectively.

HAIR TRIGGER

This controller supports the hair trigger setting, this function can help the operation of the linear trigger be faster. The trigger set with a quick trigger will lose its "linear". Press the trigger to "on", and lift the trigger for any distance to "off". You can press the trigger again without lifting it to the original position, which can greatly optimize the speed of operation. The setting methods are as follows:

On/Off Hair Trigger:

Hold the Triangle button + Trigger (LT/RT), the indicator will flash twice in cyan indicating that the Hair Trigger is successfully turned on.

Hold the Triangle button + Trigger (LT/RT) the indicator will flash twice in cyan again indicating that the Hair Trigger is successfully turned off.

SCREENSHOT

This CONTROLLER supports one-click screenshots. In Xinput and Switch modes, clicking the triangle button will be used as the screenshot button.

(The screenshot file of the PC platform is saved in "This computer - Picture - Screenshot")

AUDIO

This controller supports audio input/output. After connecting the console, you can plug the headset with a microphone into the 3.5mm audio port at the bottom of the controller. And you can set the volume by press FN+ ↑ / ↓ . (Only on PC)

VIBRATION ADJUSTMENT

This controller supports four-speed vibration adjustment, and the setting methods are as follows:

Press FN + → , and the vibration of the trigger motor can be cyclically switched between strong, medium, weak, and off.

DETAILED FUNCTIONAL OPERATION INSTRUCTIONS

Please access "BIGBIG WON Official Website>Support" to check the instruction

<https://www.bigbigwon.com/support/>



Scan the QR code to watch video tutorial

Visit the official support page for a detailed video tutorial:

www.bigbigwon.com/support

If you have any questions or issues, please submit a support request
through the ways below:

 AMAZON Product page> Seller profile> "Ask a question"

Customer Service Address: support@bigbigwon.com



BIGBIG WON SUPPORT



WELCOME TO THE BIGBIGWON COMMUNITY

The BIGBIG WON community is built to connect those who seek the winning edge.
Join us Discord and Follow our social channels for the latest offerings, exclusive event
coverage, and opportunities to score BIGBIG WON hardware.



BIGBIG WON DISCORD

     YouTube @BIGBIG WON

PLAY BIG. WON BIG

© 2022 BIGBIG WON Inc. All rights reserved.
Product may vary slightly from pictures.