



MCHOSE G3 Series

Wireless Mouse

User Guide



Overview




- 1** Left click button
- 2** Right click button
- 3** Mouse wheel
- 4** Forward button
- 5** Back button
- 6** DPI switch button

- 7** DPI Indicator light
- 8** Mode switch button
- 9** Connection indicator light
- 10** Power switch
- 11** Wireless receiver

Installation

Charge/wired connection





- Connect the cable to Type-C port of the mouse, and connect the cable to a USB 2.0(high-speed) or higher port of the computer.
- In 2.4G/BT mode, plugging in the USB cable automatically switches the mouse to wired mode and simultaneously charges the mouse.

Installation

2.4G RF connection

- Press **[Mode switch button]** to enter 2.4G connection mode when **[Connection indicator 1]** lights up. Connect the USB receiver to the computer and the mouse is ready to use.




Manual pairing dongle (The dongle is default paired)

Enter 2.4G connection mode, press the **[Mode switch button]** simultaneously for about 5 seconds. The Mouse will enter the re-pairing mode and the indicator light flashes. Re-plug the receiver and bring the mouse close to the receiver (within 20cm), and the Indicator light will be off after a successful connection.

Installation

BT connection

- Press **[Mode switch button]**
to enter BT2 connection mode
when **[Connection indicator 2]**
lights up.



(The method is same for BT2
mode which use **[Connection indicator 3]**)




- Press **[Mode switch button]**
simultaneously for about 3 seconds.
The Mouse will enter the pairing
mode and the indicator light flashes.
Search for the device with the pairing
name **[G3 Mouse]** and pair, the
indicator light will be off after the
pairing is successful.

Software

To customize DPI, macro settings, update the newest firmware, and more, please download software at

<https://www.mchose.store/pages/firmware-2>



DPI

There are 6 default DPI presets.

Press the **[DPI switch]** button at the bottom of the mouse to cycle through DPI levels. Customizing and saving DPI levels can be done within MCHOSE L7 driver software.

Factory DPI setting	
DPI level	Indicator color
400	Red
800	Blue
1600	Green
3200	Yellow
6400	Cyan
12000 ^[1]	Purple





[1] G3 Ultra is equipped a PAW3950 sensor with 42000 DPI in purple light.


Power indicator

When the **[DPI Indicator Light]** is flashing red, please charge the mouse promptly.



 The red indicator light is flashing:
Please charge immediately.

 The red indicator light is on:
Charging in progress.

 The green indicator light is on:
Charging complete