


EN

SPECIFICATIONS:

Number of keys: 100(Hot-swappable Mechanical Switch)
Numbers of Multifunction Keys: 15
Materials: ABS Body , PBT+ABS Keycaps
Interface: Type-C
Mode: Wired/Bluetooth/2.4G
Bluetooth Name: Flow100-L@Lofree
Dimensions: 374.5X138X23.5mm

Diagram:



① Battery Indicator

Charging:Indicator on breathing white
Charged:Indicator always on white
Battery<20%, Indicator on breathing red
Battery<5%, Indicator flashing till off

② Numeric keypad Indicator light

Press to switch between mute and non-mute
Press to switch between mute and non-mute

③ Caps Lock Indicator(White)/Status Indicator(Blue)

・Caps Lock Indicator(White)
Indicator white light enabled: Caps lock on
Indicator white light disabled: Caps lock off
・Bluetooth Pairing Indicator(Blue)
During Bluetooth pairing, Indicator blinks slowly for 1 min,
after success, Indicator keeps on for 3s
During device switching, Indicator flashes for 3s,
after success, Indicator keeps on for 3s
During Bluetooth reconnection, the indicator keeps blinking
After reconnection, the indicator keeps on for 3 seconds,
and then recovers to the previous state

⑤ Type-C Interface

Wired/Charging port

⑥ Mode Switch


X OFF/ N Wired Mode/ W Wireless Mode

⑦ 2.4G Receiver

Detailed Operation


Wired Connection:

① Toggle the mode switch to N




Bluetooth Connection:


① Toggle the mode switch to W



③ Find and pair "Flow100-L@Lofree" on your list of paired devices




④ Status Indicator: Indicator keeps on for 3s and turns off




2.4G Wireless Mode:

① Take out the 2.4G receiver from the bottom of the keyboard




③ Toggle the mode switch to W



② Insert the 2.4G receiver into the USB port of the device, and the corresponding 2.4G light will always be on after successful connection



④ Press Fn+4 for 1 second to enter 2.4G mode



Note:

1.The keyboard and 2.4G receiver are paired to each other from the factory, simply pair the device by inserting it
2.MAC/iOS system devices do not support multimedia functions under 2.4G&USB connection


Multifunction Keys

Fn + F1.....Del= Multimedia Key

Function Sign	Mac	Windows
FN+F1	* Screen BR -	Screen BR -
FN+F2	* Screen BR +	Screen BR +
FN+F3	Multi-Screen	Multi-Screen
FN+F4	Search	Search
FN+F5	Backlit -	Backlit -
FN+F6	Backlit +	Backlit +
FN+F7	Prev Song	Prev Song
FN+F8	Play/Pause	Play/Pause
FN+F9	Next Song	Next Song
FN+F10	Mute	Mute
FN+F11	VOL-	VOL -
FN+F12	VOL+	VOL +
FN+Opt/Ctrl	/	Menu
FN+Prtsct	/	Calculator
FN+Del	/	Lock

Use of Ambient Light:

① Fn + ←/→ : Steady/Breathe/Off



System Switch

Fn+N is to trigger the corresponding system function key of windows/Android

Fn+M is to trigger the corresponding system function key of Mac/iOS

NAME AND CONTENT OF HAZARDOUS SUBSTANCES IN PRODUCT:

Harmful Elements	Hazardous substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr+VI)	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Plastic Components	0	0	0	0	0	0
Circuit Board Assembly	0	0	0	0	0	0
Silicone Components	0	0	0	0	0	0
Spare Parts	0	0	0	0	0	0

This table is prepared in accordance with the provisions of SJ/T 11364.
The classification and marking of this product was performed in accordance with the EU directive 2011/65/EU and the revised directive 2015/863/EU.
OIndicates that the said hazardous substance contained in all the homogeneous materials for this component is below the limit requirement in GB/T 26572.
XIndicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572.

ENVIRONMENTAL PROTECTION INSTRUCTIONS:

The hazardous substances contained in the electronic parts of this product will not leak or change under normal use conditions for a period of ten years. During the same period, the electronic components of this product will not cause serious environmental pollution or serious damage to human health or property while the products are being used by the consumer.
According to the Chinese electronic industry standard SJ/T 11364-2014 and related Chinese government regulations, this product and some of its internal or external components may have an environmentally friendly use period mark, depending on the component and component manufacturer, the mark lifespan on the product and its components may vary. The expiration date on the component takes precedence over any conflicted or different UFUP labels on the product.

Warning:

• If the battery is not replaced properly, there may be leakage or explosion and personal injury hazards.
• Do not use the battery when there is leakage, discoloration, deformation, or any other abnormality.
• Do not leave the battery in a discharged or unused state for a long time.
• Do not short-circuit the product.
• Battery life varies with usage. Used batteries should be disposed of in accordance with local laws or thrown away in trash cans for recycling electronic devices.
• If any liquid accidentally enters the product, please immediately disconnect the power supply and remove the product. Continue to use the product may cause fire or electric shock. Please contact the agent or the nearest customer service center for inspection and maintenance.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
~ Reorient or relocate the receiving antenna.
~ Increase the separation between the equipment and receiver.
~ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
~ Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement


This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

JP

仕様

キーの数:100(ホットスワップ対応)
マルチ機能キーの数: 15
素材:本体:ABS、キーキャップ:PBT+PC
インターフェース:Type-C
モード:有線/Bluetooth/2.4Ghz
Bluetooth名:Flow100-L@Lofree
サイズ:374.5X138X23.5mm

ダイアグラム



① バッテリーインジケター

充電中はインジケターが白く点滅します。
フル充電された時には白く点灯します。
バッテリーが20%以下になると、赤く点滅します。
バッテリーが5%以下になると、電源が切れるまで素早く点滅します。

② ナンバーパッドインジケター

上にスクロールすると音量が上がり、下にスクロールすると音量が下がります。
スクロールキーを押すとミュートと非ミュートが切り替わります。

④ Caps Lock/状態インジケター(白&青)

・Caps Lockインジケター(白)
インジケターが常時点灯:Caps lock on
インジケターが消灯:Caps lock off
・ブルートゥースペアリングインジケター(青)
ブルートゥースペアリング中、インジケターが1分間ゆっくり点滅し、接続後3秒間点灯し続けます。
デバイス切り替え時、指示灯が3秒間素早く点滅し、接続後3秒間点灯し続けます。
ブルートゥース再接続時、指示灯が点滅し続けます。
再接続後、指示灯が3秒間点灯し続け、前の状態に戻ります。

⑤ Type Cインターフェース

有線/充電

⑥ モードの切替


X OFF/ N 有線 / W 無線

⑦ 2.4Ghzレシーバー

操作方法


有線接続:

① モードスイッチを N に切り替えます。



ブルートゥース接続:


① モードスイッチを W に切り替えます。



③ デバイスリストで「Flow100-L@Lofree」を探し、ペアリングを行います。



④ インジケターが3秒間点灯し続けた後、消灯します。



2.4Ghz接続:

① 2.4Ghzレシーバーをキーボードから取り外してください。




③ モードスイッチを W に切り替えます。



② 2.4GhzレシーバーをパソコンのUSBポートに取り付けてください




④ Fn+4を3秒間押し、ペアリングを行います。



注意:
1.ペアリング成功後、同じデバイスを2回目ペアリングする必要はありません。
2.4Ghzレシーバーをパソコンに接続し、「Fn+4」で青いインジケターがフラッシュバック接続モードになり、接続成功後、3秒間点灯し続けた後、前の状態に戻ります。
2.Macシステムデバイスは2.4Ghzおよび有線接続モードでは、マルチメディア機能をサポートしません。

バックライトの使用法:

① Fn+←/→:常時点灯/ブリージング/OFF



システムの切替

Fn+Nで、windows/Androidの対応するシステムの機能キーを操作します。

Fn+Mで、Mac/iOSの対応するシステムの機能キーを操作します。

マルチ機能キー

Fn+F1..... Del=マルチ機能キー

機能マーク Mac Windows

FN+F1	*	画面の明るさ-	画面の明るさ-
FN+F2	*	画面の明るさ+	画面の明るさ+
FN+F3	四角	マルチ画面	マルチ画面
FN+F4	四角	検索	検索
FN+F5	四角	明るさ減少	明るさ減少
FN+F6	四角	明るさ増加	明るさ増加
FN+F7	四角	前の曲	前の曲
FN+F8	四角	再生/停止	再生/停止
FN+F9	四角	次の曲	次の曲
FN+F10	四角	ミュート	ミュート
FN+F11	四角	音量-	音量-
FN+F12	四角	音量+	音量+
FN+Opt/Ctrl	四角	/	メニュー
FN+Prtsct	四角	/	電卓
FN+Del	四角	/	ロック

製品に含まれる有害物質の名称と含有量

有害物質	部品名称					
	鉛 (Pb)	水銀 (Hg)	カドミウム (Cd)	六価クロム (Cr+VI)	ポリブロモジブフェニル (PBB)	ポリブロモフエニルエーテル (PBDE)
プラスチック部品	0	0	0	0	0	0
PCB部品	0	0	0	0	0	0
シリコン部品	0	0	0	0	0	0
金属部品	0	0	0	0	0	0

本表は、SJ/T11364の規定に基づいて作成されています。
本製品の分類および表示は、EU指令 2011/65/EU およびその改訂指令 2015/863/EU に従っています。
O:当該部品のすべての均質材料中の有害物質の含有量がGB/T26572で規定された制限要件未満である
X:少なくとも当該部品の均質材料中の当該有害物質の含有量がGB/T26572で規定された制限要件を超えている

環境保護に関する説明:

本製品の電子部品に含まれる有害物質は、通常の使用条件下で10年間漏れたり変化したりすることはありません。同期間中、本製品の電子部品は、消費者が製品を使用する際に、深刻な環境汚染または人の健康や財産への深刻な損害を引き起こすことはありません。中国の電子工業規格SJ/T 11364-2014および関連する中国政府の規制により、本製品およびその内部または外部の構成部品の一部には、環境に配慮した使用期限ラベルが付いている場合があります。部品及び部品メーカーにより、製品および部品の使用期限ラベルが異なる場合があります。なお、部品ラベルに記載されている使用期限が優先されます。

警告:

・バッテリーを適切に設置しないと、液漏れや爆発、人身事故を起こす恐れがあります。
・バッテリーに液漏れ、変色、変形などの異常がある場合は、使用しないでください。
・バッテリーを充電した状態や未使用の状態でも長期間放置しないでください。
・本製品をショートさせないでください。
・バッテリーの寿命は使用状況により変わります。使用済のバッテリーは現地の法律に従って廃棄するか、もしくは電子製品リサイクル用のごみ箱に捨ててください。
・万が一本製品の中に水が入った場合、直ちに電源を切り、本製品の別の場所に移動してください。そのまま使用続けると、火災や感電の原因となります。点検・整備については、販売店またはお近くのカスタマーサービスセンターにお問い合わせください。