

Benches & Gliders Use and Care Manual

Thank you for choosing our high-quality benches and gliders! We are committed to providing you with a sturdy, durable, and aesthetically pleasing addition to your outdoor space. To ensure your benches and gliders remain in excellent condition and provide the comfort and support you need, please read this manual carefully. It contains essential information on setup, usage, maintenance, and safety guidelines.

Table of Contents

- 1.Introduction
- 2.Unpacking and Assembly
 - 2.1 Unpacking Instructions
 - 2.2 Assembly Instructions
 - 2.3 Placement and Setup Tips
- 3.Using Your Benches & Gliders
 - 3.1 Safety Guidelines
 - 3.2 Size and Weight Capacity
 - 3.3 Environmental Considerations
- 4.Maintenance and Care
 - 4.1 Regular Cleaning
 - 4.2 Preventing Damage
 - 4.3 Storage Tips
- 5.Troubleshooting
 - 5.1 Common Issues and Solutions
- 6.Warranty and Support
- 7.Contact Information

1. Introduction

Congratulations on your purchase of high-quality benches and gliders! This manual will guide you through the proper setup, use, and care of your outdoor seating to ensure they remain a sturdy and attractive addition to your garden, patio, or any outdoor space. Whether you have a wooden bench, metal glider, or a combination of materials, following these guidelines will help you maintain their durability and functionality.

2. Unpacking and Assembly

2.1 Unpacking Instructions

1.Carefully Unpack the

Items: Remove the benches and gliders and all components from the packaging. Avoid using sharp objects that could damage the materials.

2.Inspect for

Damage: Check all parts, including the frame, seat, backrest, and any included accessories, for any signs of damage. If you notice any issues, contact customer service immediately.

2.2 Assembly Instructions

1.**Lay Out the Components:** Unfold the bench or glider frame and lay out all parts, including the seat, backrest, arms, legs, and any additional accessories.

2.**Assemble the Frame:** Connect the frame pieces according to the provided instructions. Ensure all connections are secure and tight.



3. Attach the Seat and Backrest: Secure the seat and backrest to the frame and ensure they are properly aligned.

4. Install Additional

Accessories: If your benches or gliders come with additional accessories, such as armrests or cushions, install them according to the instructions.

2.3 Placement and Setup Tips

- **Stable Surface:** Place the benches and gliders on a stable, level surface to prevent them from tipping over.
- **Adequate Space:** Ensure the benches and gliders are positioned with enough space around them for comfortable seating and movement.
- **Sunlight and Wind:** Position them in an area that receives adequate sunlight but is protected from strong winds to prevent tipping or damage.

3. Using Your Benches & Gliders

3.1 Safety Guidelines

- **Secure Installation:** Ensure the benches and gliders are securely installed to prevent them from falling over.
- **Avoid Overloading:** Do not overload the benches and gliders with too many people or heavy materials.
- **Supervise Use:** Regularly check the condition of the benches and gliders to ensure they are not causing instability or discomfort.

3.2 Size and Weight Capacity

- **Size Recommendation:** Choose a bench or glider size that is appropriate for the space and the number of people you intend to seat.
- **Weight Capacity:** Ensure the weight capacity of the bench or glider is suitable for the intended use. Refer to the product specifications for weight limits.

3.3 Environmental Considerations

- **Weather Resistance:** While the benches and gliders are designed to be weather-resistant, extreme weather conditions may require additional protection or temporary removal.
- **Soil Conditions:** Ensure the ground around the benches and gliders is stable and well-drained to prevent water damage and instability.

4. Maintenance and Care

4.1 Regular Cleaning

- **Cleaning:** Clean the benches and gliders regularly with a mild soap and water solution. Avoid harsh chemicals that could damage the materials.
- **Drying:** Ensure all parts are completely dry before reassembling or storing the benches and gliders to prevent mold and bacteria growth.

4.2 Preventing Damage

- **Sharp Objects:** Keep sharp objects away from the benches and gliders to avoid damage to the frame and seating.
- **UV Protection:** The benches and gliders are UV-resistant, but prolonged exposure to direct sunlight may cause fading over time.

4.3 Storage Tips

- **Storage:** If not in use for extended periods, disassemble the benches and gliders and store them in a cool, dry place.
- **Cover:** Use a protective cover to shield the benches and gliders from dust and debris when not in use.

5. Troubleshooting

5.1 Common Issues and Solutions

- **Loose Parts:** Regularly check for any loose screws, bolts, or bars and tighten them as needed.
- **Rust:** If rust appears, clean the affected area with a rust remover and repaint if necessary.
- **Broken Accessories:** Replace any broken or damaged accessories immediately to ensure the stability of the benches and gliders.

6. Warranty and Support

Your benches and gliders are covered by a limited warranty. For more information, refer to the warranty card included with your purchase or contact our customer service.

7. Contact Information

If you have any questions or need further assistance, feel free to contact us:

Email Address: katie_jenkins_m@outlook.com

Thank you for choosing our benches and gliders! We hope they provide a comfortable and attractive seating solution for your outdoor space. Happy gardening!