



MOD007BHE

三模键盘用户手册

User Manual

快速开始指南


Quick Start Guide

感谢您购买及使用本产品



为了给您带来更好的使用体验，在使用产品前请仔细阅读本说明书，并请妥善保管，以便日后参观。

产品概览



包装内容



系统需求

Windows®XP / Vista / 7 / 8 / 10或更高版本

安装步骤

将键盘USB连接线插入电脑的USB接口即可开始使用。

指示灯说明

	指示灯位置	回连	配对	连接成功
Bt1:	按键E灯	红色慢闪	红色快闪	红灯常亮2s熄灭
Bt2:	按键R灯	蓝色慢闪	蓝色快闪	蓝灯常亮2s熄灭
Bt3:	按键T灯	黄色慢闪	黄色快闪	黄灯常亮2s熄灭
2.4G:	按键Y灯	绿色慢闪	绿色快闪	绿灯常亮2s熄灭
有线:	按键U灯	无	无	白灯常亮2s熄灭

	指示灯位置	指示方式
低电:	空格键	红灯慢闪
充电:	空格键	红灯常亮
充满:	空格键	灯灭
Caps:	Caps键	白光常亮
锁WIN:	L_Win键	白光常亮

调整按键行程快捷键

Fn+1

轴行程为2mm

Fn+2

轴行程为0.5mm


Fn+3

轴行程为0.5mm+火力模式

Fn+4

驱动自定义轴行程通道，默认2mm轴行程

MOD007B-HE 组合键功能





Fn+	F1	我的电脑
	F2	电子邮件
	F3	= Windows搜索
	F4	浏览器主页
	F5	多媒体播放器

Fn+	F6	播放 / 暂停
	F7	上一首
	F8	= 下一首
	C	计算器
	M	静音

Fn+	<	音量减小
	>	音量放大
	P	= Print SCR
	I	Insert
	w	将 WASD 与 ↑ ↓ ← → 键对调

MOD007B-HE 系统功能 (Windows)



锁Win键

Fn + 左Win


恢复出厂设置

长按 Fn+~ 5秒

切换成菜单键 (可记忆)

长按 Fn + 右Ctrl 3秒

MOD007B-HE 系统功能 (Mac)



F1 降低显示屏亮度

F2 增加显示屏亮度

F3 开放任务控制

F4 呼出Siri

F7 上一曲

F8 暂停/播放(音频)

F9 下一曲

F10 静音

F11 调低音量

F12 调高音量


左Win Option

左Alt Command

右Alt Command

Fn + (F1-12) F1 ~ F12

MOD007B-HE 灯光调节



Fn+← 灯光速度变慢

Fn+= 灯光速度变快

Fn+↑ 灯光变亮

Fn+↓ 灯光变暗

Fn+← 灯光方向向左

Fn+→ 灯光方向向右

Fn+L 灯光关闭/开启

Fn+Home 常亮、涟漪、如影随形、川流不息、流星

Fn+PgUp 繁星点点、霓虹、光波、层出不穷、彩泉涌动

Fn+End 呼吸、极光、正弦波、雨滴、峰回路转

Fn+PgDn 斜风细雨、踏雪无痕、聚合、一石二鸟、百花争艳

Fn+\ 在RGB彩光模式下，调节灯光颜色致7色单色+RGB循环

MOD007B-HE 无线连接使用指南



Fn+	E	=	蓝牙设备1
	R		蓝牙设备2
	T		蓝牙设备3
	Y		2.4G无线设备
	U		有线模式

 开关位于 CAPS按键右侧	上：MAC (内置电源开)
	中：Windows (内置电源关)
	下：Windows (内置电源开)

蓝牙配对

键盘开机后,按下FN+E/R/T进入蓝牙模式,长按FN+E/R/T组合键3S,键盘进入对码状态,红\蓝\黄色指示灯快闪,连上后指示灯常亮2S,如果没有连上设备指示灯熄灭,键盘进入睡眠。

2.4G配对

键盘开机后,按下FN+Y进入2.4G模式,再按下FN+Y组合键3S进入配对模式后,插入接收器,绿色指示灯快闪配对成功后退出对码,模式灯常亮2S,找不到配对设备30s后,退出对码模式灯熄灭,键盘进入睡眠。

电量查询

在无线模式下,按Fn+空格组合键可检查电池电量。如果电池电量低于30%,数字1-2键将显示红灯。

如果电池电量低于100%,数字1-9键将显示绿灯,电池电量充满则数字1-0键显示绿灯。

1	2	3	4	5	6	7	8	9	0
<30%	<40%	<50%	<60%	<70%	<80%	<90%	<100%	充满	
亮红灯				亮绿灯					

Akko保修和服务声明

1. Akko为中国大陆的客户提供一个保修。对于其他地区，请联系您的卖家（Akko分销商）以了解具体的保修政策。
2. 如果保修期到期，客户需要支付维修费用。如果用户喜欢自己修理键盘，Akko也会提供说明。用户应对自行修复过程中发生的任何损失承担全部责任。
3. 在未经制造商/卖方指示的情况下拆开键盘将立即导致保修无效
4. 官方售后服务时间为每周一至周五上午10:00至下午18:00
节假日以国家法定节日休息为准。
5. 退货和保修政策在不同的平台上可能有所不同，并在购买时取决于具体的经销商。

公司：深圳银宸科技有限公司

地址：深圳市宝安区松岗街道碧头第一工业区朗碧路33号

电话：0755-23216420

网址：www.akkogear.com

产地：中国·深圳

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou First Industrial Zone, Bao'an District, Shenzhen, China



WARNING:
Water and Beverages can't be
poured into the Keyboard.



[instagram.com/akkogear](https://www.instagram.com/akkogear)



[facebook.com/akkogear](https://www.facebook.com/akkogear)

中国制造/Made in China



[tiktok.com/@akkogear](https://www.tiktok.com/@akkogear)

注意 事项


人为损坏不局限于键盘进水、高处坠落、过度用力拉扯线材等，键盘为电子产品
请按照电子产品保护方式爱惜使用。

Thank you for supporting Akko



To provide you with a better user experience, please read this manual carefully before using the product.

Overview



Packing List



Minimum System Requirement

Windows®XP / Vista / 7 / 8 / 10 or higher version

Connectivity Method

Connect the keyboard to your computer by plugging in the USB cable into an available USB port to start using it.

LED Indicator Overview


Status	Indicator	Re-Connecting	Pairing	Connection
Bluetooth device 1	LED for Key E	Red light blinks slowly	Red light blinks fast	Red light stays on for 2 seconds and then turns off
Bluetooth device 2	LED for Key R	Blue light blinks slowly	Blue light blinks fast	Blue light stays on for 2 seconds and then turns off
Bluetooth device 3	LED for Key T	Yellow light blinks slowly	Yellow light blinks fast	Yellow light stays on for 2 seconds and then turns off
2.4G wireless device	LED for Key Y	Green light blinks slowly	Green light blinks fast	Green light stays on for 2 seconds and then turns off
Wired mode	LED for Key U	N/A	N/A	White light stays on for 2 seconds and then turns off

Status	Indicator	Indicating mode
Low Battery	Independent LED Indicator (near spacebar)	Red light blinks slowly
Charging		Steady red
Fully Charged		Light off
Caps	LED for Caps Key	Steady white
Lock WIN	LED for left WIN Key	Steady white

Shortcuts to Adjust Travel Distance

Fn+1	Switch Travel Distance = 2mm	Fn+2	Switch Travel Distance = 0.5mm
Fn+3	Switch Travel Distance = 0.5mm + Ultra Sensitive Mode		
Fn+4	Customize switch actuation distance through Akko Cloud Driver (2mm by default)		

MOD007B-HE HotKeys




Fn+	F1	=	My Computer
	F2		E-mail
	F3		Windows Search
	F4		Browser Homepage
	F5		Media

Fn+	F6	=	Pause/Playback
	F7		Previous Song
	F8		Next Song
	C		Calculator
	M		Sound off

Fn+	<	=	Decrease Volume
	>		Increase Volume
	P		Print SCR
	I		Insert
	W		Swap W A S D with ↑ ↓ ← →


MOD007B-HE System Commands (Windows)



<p>Rotary Knob</p>	<p>Default is volume function; Rotate counterclockwise to decrease the volume; Rotate clockwise to increase the volume.</p>
	<p>Press the middle to switch to brightness function; Rotate counterclockwise to decrease brightness; Rotate clockwise to increase brightness.</p>

<p>Lock Windows Key</p> <p>Press Fn and Left Win Key</p>	<p>Revert Ctrl into Menu Key (Memorable)</p> <p>Hold down Fn and press Right Ctrl Key for 3S</p>	<p>Restore Factory Settings</p> <p>Hold down Fn and press ~ Key for 5S</p>
---	---	---

MOD007B-HE System Function (Mac)



F1 Decrease display brightness

F2 Increase display brightness

F3 Open mission control

F4 Activate Siri

F7 Skip back (Audio)

F8 Pause/Play (Audio)

F9 Skip forward (Audio)

F10 Mute

F11 Decrease Volume

F12 Increase Volume


Left Win Option

Left Alt Command

Right Alt Command

Fn + (F1-12) F1 ~ F12

MOD007B-HE Backlight Settings



Fn+- Slower Animation

Fn+= Faster Animation

Fn+L Light On / Off

Fn+↑ Bright

Fn+↓ Dim

Fn+← Set Animation Direction to Left

Fn+→ Set Animation Direction to Right

Fn+Home

Fn+PgUp

Fn+End

Fn+PgDn

Fn+

Effect1, Effect2, Effect3, Effect4, Effect5


Effect6, Effect7, Effect8, Effect9, Effect10

Effect11, Effect12, Effect13, Effect14, Effect15


Effect16, Effect17, Effect18, Effect19, Effect20

In all lighting effects with RGB colormode, set the backlight color to 7 single color with RGB loop effect.

MOD007B-HE Wireless Connection Guide



Fn+	E	=	Bluetooth Device 1
	R	=	Bluetooth Device 2
	T	=	Bluetooth Device 3
	Y	=	2.4G Wireless Device
	U	=	Wired mode

 The switch is located to the right of the CAPS button	Top: MAC (built-in power on)
	Middle: Default Windows (built-in power supply off)
	Bottom: Windows (built-in power supply on)

Bluetooth pairing

After turning on the keyboard, press FN+E/R/T to enter Bluetooth mode. Press and hold the FN+E/R/T combination key for 3 seconds to put the keyboard in pairing mode, with the blue indicator light flashing quickly. Once the connection is established, the indicator light will stay on for 2 seconds. If the device fails to connect, the indicator light will turn off and the keyboard will enter sleep mode.

2.4G pairing

After turning on the keyboard, press FN+Y to enter 2.4G mode. Then press and hold the FN+Y combination key for 3 seconds to enter pairing mode. Then insert the receiver, and the indicator light will flash quickly. Once pairing is successful, the LED indicator will stay on for 2 seconds. If no available device is found within 30 seconds, the LED indicator will turn off and the keyboard will enter sleep mode.

Battery Level Check

Press the Fn + Space combination keys to check the battery level. If the battery level is below 30%, the Number 1 & Number 2 keys will show a red light. If the battery level is below 100%, the Number 1-9 keys will display green light correspondingly. If the battery is fully charged, the Number 0 key will show a green light.



Customization Instruction

- 1.The key/lighting effects customization can be programmed with Akko Setup.
- 2.The lighting effects can also achieve music rhythm effects with Akko Setup.
- 3.Please download the Akko Setup on our website
- 4.Users can download the driver via en.akkogear.com

Akko Warranty and Service Statement

- 1.Akko provides One-Year warranty for customers in mainland China. For other regions, please contact your seller (Akko distributor) for specific warranty policy.
- 2.If the warranty window expires, customers need to pay for repairs. Akko will also provide instructions if users prefer to repair the keyboard by themselves.
However, users shall take full responsibility for any loss happened during self-repair.
- 3.Disassembling the keyboard without manufacturer/seller's instruction will immediately void the warranty.
- 4.The return and warranty policy may vary in different platforms and are subject to the specific distributor at the time of purchase.

Company: Shenzhen Yinchen Technology Co., Ltd

Address: 33 Langbi Rd, Bitou Community 1st Industrial Zone, Bao'an District, Shenzhen, China

Tel: 0755-23216420

Website: www.akkogear.com

Origin: Shenzhen, China



WARNING:
Water and Beverages can't be poured into the Keyboard.



[instagram.com/akkogear](https://www.instagram.com/akkogear)



[facebook.com/akkogear](https://www.facebook.com/akkogear)

中国制造/Made in China



[tiktok.com/@akkogear](https://www.tiktok.com/@akkogear)



www.akkogear.com



@akkogear



扫描关注官方微信



扫描关注官方微博