



QUICK START GUIDE

STEAM COMPLETE PET STEAM CLEANER



1

Plug in your Steam Complete Pet and turn it on. Allow 60 seconds for your unit to heat up, and adjust both dials to your desired setting.



2

Adjust steam dial to desired setting. Utilize the Supplemental water tank by turning dial to large area when cleaning large spaces and turn the dial to small area for quick cleaning.



3

Pull trigger in short bursts to produce steam and clean. To prevent over saturating floors, avoid holding down the trigger continuously.

PRO TIPS

TO ENGAGE STEAMSTREAM

Press the button on floor head to activate, and squeeze trigger to release the steam. Press button again to deactivate.

TO RELEASE THE TILE AND GROUT SCRUB BRUSH

Place foot on outer floor head and gently pull away steam cleaner.

FOR BEST PERFORMANCE

Use distilled water.




TOOLS FOR EVERY MESS



To remove the handheld


Lift the release button and gently pull away from the steam cleaner.

TIP: Remove main water tank and fill before use.



Using small accessories

Small tools can be attached with the concentration nozzle. Twist clockwise until locked into position.



Using large accessories

Larger tools can be attached with the concentration nozzle or hose. To attach the hose, twist clockwise until locked into position.



For more information about the tools included with your Steam Complete Pet, scan the QR code or see the included user guide.