



Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 TV / AV	 AV
 1	 1	 Sleep	 Sleep
 2	 2	 Up / PR+	 Up
 3	 3	 Up / PR+	 Ch +
 4	 4	 Down / PR-	 Down
 5	 5	 Down / PR-	 Ch -
 6	 6	 Right / Vol+	 Right
 7	 7	 Right / Vol+	 Vol +
 8	 8	 Left / Vol-	 Left
 9	 9	 Left / Vol-	 Vol -
 0	 0	 OK	 Ok
 *	 Guide	 Text / Mix	 Text
 *	 Pre Ch	 Q.View	 Options
 PSM	 Format	 List	 List
 SSM	 +  Shift + Dual	 Red	 Red
 I/II	 Dual	 Green	 Green



