




Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	*		Guide
	*		Pre Ch
	PSM		Format
	SSM		Shift + Dual
	I/II		Dual
	Menu		Menu
	TV / AV		AV
	Sleep		Sleep
	Up / PR+		Up
	Up / PR+		Ch +
	Down / PR-		Down
	Down / PR-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	Text / Mix		Text
	Q.View		Options
	List		List
	Red		Red
	Green		Green



