

# User Manual

## A56 Automatic Pet Feeder



Dear customer,

We appreciate your choice of the automatic pet feeder. We insist on providing premium pet products, helping pet owners feed pets in a scientific and reasonable way and providing pets a healthy lifestyle. We are working for establishing a harmonious relationship between you and your pets.

For the convenience of using, please read the user manual carefully and follow the instructions.

## **WARRANTY**

1 Year Warranty


Lifetime Support: For guidance on product use and warranty extension, please contact after-sales email:  
**honeyguardan@hotmail.com**

If you have any questions related to orders, please contact the seller via the shopping platform.

# Contents

English	01-08
German	09-16
French	17-24
Spanish	25-32
Italian	33-40
Japanese	41-48
Chinese	49-54

## Structural image



## Packing List:

### Single Bowl Version:

1 x Pet Feeder, 1 x Stainless Steel Bowl, 1 x Bowl Holder, 1 x Power Adapter, 1 x Desiccant Bag, 1 x User Manual

### Dual Bowls Version:

1 x Pet Feeder, 2 x Stainless Steel Bowls, 2 x Bowl Holders, 1 x Power Adapter, 1 x Desiccant Bag, 1 x 2-way Splitter, 1 x User Manual

## Notice:

- To prevent the mold growth, it is recommended to change the desiccant bag every 15 days
- The feeder is for indoor household use only.
- The host of the equipment is not washable.  
The hopper and the food tray and stainless steel bowl can be removed and washable.
- Please keep pets from biting the power cable or it may cause leakage.
- Please place the feeder horizontally and close the lid to keep the food from spilling out.

## Setting Instructions

### Control panel:



Long pressing the button for 3 seconds to shut down/Boot up;

Meals Switch Button (1-6 meals)



Meals Portion Volume Button: Program the meals portion size ( 0- 24 portions)



Manual Feeding Button: Dispense one portion by pressing this button 1 time.

-  — Hours Setting Button: Set the hours time.
-  — Minutes Setting Button: Set the minutes time.
-  — Time Setting Button: Press this button to enter the time setting and save time when you finished the time setting.
-  — Recording Button: Record the voice, play the voice or delete the voice recording function.

## Time Setting


- Press “” and hold for three seconds to unlock the screen and enter the time setting mode, The hour and minute “88:88” blinks. Press “”、 “” to set hours and minutes time as your demand. Press “” and hold the button for 3 seconds to exit the time setting.
- You can switch the 12-hour clock and 24-hour clock by pressing the “” and “” at the same time



## Feeding Setting


- Recommended food size: 0.2-1.2cm(0.07-0.47inch) diameter. Please use food smaller than 1.2cm, otherwise the feeder may get stuck.
- You can set 0-6 meals per day and MAX 24 portions volume for each meal.  
One portion size is about 5-6g (16 ml) food kibble. The dual bowls version dispense one portion in each bowl is about 2.5g.

- Meal 1:  
Pressing "  " one time to enter the feeding plan mode, at this time the meal 1, feeding time and feeding portions volume will blink, press : "  " and "  " to set the feeding time, then press "  " to set the meal portions.




- Meal 2:

After you finished the meal 1 setting, you can also press the "MEAL" one time to choose meal 2. The meal feeding time and feeding portions volume will blink, press ":" (12H) and "60M" to set the feeding time, then press "Bowl" to set the meal portions.



- You can use same method to program 3, 4, 5, 6 feeding plans. If you do not need to program the others feeding plan or delete the previous feeding plan, you can set the feeding portions volume.



## Recording Setting

- Press “  ” and hold for three seconds then you can record for Max 10 seconds after the recording indicator lighting up. If you release your hand when recording, the system will recognize you finished the recording. After finishing the recording, you can press “  ” one time to play your recording. You can press “  ” two times until the recording indicator light blinking 3 times, then the recording message is removed.

## Manual Feeding


- Press “  ” and hold for three seconds, the food will dispense one portion each time.

## Low Battery Reminder

- When the batteries are low, the “  ” on the LCD screen will turn on. After new batteries are installed, the “  ” on the LCD screen will be off.(Battery model: 3×D size alkaline battery)

## Reset Function


- If you need to reset the automatic pet feeder, press the reset button for 3s.



## Dual bowls installation

(If you purchased the dual bowls version)

- Step1: Connect the two-way dispenser to the host.



- Step2:Connect the feeder base dispenser to the host.

