


Manual

English/Español/Français/Deutsch/Italiano



GM700

※ Quick Installation Guide ※

NETFLIX

 YouTube

 Disney+

prime video


Attention

Please read this manual carefully before use and keep it for future reference.

- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Catalogue

English

Structure description.....	1
Remote Control and Functions.....	3
How to connect projector with HDMI.....	4
TV CAST - Quick Cast Screen (Andriod, IOS).....	5
How to use Miracast with projector.....	6
How to use Airplay with projector.....	7
Bluetooth/WiFi/Language.....	8
Feature introduction.....	10

Catalogue

Français

Description structurelle.....	25
Télécommande et fonctions	27
Comment connecter un projecteur avec HDMI.....	28
TV CAST - Écran Rapide Cast (Andriod, IOS).....	29
Comment utiliser Miracast avec un projecteur.....	30
Comment utiliser AirPlay avec Projecteur.....	31
Bluetooth/WiFi/Langue.....	32
Présentation des fonctionnalités.....	34

Catalogar

Español

Descripción estructural.....	13
Mando a distancia y funciones.....	15
Cómo conectar un proyector con HDMI.....	16
TV CAST - Screen Cast Rápido (Andriod, IOS).....	17
Cómo usar Miracast con un proyector.....	18
Cómo usar AirPlay con el proyector.....	19
Bluetooth/WiFi/Idioma.....	20
Introducción de característica.....	22

Katalog

Deutsch

Strukturbeschreibung.....	37
Fernbedienung und Funktionen.....	39
So schließen Sie einen Projektor über HDMI an.....	40
TV CAST - Quick Cast Screen (Andriod, IOS).....	41
So verwenden Sie Miracast mit einem Projektor.....	42
So verwenden Sie Airplay mit Projector.....	43
Bluetooth/WiFi/Sprache.....	44
Einführung in die Funktionen.....	46

Catalogare

Italiano


Descrizione strutturale.....	49
Telecomando e funzioni.....	51
Come collegare il proiettore con HDMI.....	52
TV CAST - Schermata rapida del Cast (Andriod, IOS).....	53
Come usare Miracast con il proiettore.....	54
Come utilizzare AirPlay con il proiettore.....	55
Bluetooth/WiFi/Lingua.....	56
Introduzione alle funzioni.....	57

English Manual (pages 1 - 12)



Structure description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.

After connecting the power, tap the power button for 2 seconds to turn on the device




The projector has auto focus and motorized focus. After turning on the projector, please wait for 10-20 seconds, the projector will automatically adjust the focus and sharpness. Whenever you move the projector, the projector will also adjust the focus automatically




Remote Control and Functions

Note: Please install 2 AAA batteries in the remote control



How to connect projector with HDMI

- Step 1. Please use an HDMI cable to plug into the HDMI port of the projector
- Step 2. Then please plug another end of the HDMI cable into the HDMI port of the laptop or computer
- Step 3. Please find the HDMI option on the projector and enter.
Operation on projector: Home Screen→HDMI



The HDMI function is on the homepage

The HDMI option is in the Home Screen of the projector

TV CAST - Quick Cast Screen (Android, IOS)

TV CAST is compatible with most **iPhones, iPads, Android phones, Android tablets**


Please make sure the projector and Android or IOS device are connected to the same WiFi

Step 1. Connect the projector and the iOS or Android device to the same WiFi

Step 2. Click the 'TV CAST' function on the remote control. The projector will jump to the TV CAST page

Step 3. Scan the QR code on the projector screen and download the app 'TV Casting'

Step 4. Open the App 'TV Casting' and match the device



step 2



step 3

How to use Miracast with projector


(Android devices)

Please make sure the projector and Android device are connected to the same WiFi

Step 1. Please connected the projector and the Android device to the same WiFi


Step 2. Operations on Projector:

Setting→Device Preference→Whale OS Cast→Miracast
→Click here to open Miracast: Turn on the phone mirroring
→Connection



Step 3. Operations on your Android device (phone or tablet)

Turn on the 'Screen Cast'→Wait for searching→Connect the projector



How to use Airplay with projector


(Apple IOS devices)

Please ensure that Apple devices (iPhone,iPad) and projector are connected the **same WiFi**


Step 1. Please connect the projector and Apple devices to the **same WiFi**

Step 2. Operations on your iPhone/iPad

Turn on 'Screen Mirroring'→Wait for searching→Connect the projector



Bluetooth remote controller pairing




Note: the matching interface of Bluetooth remote control, Press "Voice input" button to bring up the matching guide.


Select or add a Wi-Fi network



Privacy Policy



Select your Language




Feature introduction

Left side

1. Weather.
2. Setting.
3. Signal.
4. Recently viewed.
5. Search.

The right side is the application area, where all applications installed by the user will be displayed here, with no limit on the number. The first eight application positions are preset applications. Cannot be moved and cannot be removed. Applications installed by users start from the ninth position.



Weather:

By default, the climate and temperature of the current city on the 7th this week are displayed. Change City can switch city display.



Signal:

After connecting projector to other output device, enter HD.



Recently viewed:

Record what users watch and use the App.



Search:

global search function.



Application download.
Application installation.



The file manager has the ability to select, compile, sort, and display lists and thumbnails.

WIFI & Bluetooth

- ⚙ Setting-Wireless and Network: WIFI & wired network connection and Bluetooth related functions.

Wireless and Network	Wired or Wi-Fi
	Connect to Network
	Wi-Fi On/Off
	Bluetooth
	Search for Bluetooth device
	Bluetooth On/Off

Sound Settings

- ⚙ Setting-Sound: Sound Settings.

Sound	Balance
	Sound Mode
	Audio Output Devices
	Select formats

Lens Settings

- ⚙ Setting-Lens: Projection Direction, Keystone Correction, Digital Zoom.

Lens	Projection direction
	Keystone correction
	Digital zoom

Manual en español (páginas 13-24)

Descripción estructural

Este manual es sólo para referencia. Sujeto a cambios sin previo aviso. Hotack se reserva el derecho de interpretación final.

Después de conectar la alimentación, toque el botón de encendido durante 2 segundos para encender el dispositivo

