

Bang & Olufsen Cisco 950

Model: HS-WL-950

Quick Start Guide

Lynguide

Kurzanleitung

Guía de inicio rápido

Guide de démarrage rapide

Guida di avvio rapido

クイックスタートガイド

퀵 스타트 가이드

Snelstartgids

Guia de início rápido

Краткое руководство пользователя


Snabbstartguide

快速入门指南

快速入門指南



I. DOWNLOAD THE BANG & OLUFSEN APP




Bang & Olufsen




II. SET UP IN THE BANG & OLUFSEN APP

Product tutorial, settings, features and software updates



III. OPEN CASE FOR AUTOMATIC BLUETOOTH PAIRING




When opening the Charging Case lid for the first time,
it will go into automatic pairing mode.

BLUETOOTH PAIRING WITH ANOTHER DEVICE

1.




2.



Wait until LED turns off


3.



Tap and hold (5 secs)

Follow these steps to connect to another device after first time pairing.
After 5 seconds, the LED will flash blue, indicating that
your earphones are in Bluetooth pairing mode.





INSERT EARBUDS




Inside the box, you will find different sizes of eartips. Pick the ones that fit you best for maximum comfort. Remember, the earbuds will automatically connect to your latest device via Bluetooth when removed from the charging case.

CALL OPERATIONS



 Answer call		● Single tap
 End call		● ■ Double tap and hold
 Reject call		● ■ Double tap and hold
+ Volume up		■ Tap and hold
— Volume down	■ Tap and hold	
Own Voice, Active Noise Cancellation, Neutral (cycle)	● Single tap	
 Mute/Unmute		● Single tap


MEDIA OPERATIONS











▶ Play/Pause		● Single tap
+ Volume up		■ Tap and hold
- Volume down	■ Tap and hold	
> Next track (Customize*)		● ● Double tap
Transparency, Active Noise Cancellation, Neutral (cycle)	● Single tap	

*Customize Media Operations in the Bang & Olufsen app, to match your preferences. (e.g. previous track, voice assistant, battery status...)



SINGLE EARBUD OPERATIONS





 Play/Pause	●	Single tap
 Answer call	●	Single tap
 End call	● 	Double tap and hold
 Next track (Customize*)	● ●	Double tap
 Reject call	● 	Double tap and hold
 Mute/Unmute	●	Single tap

*Customize Single Earbud Operations in the Bang & Olufsen app, to match your preferences. (e.g. previous track, voice assistant, battery status...)

CHARGING



BOX OVERVIEW




Silicone



Comply™



CISCO USB HD ADAPTER



Compatible with the
Bang & Olufsen Cisco 950*

How to pair with the dongle

*Available to purchase as a spare accessory.

Note, the Cisco USB HD Adapter is not included in the box.

NEED HELP?
VISIT WEBEX HELP CENTER

www.cisco.com/go/headsetsupport

