## NoiseFit Curve UM - 84 x 84 mm

User Manual for NoiseFit Curve 01 User Manual for NoiseFit Curve 05 User Manual for NoiseFit Curve 07 User Manual for NoiseFit Curve 08 User Manual for NoiseFit Curve 09 User M
--

WATCH NAVIGATION

watch or set your own time and it will remind you when the time is up.
WORLD CLOCK
Save up to 5 world clocks of your choice on the NoiseFit app.
WORKOUTS
Select Workouts & proceed to track your performance to the routine of your choice.
SPORTS RECORDS
Tap on Sports records to check on your recent performance.
REMINDERS
Select reminders to set your preferred reminder. You can add or edit reminders on the NoiseFit app.
MUSIC
You can control your favourite songs and podcasts that play f your phone, right on your wrist as long as the watch is conne with the NoiseFit app in your phone. You can play/pause mus to the next/previous track and increase/decrease volume.

User Manual for NoiseFit Curve

You can set a countdown with a pre-set duration on the

## NoiseFit Curve supports 5-day weather viewing in a location of your choice as long it is synced with the NoiseFit app. You can view today's current weather and for the next 4 days as well. So to the NoiseFit app, select 'Devices' click on 'weather settings' to people the feature. settings' to enable the feature.

CALCULATOR Manage daily calculations by tapping on Calculator.

WATCH FACES Long press the home screen to access your saved watch faces

Swipe left/right to navigate. You can customise your watch face on the NoiseFit app.

FLASHLIGHT

09 User Manual for NoiseFit Curve

TABLE OF CONTENT

You can use this feature to turn on the screen brightness and s

your surroundings better. Go to the Flashlight. Tap to turn on.

MENU VIEW

RINGTONE VIBRATION You can set the ring and vibration as per your preferer You can also choose to put the device on silent mode. WRIST AWAKE Tap on Wrist Awake. Activate the wrist awake feature for a set amount of time or leave it on all-day.

BRIGHT SCREEN TIME Select the duration for which you want the screen to stay on. You can even choose to keep the screen always bright.

You can set the brightness as per your preference.

WATCH OVERVIEW

BRIGHTNESS

10 User Manual for NoiseFit Curve

Tap on DND and select the amount of time you want notifications to be turned off.

Tap on menu view and make your selection from a grid or list view.

PACKAGE CONTAINS

Tap on Auto sports detection to turn it on or off. ABOUT CALLS To use this feature connect your phone's Bluetooth

DEVICE INFO

11 User Manual for NoiseFit Curve

CHARGING NOISEFIT CURVE SMARTWATCH

Tap on Device Info to view the device information.

QR CODE Tap on QR Code to scan your device.

REBOOT You can choose this option to reboot the watch. POWER OFF You can select this option to power-off the watch. You can select Reset to choose to reset.

Note: If you choose to reset, all your data and settings will be erased. 12 User Manual for NoiseFit Curve

QUICK SETTINGS You can swipe up from the watch's home

SILENT MODE BRIGHTNESS FIND PHONE DND SETTINGS

POWER ON

POWER SAVING MODE

DEVICE INFORMATION AND TIPS DEVICE INFORMATION The NoiseFit Curve smartwatch contains the following: 1.38" TFT display (240\*240 px)

How do I update my NoiseFit Curve?

How do I find my watch's current firmware version?

Go to "My Device" on the NoiseFit app. Select "Upgrade", choose Check for

and select Check for updates.

13 User Manual for NoiseFit Curve

• Bluetooth calling (built-in microphone & speakers, recent calls, dial pad, contacts) 100+ customisable watch faces • Health tracking with NoiseFit app (Activity tracking, SpO2, sleep tracker,

24\*7 Heart Rate Monitor, Stress measurement) • 300mAh battery (up to 7 days of use, 2 days with calling & 25 days on standby) Utility/productivity features (Stopwatch, alarm, timer, reminder, DND, weather,

camera/music controls, world clock, calculator) • 3 colour options - Jet black, Silver grey & Vintage brown • IP68 resistance

DISPOSAL AND RECYCLING INFORMATION You can update your NoiseFit Curve via the NoiseFit app. Go to My Device

14 User Manual for NoiseFit Curve

How do I save battery?

Minimise the screen brightness

Follow these simple steps to save NoiseFit Curve battery.

SETUP

Consumers are obliged by law to return the electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment.

BT CALL CONNECTIVITY

NOISE HEALTH

The NioseFit Curve watch is not a toy. The watch contains small components

devices or scientific measurement devices.

MAINTENANCE INSTRUCTIONS

the wrist strap and your wrist.

16 User Manual for NoiseFit Curve

The Noserit Curve watch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical

In some cases, prolonged use of products may cause skin irritation, Prolonged

of wear. If you feel soreness, tingling, numbness, burning or stiffness in you

on the cases, protoliged use of products may cause skin irration. Protoliged contact may contribute to skin irritation or allergies. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period

hands or wrists while or after wearing the watch, please immediately discontinue

• Keep the device dry and clean regularly and especially after prolonged use as

moisture and dirt can build up underneath the band and can cause skin irritation

Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and there is a gap of about one finger's width between

• Do not use household cleaners to clean the device. Use soap-free cleaners instead.

• For stains that are difficult to remove, it is recommended to scrub with alcohol.

• The device is not suitable for diving, swimming in the sea or sauna; it is suitable

• Keep it away direct sunlight, high temperatures or humid conditions as it may

for swimming pool, shower (cold water) and swimming in shallows.

USA: Federal Communications Commission (FCC) Statement his device complies with Part 15 of the FCC rules. Operation is subject to the This device may cause harmful interference, and this device must accept any

• Limit the notification you receive from the NoiseFit app. interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible How does the watch estimate how many calories have been burned? for compliance could void the Max's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the Max is encouraged to try to correct the interference by one or more of the or compliance could void the Max's authority to operate the equipment

15 User Manual for NoiseFit Curve

NoiseFit Curve estimates how many calories you've burned based on the physical data you entered when you set up your account. How do I change my activity goals?

You can do it through the NoiseFit app. Go to "My Profile" and select "Goal".

How do I log my weight? You can log in your weight the first time you setup your NoiseFit app. However, you can update the weight later via NoiseFit app. Go to My Profile and change or update your weight. You can update birthday, height, weight, and step length. Max is encouraged to try to correct the interference by one or more of the

• Reorient or relocate the receiving antenna. Electrical and electronic devices may not be disposed of with domestic waste. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help.

CUSTOMER SUPPORT

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at link: https://support.gonoise.com/support/home

The excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion. · Charge the battery in a cool, ventilated room.

• Do not expose NiseFit Curve to extremely high or low temperatures.

• Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water (DO NOT RUB THE EYE) or seek medical help. • Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting

can occur when a metallic object, such as coins, causes the direct connection of positive and negative terminals of the battery.

• Keep the batteries out of children's reach and in a safe place to prevent danger. Do not place the batteries in the water.

• Do not use your product in a sauna or steam room.

• Do not disassemble the battery on your own.

SAFETY INSTRUCTIONS

SLEEP

• Do not dispose of batteries in the fire as that may cause an explosion. Dispose of used batteries in accordance with your local regulations. Do not dispose it as household waste.

 $\bullet$  Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours. Do not attempt to repair or maintain the watch yourself, service and maintenant

should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel. • To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.

User Manual for NoiseFit Curve

18 User Manual for NoiseFit Curve