


### Warning

1. It is a high-precision product, do not fall or crash.
2. Do not expose the unit to strong magnetic objects, such as magnet and electrical motor. Avoid strong radio waves. Strong magnetic fields may cause the products breakdown or images and sounds damage.
3. Never leave the products exposed to high temperatures and direct sunlight.
4. Please choose branded Micro SD card. Neutral cards are not guaranteed to work normally.
5. Do not place Micro SD card near strong magnetic objects to avoid data loss.
6. In case of overheating, smoke, or unpleasant smell in the process of charging, unplug the device immediately to prevent fire hazard.
7. **Water** When you play the product in water, please pay attention to the safety, cause children accidental suffocation or electric shock.
8. Please use the device in cool, dry and dust-proof places.

### Preface

This product is a high-definition digital motion video recording device tailored to market demand. It has a variety of industry-leading features including digital video recording, photos shooting, audio recording, video display and rechargeable battery, which makes it perfect for vehicle date recording, photo-shooting, outdoor sports, deep-water probing, etc., allowing you to film at anytime, anywhere.


### 1



### Product Features

- A water-resistant casing that allows you film fascinating water sports.
- Water-resistant up to 30 meters under water.
- High definition screen that displays and replays fascinating videos record.
- Detachable battery that is easy to replace and prolongs your camera's service life.
- Video recording while charging.
- Video recording by battery.
- 16-megapixel HD wide-angle lens.
- Support storage cards up to 64GB maximum.
- Multiple video recording formats: 1080FHD/1080P/720P/WVG/VGA
- AVI video format.
- JPG photo format.
- Multiple shooting modes: Cyclo Record, Video Lapse, Timer, Continuous shooting.
- Mini appearance.
- Open WiFi button within the menu, it will be more convenient to operate the machine by using a mobile phone.

### 2



### Picture of Product



### 3

### Accessories



### 4

### Accessories instructions



### 5

### 6. Inserting Micro SD cards

Note: Please choose branded Micro SD card and format it on computer before use. Neutral cards are not guaranteed to work normally.

### 2. Installing and removing batteries

a. Press on battery cap to open it.

b. Correctly install battery into camera as indicated by +/- symbols and direction of arrows marked on battery until it's in place.

c. Battery gauge: please refer to diagram.

d. Remove cap to take battery out.

### 3. Charging

a. Charging can be done by either connecting power adapter to computer or power adapter.

b. Charge on phone by connecting it to a car charger.

c. It can record video while charging.

Note: When it is connected with power and automatically video recording, charging can be done even when long press power which.

### 4. Switching camera on and off

a. Press and hold power button for 3 to 5 seconds to turn it on/off.

Long press UP button to turn on Wi-Fi.

### 5. Mode Switching

a. Switch between video recording / photo shooting / playback / menu by pressing Power On/Off button.

### 6. Switch between large and small screens

Long press the key to switch the screen size (just screens cannot be displayed at the same time).

### 7

### 7. Indicator light

Power indicator light, red light is always on when charging; when fully charged, the red light goes out.  
Work indicator light, blue light is always on after powering on; the blue light flashes when shooting.  
WiFi indicator light, blue light. When WiFi is turned on, the red light flashes; after WiFi is connected, the blue light stays on.

### 8. How to record videos and configure recording setting

a. Video Recording

Switch to recording mode and there'll be an **●** icon in the upper left corner of the screen, and the indicator light will turn red.

b. Resolution of video recording: 1080FHD/1080P/720P/WVG/VGA

Note: The default recording mode is loop. Not enough storage space available for the recording. If you want to record more, please adjust the memory.

Adjust the resolution according to the memory.

b. Photo Shooting & Setting

Press and hold power button to enter "Photo shooting Mode". To select "Photo shooting Mode", there'll be an **●** icon in the upper left corner of the screen, and the indicator light will turn red.

c. Recording time: 1080P/About 100 minutes

Recording time: 1080FHD/About 100 minutes

Recording time: 720P/About 100 minutes

Recording time: VGA/About 100 minutes

Recording time: WVG/About 100 minutes

Recording time: 30S/About 100 minutes

Recording time: 10S/About 100 minutes

Recording time: 5S/About 100 minutes

Recording time: 3S/About 100 minutes

Recording time: 1S/About 100 minutes

### 9. Install and use WiFi

WiFi connection (for WiFi model)

Open WiFi function.

PS: Android, please download at Google Play iOS, please download at Apple Store. This domestic can be downloaded in the mobile phone 360.

Scanning QR code to download the APP

Connecting step:

a. When you open the phone, press and hold the "UP/WiFi" button to turn on WiFi, and the indicator light will turn red.

b. Find the "Sports DV" network on your phone, then connecting it by entering the original password: 1234567890.

c. Opening the GoPlus Cam application

Open your phone in real time remote control your camera on your phone, also you can download files from the camera to your phone.

Disconnecting the WiFi connector:

Short press the "UP/WiFi" key to exit WiFi mode.


Can be used for car drivers.

Can be used for a car driver.

Note: Specifications could be subject to modification due to upgrading or updating.

Please regard the actual product as the standard form.

### 8



### 注意事項

1. 高精度产品，防止跌落。
2. 使其与任何强电磁干扰物体（例如电机）保持一定距离，以免造成电磁干扰，可能损坏产品并影响声音或图像质量。
3. 请勿将产品直接暴露在高温和强烈阳光下。
4. 我们建议使用高质量的Micro SD卡以获得最佳效果。
5. 请勿将Micro SD卡放在强磁性物体附近，以免造成数据丢失。
6. 充电过程中若出现过热、冒烟或异味，立即将其从电源插座上拔下，以防止发生火灾。
7. 充电时，请将产品放在儿童接触不到的地方，以防触电。
8. 将设备存放在阴凉、干燥、无尘的地方。

### 前言

该产品是根据市场需求量身定做的高清晰度数字运动视频记录设备。它具有多种行业领先的功能，包括视频录像、慢动作、音频录制、视频显示和可拆卸电池，这使得它非常适合车辆日常记录、照片拍摄、户外运动、深水探测等，让您随时随地拍摄。


### 1



### 产品特点

- 防水外壳，让您拍摄您的水上运动；防水深度达 30 米。
- 高清屏幕，方便观看视频和播放视频。
- 可拆卸电池，易于更换，有助于延长产品使用寿命。
- 边充电边录像。
- 可装电池录制视频。
- 1600万像素高清广角镜头。
- 支持最大64GB的存储卡。
- 多种视频录制格式: 1080FHD/1080P/720P/WVG/VGA
- AVI 视频格式。
- JPG 照片格式。
- 多种拍照模式: 循环录像、间隔摄影、连拍、定时拍照、迷你外观。
- 打开 WiFi，使用手机操作机器会更方便。

### 2



### 3



### 4




### 5




### 6




### 7




### 8



### 9



### 10



### 11



### 9

[FCC Caution.](#)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

\*RF warning for portable device:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator & your body.

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.