


## Programming Remote Directly to Motor

1. Press and hold buttons 1 and 2 (top 2 buttons) on the new remote simultaneously. The green indicator light on the remote will turn on. Continue holding both buttons until the light turns off (in about 5 seconds). remote will turn on. Continue holding both buttons until the light turns off (in about 5 seconds).
2. You have now successfully adjusted the frequency to match your motor's frequency.
3. Find the Code Set button on your motor. If your motor has a clear plastic cover over the buttons, remove it to access them.
4. Briefly press and release the Code Set button (labelled 'DOOR CODE') on the motor. A red LED on the motor will light up.
5. Press the desired button on the new remote that you want to pair with the motor. Hold it for 1-2 seconds. The red light on the motor will begin flashing.
6. Press that same button on the remote again. The flashing light on the motor will stop. Your remote is now successfully programmed and ready to operate the gate.



Motor Type 1 (DOOR CODE)



Motor Type 2 (CODE SET)



### WARNING!

**Product contains coin/button cell battery.**  
Keep product and batteries away from children. The battery is hazardous and can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body. Seek immediate medical attention if it is suspected that a coin/button cell battery has been swallowed or placed inside any part of the body.