

Since this is a passive Toslink Splitter - you may encounter issues with some devices. If you do, please email us at service@bluerigger.com and we will promptly ship an Active Toslink Splitter for free, which will work in all scenarios.



■ service@bluerigger.com

support.bluerigger.com



Installation Instructions

1) Connect the Splitter:

 Plug the splitter into the Toslink port of your HDTV or source device. Ensure it clicks into the Toslink port, for a secure connection



2) Connect Output Devices:

- Use cables <u>shorter than 10 feet</u> to connect your output devices such as headphones or Soundbar
- Ensure each cable clicks into the Toslink port of your output devices and the splitter for a secure connection