



User Manual



BLS-2700

Stand

Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
Internet: www.thomann.de

29.11.2024, ID: 568330 (V5)

Table of contents

1	General information.....	5
1.1	Symbols and signal words.....	5
2	Safety instructions.....	7
3	Features.....	9
4	Operation.....	10
5	Technical specifications.....	14
6	EU declaration of conformity.....	16
7	Protecting the environment.....	18



1 General information

This document contains important instructions for the safe operation of the product. Read and follow the safety instructions and all other instructions. Keep the document for future reference. Make sure that it is available to all those using the product. If you sell the product to another user, be sure that they also receive this document.

Our products and documentation are subject to a process of continuous development. They are therefore subject to change. Please refer to the latest version of the documentation, which is ready for download under www.thomann.de.

1.1 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this document.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – danger zone.

2 Safety instructions

Intended use

This speaker / light stand is used for stable fixing and height-adjustable installation of loud-speaker cabinets and lights. Use the product only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This product may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this product only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Risk of injury and choking hazard for children!

Children can suffocate on packaging material and small parts. Children can injure themselves when handling the product. Never allow children to play with the packaging material and the product. Always store packaging material out of the reach of babies and small children. Always dispose of packaging material properly when it is not in use. Never allow children to use the product without supervision. Keep small parts away from children and make sure that the product does not shed any small parts that children could play with.



CAUTION!

Risk of injury due to tipping of the stand during loaded transport!

If the stand is moved without having removed the installed devices, the stand may tip over and cause injuries and property damage. Remove the installed devices before transporting the stand.



CAUTION!

Risk of injury due to tipping of stand on an unsuitable ground!

When the stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage. Install the stand only on even and solid ground.



CAUTION!

Risk of injury due to tipping of the stand from excessive loading!

In case of excessive loading, the stand might tip over, causing injury and property damage. Never exceed the specified maximum load for the stand.

3 Features

Special features of the speaker/lighting stand:

- Can be extended up to a height of 3.10 m
- Centric load up to 50 kg (110 lbs)
- Extension tube made of hardened steel
- Legs and cross braces made of aluminium
- M10 female thread on 35-mm flange
- Transport length when folded: 1.68 m

4 Operation

Unpack and check carefully there is no transportation damage before using the product. Keep the equipment packaging. To fully protect the product against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.



CAUTION!

Risk of injury due to tipping of the stand during loaded transport!

If the stand is moved without having removed the installed devices, the stand may tip over and cause injuries and property damage.

Remove the installed devices before transporting the stand.



CAUTION!

Risk of injury due to tipping of stand on an unsuitable ground!

When the stand is installed on soft or uneven ground, the stand may tip over and cause injuries and property damage.

Install the stand only on even and solid ground.

**CAUTION!****Risk of injury due to tipping of the stand from excessive loading!**

In case of excessive loading, the stand might tip over, causing injury and property damage.

Never exceed the specified maximum load for the stand.

**NOTICE!****Possible staining due to plasticiser in rubber feet!**

The plasticiser contained in the rubber feet of this product may react with the coating of the floor and cause permanent dark stains after some time.

If necessary, use a suitable mat or felt slide to prevent direct contact between the product's rubber feet and the floor.

**Comply with regulations**

When installing and operating, make sure to follow the standards and regulations that apply in your country.

Setup



1. ➤ Unfold the feet of the stand until the cross braces are in a horizontal position.
2. ➤ Secure this position with the safety screw on the carriage to which the three feet are attached.
3. ➤ Lift the speaker box / spotlight onto the extension tube. The weight of the loudspeaker cabinet / lights to be installed must not exceed the maximum centric load of 50 kg.
4. ➤ Fold out the hand crank.
5. ➤ To adjust the height, loosen the safety screw on the crank case.
6. ➤ Press and hold the yellow security button on the crank case while setting the required height with the hand crank.
7. ➤ Release the yellow security button on the crank case, fix the position of the telescopic rod with the safety screw on the crank case and fold the hand crank back in.

Disassembly

1. ➤ Fold out the hand crank.
2. ➤ Loosen the safety screw on the crank case.
3. ➤ Press and hold the yellow safety button on the crank case while completely lowering the telescopic rod.
4. ➤ Release the yellow security button on the crank case, fix the position of the telescopic rod with the safety screw on the crank case and fold the hand crank back in.
5. ➤ Lift off the speaker or spotlight from the telescopic rod.
6. ➤ Loosen the safety screw on the carriage to which the three feet are attached.
7. ➤ Fold up the feet of the stand.

5 Technical specifications

Height, max.		3.10 m
Total width		1.40 m
Adjustable stand height		2.05 m ... 3.10 m
Stand footprint		0.85 m ²
Length cross-braces		470 mm
Tube diameter	Main tube	Ø 41 mm
	Extension tube	Ø 35 mm
	Feet	Ø 35 mm
Holder type		M10 female thread at the flange / 35 mm flange
Load capacity, max. (not extended, with centric load)		50 kg
Transport dimensions (W × H × D)		170 mm × 1676 mm × 130 mm
Weight		10.8 kg
Colour		Black

Further information

Stand type	Crank stand
Flange type	35 mm at the top end / M10 female thread
Incl. truss	no
Crank	yes

6 EU declaration of conformity

Name and address of manufacturer / EU-AR	Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany
THIS DECLARATION OF CONFORMITY IS ISSUED UNDER THE SOLE RESPONSIBILITY OF:	
Name and address of manufacturer	Thomann GmbH Hans-Thomann-Straße 1 96138 Burgebrach Germany
Product identification	568330 Roadworx BLS-2700 Speaker Stand
THE PRODUCTS MENTIONED IN THIS DECLARATION ARE IN CONFORMITY WITH:	
EU Community Legislation	Machinery Directive 2006/42/EC
Harmonised standards	Safety of machinery ANNEX I OF 2006/42/EC


SIGNED FOR AND ON BEHALF OF:

Place and date of issue

Burgebrach, 26 May 2023

7 Protecting the environment

Disposal of the packing material



Environmentally friendly materials have been chosen for the packaging. These materials can be sent for normal recycling. Ensure that plastic bags, packaging, etc. are disposed of in the proper manner.

Do not dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the instructions and markings on the packaging.



Observe the disposal note regarding documentation in France.

Disposal of your old product

Do not dispose of your old product with your normal household waste; instead, deliver it for controlled disposal by an approved waste disposal firm or through your local waste facility.

Proper disposal protects the environment as well as the health of your fellow human beings. This is because the proper handling of old products negates the potential negative effects of hazardous substances, and because it conserves resources by recycling them.

Also note that waste avoidance is a valuable contribution to environmental protection. Repairing a device or passing it on to another user is an ecologically valuable alternative to disposal. For example, use the classified ads of Thomann GmbH.

