


T6

Waterproof Wireless Earbuds

Thank you for purchasing the TOZO authentic product. For more latest product, parts and accessories, please visit: www.tozostore.com. For any assistance please contact Email: info@tozostore.com

1

Product diagrammatic sketch



wearing diagrammatic sketch




2

Wearing Steps



Operation of earbuds



3

Another method of Turning on&Turning off

Turn on:
Tap and hold the Touch Control on both earbuds for over 3 seconds.
Turn off:
1. Touch the Control button 5 seconds will turn off when earbuds in playless status.
2. The earbuds will turn off automatically after it is disconnected for more than 5 minutes.
Reset:
If your earbuds fails to pair each other, or if you accidentally get only one earbud paired with phone, please reset to factory settings as per instructions below:
1. Delete all TOZO-T6 records on the phone, then turn off the Bluetooth.
2. Take out the earbuds from charging case, wait till two earbuds flash red and blue alternately, then tap both of earbuds 3 times quickly, earbuds will turn off, reset done.
3. Put earbuds back into the charging case, and take earbuds out again, now turn on the phone's Bluetooth and choose [TOZO-T6].

Charging

Charging the Earbuds

1. Put the earbuds into the charging case, they will power off & be charged automatically. When the red LED lights up, it means that the earbuds are being charged from charging case.
2. The red light will turn off when the earbuds are fully charged.

Charging the Charging Case

Please use the 5V/1A adapter to charge the charging case, which can be charged with a computer USB or other USB interface charger.

Box wireless charging

Designed for the modern life, never be strangled by headphone cables. Enjoy the convenience of wireless charging and free charging devices provided by airports, hotels, and cafe shops around the world.

Note: The battery indicator--white indicator light is above the wireless charger.

Charging warning!

Don't tap the earbuds Touch Control while in charge, otherwise it will be fail to pair. Then you should follow the reset to factory settings.

Wireless Charging pad not included.



4

Button operation

Earbuds LED indicator

Turn on	Blue light flash for one seconds
Turn off	Red light flash for one seconds
Pairing status	The two earbuds flash red and blue alternately
Paired with the phone	Non-flashing light
Charging process	Red lights on
Fully charged	Red light goes out

Right Earbud

Play/Pause	Tap the Touch Control Button once on either of earbuds
Volume +	Tap and hold the Touch Control on Right earbud for over 3 seconds, voice "beep"
Next Track	Tap the Right Touch Control twice for forward
Answer Phone Call	Tap the Touch Control once on either of earbuds
Hang Up Phone Call	Tap the Touch Control for 2 seconds on either of earbuds
Reject Incoming Call	Tap and hold the Touch Control for 3 seconds

Left earbuds

Play/Pause	Tap the Touch Control Button once on either of earbuds
Volume -	Tap and hold the Touch Control on Left earbud for over 3 seconds, voice "beep"
Previous Track	Tap the Left Touch Control twice for backward
Answer Phone Call	Tap the Touch Control once on either of earbuds
Hang Up Phone Call	Tap the Touch Control for 2 seconds on either of earbuds
Reject Incoming Call	Tap and hold the Touch Control for 2 seconds

5

Note:

Note: If you accidentally get only one earbud paired with phone, please make sure both earbuds have been turn on. (Tap and hold the unpaired earbud for 3 seconds to turn on).
If necessary, please try "Reset" options to restore to factory settings.

Specifications

Version	V5.0
Support	A2DP, AVRCP, HFP, HSP
Transmission Distance	≥ 10m
Frequency Range	2.402GHz~2.480GHz
horn	Φ 6mm*2
Impedance	16Ω ± 15%
Standby time	70 hours
Call time	5 hours
Music playback time	5 hours
Earbuds battery capacity	55 mAh
Charging time of earbuds	1 hours
The battery capacity of charging case	600 mAh
Charging time of the charging case	1 hours
Weight	4.5g

6

Waterproof

Waterproof for daily use (sweating, rain, washing face, showering, having a bath, etc., but not for swimming under water*)
*Please note that the phone's Bluetooth signal can not be transmitted underwater.



Notes for signal transmission distance (as show below)



Warning!

1. Never dismantle or left the product to avoid malfunction or fire hazards.
2. Keep away from corrosive liquids to avoid damages to the product.
3. Keep away from extreme ambient temperatures below -10°C or above 60°C.
4. Keep away from children and pets.
5. Never touch the earphone with sharp objects, otherwise it will easily cause scratches.
6. Don't use the product in thunderstorm weather to avoid malfunction or electric shock.
7. If it has not been used for more than a month, please charge and maintain it in time to ensure that it is safe.
8. Since the Bluetooth signal cannot be transmitted underwater, swimming, diving will caused the signal disconnected or intermittent.

7

FAQ

1. Q: Failed charging of the charging case.
A: Make sure the charging cable is intact and plugged in properly.
2. Q: Two devices named "TOZO-T6" are found.
A: Delete both names and search again.
3. Q: Sound is unclear.
A: Increase the volume slowly on your phone and earbuds and keep them close to each other.
4. Q: Why cannot hear voice?
A: 1. Ensure both earbuds have been turned on.
2. Turn up the phone's volume to the maximum setting.
3. Try to tap the touch control once to play music.

Note: If your problem is not answered above, please contact us via email.

We will respond within 24 hours.

Email: info@tozostore.com



This product has built-in lithium batteries. Do not expose the product to strong sunlight, fire or throw it into the fire to avoid explosion.

8