

ROCKERZ
480



boAt

ROCKERZ 480


Thank you for choosing the boAt Rockerz 480. This manual is meant to guide you through to the shores of Nirvana without much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for steering this boAt. Therefore, we strongly advise that this manual is thoroughly read before use, and referred to in times of difficulty.



PACKAGE CONTENTS

- 1 x boAt Rockerz 480
- 1 x USB Type-C Charging Cable
- 1 x AUX Cable
- 1 x Manual
- 1 x Warranty Card

PRODUCT OVERVIEW



Power On: Press and hold the MFB (Multifunction Button) for 3 seconds. The blue and red LEDs flash alternatively accompanied by a voice prompt.

Power Off: Press and hold the MFB for 4 seconds. Red LED blinks once to indicate the device getting switched off.

RGB ON/OFF: Short press the dedicated RGB button to toggle between the 6 LED Modes. The cycle of operation is as follows -

LED Mode 1 LED Mode 2 LED Mode 3 LED mode 4 LED mode 5 LED mode 6 Turn off LED LED Mode 1

BLUETOOTH CONNECTIVITY

Step 1: Press and hold the MFB for 3 seconds to turn on the headphone and put them into pairing mode, indicated by blue and red LED flashes
Step 2: Open your device's Bluetooth menu and search for 'Rockerz 480' to pair

Congratulations! The headphone has been paired with your media device.



Front

BASIC FUNCTIONS

Play: Short press the MFB once to play
Pause: Short press the MFB once to pause
Volume Up: Press the Vol + button in steps to increase volume
Volume Down: Press the Vol - button in steps to decrease volume
Next Track: Press and hold Vol + button for 1 second to skip to next track
Previous Track: Press and hold the Vol - button for 1 second to return to previous track
Answer Incoming Calls: Short press the MFB once
Hangup Ongoing Calls: Short press the MFB once
Reject Calls: Double press the MFB
Voice Assistant/Siri: Triple press the MFB Button

BEAST™ Mode for Gaming: Double press the MFB to activate BEAST Mode for low latency gameplaytime. To switch back to Music Mode, double press the MFB again.

Note: If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.

Charging norms & Precautionary Guidelines: -	
1) Charger/Brick/Adapter	5V 2A
2) Cable/Wire	Standard Cable (35 strands @0.10mm diameter/ strand)
Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.	

CHARGING

- Connect one end of the provided cable to the USB Type-C port on the headset and the other end to a wall adapter or laptop
- While charging the indicator LED turns into steady red
- When the headphone is fully charged, LED turns into steady blue
- Use only authorized/company chargers for the headset, as unauthorized ones may damage the same and invalidate the warranty on the headset as well
- The headphones cannot be utilized for listening purposes while it is charging mode

Note: When the headphones are in low power state, then that gets indicated by slowly flashing red LED.

DUAL PAIRING:

To connect Rockerz 480 to two devices simultaneously, firstly connect the headphone to one of the devices. Then, switch both the headphone and the first device's Bluetooth off. Thereafter, connect the headphone to the second device, and again switch the first device on. The headphone gets connected to both devices. If not, connect the first device manually once again to activate dual pairing.

ENX™ TECH

Our ENX™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENX™ as the mic is equipped with the same and activated by default.

Deliver your voice without interruptions anywhere – traffic, railway stations, airports, work space; literally anywhere!

RESET

When the headphone is in the 'ON' state, press and hold the Vol + and Vol - buttons simultaneously for 5 seconds

Note: Reset should be done in pairing mode.

OTHER FUNCTIONS

- If there's no connection established when the Bluetooth is switched on then the device powers off automatically after a while
- If you receive an incoming call during playing music, the music automatically disconnects. When the call is done and disconnected, the music starts to play automatically from where it left.

ANOMALIES & SOLUTIONS

- A. Mobile can't search the headset
- Check if the Bluetooth headset is powered on or off (When powered on, the LEDs blink with red and blue colours alternatively)
- If it is powered on and the device still can't connect, then please reboot the Bluetooth device and the phone
- B. After connecting the headset with the phone, disconnection or noise occurs
- This may be due to the low power of the headset. Please charge the Bluetooth headset
- There might be obstruction between the headset and the phone or the distance between them exceeds the maximum range for signal reception
- C.Voice Assistant Support doesn't respond
- If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device's settings.

SPECIFICATION:

Headphone Type	Bluetooth Headphones
Driver Size	40mm*2
HD Sound	Yes
THD	≤5% at 1kHz
Frequency Range	20Hz-20 KHz
SNR	96dB
Bluetooth Version	V5.3
Bluetooth Profile	A2DP,AVRCP,HFP,HID,AVCTP,AVDTP,SPP
Bluetooth Range	10m
Battery Capacity	600mAh
Playing Time	Up to 60 Hours (at 60%vol approx.)
Charging Time	1.5HRS
Standby Time	>120HRS
Charging Interface	USB Type-C
Mic Sensitivity	-38dB±3dB
Charging Voltage	5V 0.5A
BEAST™ Mode	Yes
ENX™ Tech	Yes

SAFETY PRECAUTIONS

- This is not a toy. The children are advised to use this under adult supervision.
- Avoid exposing the device to extremely hot or cold temperatures.
- Avoid using the headphone for listening to full volumes to protect from hearing damage.
- Please do not use the device under thunder storms.
- Don't dismantle the product in any way.
- Please don't clean the product using oily volatile liquid.

Back