

## INSTALLATION GUIDE

Everything you wanted to know but were too afraid to ask

# andro.

think. again.

### ANDRO TRIM



### WHOA, HOLD IT!

- 1 To avoid non-replaceable damage of custom-painted fittings, the secondary ring must be removed before adjusting the inner tube. The inner tube must be adjusted at ground level before ceiling installation.
- 2 Hit the off switch on any power before install.
- 3 Install must only be carried out by someone suitably qualified.
- 4 Only use the product at the specified voltage and frequency.
- 5 It would be sweet if you ♻️ the packaging.
- 6 Read Step 1 again. Thx.



IP20

RoHS



ambience  
MAKING LIGHT WORK


+61 3 9486 3699  
sales@ambienclighting.com.au  
ambienclighting.com.au



1


Cut a hole in the ceiling as per the nominated cut-out sizes:

S Ø98mm  
M Ø115mm  
L Ø128mm




2

Remove the secondary ring by rotating it anti-clockwise and pulling it out.




3

Push the housing in the hole.




4 A

Fix the screws onto the ceiling using a screw driver.




4 B

Tighten the screws until the flanges on the housing are retracted and the housing is held tight in its position.




5

Fix the secondary ring back onto the housing by rotating it clockwise and pushing it in.



6

Turn ON power supply to complete installation.



7

Now repurpose your **andro** packaging to plant some seedlings.

