

# Brookstone®

## COMPACT WIRELESS HEADPHONES

BLUETOOTH® HEADPHONES WITH ON-EAR CONTROLS



Fold

### LITHIUM-ION BATTERY WARNINGS

This device contains a non-removable lithium-ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.

### FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Fold

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.



Modifications not authorized by the manufacturer may void the user's authority to operate this device.

FCCID: 2AF8E-WL-2706

Fold

### LOCATION OF PARTS AND CONTROLS

1. Power Button
2. Volume Up/Track Backward Button
3. Volume Down/Track Forward Button
4. Microphone
5. Audio Cable Port
6. Micro USB Charging Port
7. Micro USB Charging Cable (not shown)
8. Audio Cable (not shown)
9. Travel Pouch (not shown)



Fold

### PAIRING YOUR DEVICE

1. Press and hold the Power Button for 3 seconds to power on the headphones. The blue light will illuminate.
2. If the Button is pressed and held, the headphones will search for Bluetooth® enabled devices. The red and blue lights will flash alternatively.
3. Once the headphones are in pairing mode and your device is ready to pair, select 'Brookstone Headphones.' If prompted, use 0000 as a PIN for the pairing code. Once the headphones are selected, a beep tone will sound and the blue light will flash.

### NOTE:

If the headphones were powered on and without Bluetooth® connection for 3 minutes, they will auto shut off. After a successful connection, the blue LED will flash three times every 5 seconds (Bluetooth® connected but not playing music)

Brookstone®  
A WORLD OF INNOVATION

Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

306612

Merrimack, New Hampshire, USA 03054  
800-846-3000 • Brookstone.com

## CHARGING THE HEADPHONES

The headphones are equipped with non-removable built-in battery that can be charged repeatedly. When used for the first time, please make sure that the headphones are fully charged.

1. Connect the USB charging cable to the charging port on the headphones.
2. Insert the charging cable into the standard power socket. During charging process, the indicator light will become red. If the charging has not been started, please unplug the charger and then re-insert it.
3. After the headphones are fully charged, the red indicator light will turn off. In this case, please unplug the charger from the power socket and headphones.
  - Repeated charging and discharging of the headphones may lead to the declined battery performance over time.
  - During charging, please be sure not to make or receive phone calls using the headphones.

NOTE: When the battery capacity of headphones is not adequate, the indicator light of headset will flash red, and you will hear the alarm or "The headset battery capacity is low." If the headphones are shut down during the time when you make phone calls, these calls will

## Fold

be automatically transferred to your mobile phone. The headphones will shut off when AUX/MICRO input is used, and you will need to unplug and power on again for music to play.

## LISTENING TO AUDIO

1. Press the Power Button once to play music. Press the Power Button again to pause the music.
2. Short press the Volume "+" button one time to go to the previous song or beginning of current song. Short press the Volume "-" button to go to the next song.
3. In the process of playing music or receiving calls, a long press of the Volume "+" or "-" buttons will increase or decrease the volume level to desired level.

## PLAYING MUSIC THROUGH A WIRED CONNECTION

Plug one end of the audio cable (included) into your audio device and plug the other end of the cable into the headphones' Aux-In port.

## Fold

## MOBILE PHONE OPERATION

When the headphones are paired to your device and a call is received, the incoming call tone will sound.

If there is audio playing through the headphones when a call is answered, the audio will pause and only your call will be audible. When you end the call, your audio will resume.

1. Receiving call: When the bell rings, short press the Power Button for 1 second.
2. Hanging up calls: At the end of calls, short press the Power Button for 1 second.
3. Rejecting calls: When the bell rings, press and hold the Power Button for 2 seconds.

## RESET

To hard reset the headphones, connect to the USB cable and plug into a charging source.

## CARE AND MAINTENANCE

Do not submerge the headphones in water. To clean, wipe the headphones with a soft, dry cloth.

## Fold

## SPECIFICATIONS

Power Supply: 3.7V, 300mAh

DC Input: 5V, 1A

Range: Class 2, up to 33 ft (10m)

Driver: 40 mm Dia.

Frequency Response: 20Hz~20KHz

Sensitivity @ 1KHz: 110 +/- 3 dB

Charging Time: Approx. 2 hours

Battery Life: Approx. 14 hours

Compatibility: Bluetooth® 2.0 or above device with A2DP/AVRCP/HFP/HSP

## Fold

## ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

**Obtaining Service:** To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

**Limits and Exclusions:** Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own

## Fold

warranties to the purchaser, but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

**BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.**

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

The Bluetooth® word mark and logos are registered trademarks owned of Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.