

Operation Manual

Foldable Handcart

60274

toboli



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps, and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.

The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless, and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler
Germany

To return orders for exchange, repair, or other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15

Introduction

Thank you for purchasing this quality product. **To minimise the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.** Keep these operation instructions safe.

Unfolding the handcart



1. Unpack the folded cart and lay it flat on the floor.



2. Press the plastic buckles on the carrying case to open it.



3. Remove the carrying case from the cart.



4. Pull apart the Velcro fastener on the handle of the bag.



5. Remove the handle from the plastic fastener.



6. Unfold the cart (see photo).



7. Loosen the two rear wheels to pull them to the right and left.



8. The wheels must then be at both ends of the axle.



9. The fully unfolded cart should look like the one in the photo.

Technical specifications

Dimensions (cm)	Unfolded	approx. 110×50×121
	Folded	approx. 76×50×17
	Capacity	approx. 80×45×27
	Wheel/rim	10×Ø17.5
Max. capacity (kg)		80
Weight (kg)		10.5

 **Caution:** Do not exceed the maximum capacity!

Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part, of this instruction manual require the written permission of WilTec Wildanger Technik GmbH.