

- *¹⁰ Measured to be accurate by playing our specified music source with the volume level of the unit set to 20, the sound mode set to S-PROLOGIC, and the illumination turned off.
- *¹¹ Measured to be accurate by playing our specified music source with the volume level of the unit set to 20 and with the factory default settings (illumination: ON and sound mode: DCTA BASS).
- *¹² Measured to be accurate by playing our specified music source with the volume level of the unit set to medium and with the factory default settings (illumination: ON and sound mode: DCTA BASS).

If the built-in battery has been fully recharged, the power is now on, and it is used to play with power for about 17 hours on a full charge.

The average battery life may vary depending on the volume level, sound mode, and the volume, surrounding temperature, and usage conditions.

System requirements for charging battery using USB





Using a commercially available USB AC adapter capable of feeding in 1.5 A

Compatible iPhone/iPod models

iPhone: iPhone 8 Plus, iPhone 8, iPhone 7 Plus, iPhone 7, iPhone SE, iPhone 6s Plus, iPhone 6s, iPhone 6 Plus, iPhone 6, iPhone 5s, iPhone 5, iPod touch (6th generation), iPod touch (5th generation), iPod nano (7th generation)

New model specifications are subject to change without notice.

SONY



PRINTED IN MEXICO
SC:02.07.2020 / 2P / Elbrd:J.E.
OBPN: 4-747-828-11(1)
SHNMDL:SRXB32BC_B
804109570

