


特技车使用说明书

请在使用前仔细阅读使用说明书。请保管好本说明书以备不时之用。

包装清单



特技车及遥控器电池安装和充电



遥控器功能



基本操纵图



保养与维修

1. 用湿布来清理玩具。
2. 勿把玩具放在高温或潮湿及阳光直射的地方。
3. 不要把玩具放在水中，会损坏电子元件。

注意事项

1. 安装或更换电池请注意极性。
2. 非充电电池不能充电。
3. 不可使用新旧电池或不同类型的电池。
4. 操作时，注意附近信号干扰，否则会影响遥控距离。
5. 车速慢时，说明车体电量不足，请及时充电。
6. 遥控器电量不足，指示灯会变暗或者不亮，请更换电池。
7. 长时间不使用时，请取出遥控器内的电池，遥控车电源开关要拨到OFF位置并半个月给车子充电一次。


STUNTCARINSTRUCTION

Please read this instruction manual carefully before use, and properly keep this manual for future use.



Packing list




Installation and charging method for the batteries of stunt car and remote control



Remote control function



OPERATION METHOD



CAR AND MAINTENANCE

1. If necessary, use a wet towel to gently wipe the car body clean.
2. Do not expose this toy to high temperature, high humidity or direct sunlight.
3. Do not put the toy in water to avoid damaging its electronic components.

CAUTIONS

1. Pay attention to the direction when installing or replacing batteries.
2. Do not use non-rechargeable batteries.
3. When charging the rechargeable battery, adult guardianship is required.
4. Do not mix old and new batteries or different types of batteries.
5. During the operation, please pay attention to the nearby interference signal, otherwise the remote control distance will be affected.
6. Please replace the battery in the following cases: the battery of the remote control is low, it is unable to charge the truck and the charging indicator becomes dark or is not turned on.
7. Please take out the battery on the remote control and take out the battery, put the power switch of the truck to the "OFF" position if the truck is not used for a long time.