


GC420t



GC420t

Item #	Description	Part Number
1	Latch Assy.	105910-052
2	Feed Switch/Sensor Assy. (set of 3)	G105910-064
3	Upper Cover Support (set of 3)	G105910-066
4	Printhead Assy., (203 dpi) Print Head Cable Assy.	G105910-053 105910-065
5	Head Up Sensor	G105916-015
6	Gap/Blackline Sensor PCBA (set of 3)	P1012845-002
7	Platen Kit, std. (set of 3)	105910-055
8	Front Bezel, std. (set of 10)	105910-057
9	Front Bezel, Dispenser Label Taken Sensor PCBA (set of 3)	P1031815-013 P1031815-012
10	Rubber Foot Kit (set of 24)	105910-007
11	Main Control PCBA, Ser./USB/Par., Cutter Main Control PCBA, Ethernet/USB, Cutter	P1031815-019 P1031815-020
12	Lower Frame Assy.	P1031815-014
13	Cover Hinge (set of 10)	G105910-074
14	Upper Cover Assy.	P1031815-015
15	Ribbon Out Sensor (set of 3)	G105910-067
16	Ribbon Carriage w/o print head	G105910-061
Not Shown	Motor (set of 2) Nameplate GC420t Power Supply, 60W, 20V, with US Cord Power Supply, 60W, 20V, with UK and EU Cords Power Cord, US (Set of 5) Power Cord, Euro (Set of 5) Power Cord, U.K (Set of 5) Power Cord, Australia (Set of 5) Power Cord, Argentina (Set of 5) Power Cord, Brazil (Set of 5) Users CD-ROM Service CD-ROM Shipping Pack – Packaging for shipping the printer	G105910-051 P1031815-022 P1012845-011 105950-076 105950-061 105950-062 105950-063 105950-064 105950-066 P1037999 P1031815-024 P1050233-001 105934-151