# **C28 Wireless Transmitter receiver**



**USER MANUAL** 

Please read this manual carefully before use.

Package contents:

- \* 1 Charge Cable.
- \* 1 3.5mm audio head.
- \* User manual.

## **Specifications:**

\*Life time: 4 h

\*Battery capacity: 140 mA

\*Working range: open area up to 10 meters, without any obstacles


\*Product size: 59.5mm (L) x 22mm (W) x 12mm (H)



## **One Button Control**

Easilly switch between transmitter (TX) & receriver (RX) mode.

## Interface diagram:



- ①.Multifuntion Botton(Power/Play/Pause).
- Aux in/out.
- 3. Transmitter and Receiver Swiches.
- microphone
- Indicator Light.
- 6.5V/1A Charging port.

## How To Use:

## Receiver Mode

- 1.Use the micro USB cable to charge before use;
- 2.Connect the C28 to your audio device using the AUX cable;
- 3.Change the switch button to position RX; 4.Turn on the device(Long press in the multifunction button)
- then the blue light will flash quickly,indicating that is ready
- 5.Find C28 in the wireless search of your phone and chose to

#### Transmitter Mode

- 1.Use the micro USB cable to charge before use;
- 2.Connect the C28 to your audio device using the AUX cable;
- 3. Change the switch button to position TX;
- 4.Turn on the device(Long press in the multifunction button) then the red light will flash quickly,indicating that is ready for pairing;
- 5.Turn on the device you want to connect and the C28 will automatically connect. When the connection is successful the wireless indicator will illuminate red.

#### Precautions

- 1. Our adapter is only an converter, which sound quality depends on the sound effect of your own equipment and you can change your device then try it again.
- 2. If you have any questions about our products, please contact us with after-sales mailbox directly. We will reply in time to help you resolve and satisfy you. You can believe that we'd like to address any issues or concerns you have.