


# GC-EH 6055/1


- D Originalbetriebsanleitung Elektro-Heckenschere
- GB Original operating instructions Electric hedge trimmer
- F Instructions d'origine Taille-haies électrique
- I Istruzioni per l'uso originali Cesoie per siepi elettriche
- DK/ Original betjeningsvejledning N Eldreven hækkeklipper
- S Original-bruksanvisning Elektrisk häcksax
- NL Originele handleiding Elektrische heggenschaar
- E Manual de instrucciones original Tijeras recortasetos eléctricas
- RUS Оригинальное руководство по эксплуатации Электрические содовые ножницы
- SLO Originalna navodila za uporabo Električne škarje za živo mejo
- H Eredeti használati utasítás Elektromos-kerti olló

- P Manual de instruções original Corta-sebes eléctrico
- HR/ Originalne upute za uporabu
- BIH Električne škare za živicu
- RS Originalna uputstva za upotrebu Električne makaze za živicu
- PL Instrukcją oryginalną Elektryczne nożyce do żywopłotu
- BG Оригинално упътване за употреба Електрическа градинска ножица




Art.-Nr.: 34.033.20 I.-Nr.: 11016



































#### Danger!

When using the equipment, a few safety precautions must be observed to avoid injuries and damage. Please read the complete operating instructions and safety regulations with due care. Keep this manual in a safe place, so that the information is available at all times. If you give the equipment to any other person, hand over these operating instructions and safety regulations as well. We cannot accept any liability for damage or accidents which arise due to a failure to follow these instructions and the safety instructions.

# Explanation of the warning signs on the equipment (see Fig. 10)

- 1. Warning!
- Do not expose the hedge trimmer to rain or wet conditions.
- CAUTION Read the operating instructions to reduce the risk of inquiry.
- If the cable is damaged or cut, pull out the power plug from the mains immediately.
- 5. Wear eye protection and ear plugs.
- 6. **Danger!** Moving blade. Keep hands and feet away from the blade.

# 1. Safety regulations

The corresponding safety information can be found in the enclosed booklet.

#### Warning!

Read all the safety information, instructions, illustrations and technical data provided on or with this power tool. Failure to adhere to the following instructions may result in electric shock, fire and/or serious injury.

Keep all the safety information and instructions in a safe place for future use.

This equipment is not designed to be used by people (including children) with limited physical, sensory or mental capacities or those with no experience and/or knowledge unless they are supervised by a person who is responsible for their safety or they have received instructions from such a person in how to use the equipment safely. Children must always be supervised in order to ensure that they do not play with the equipment.

# 2. Layout and items supplied

## 2.1 Layout (Fig. 1/2)

- 1. Cutter rail
- 2. Hand guard
- 3. Steady grip with button switch
- 4. Handle with button switch
- 5. Cable strain-relief clamp
- 6. Power cable
- 7. Cutter guard
- 8. Fastening screws for cuttings collector
- Cuttings collector

#### 2.2 Items supplied

Please check that the article is complete as specified in the scope of delivery. If parts are missing, please contact our service center or the sales outlet where you made your purchase at the latest within 5 working days after purchasing the product and upon presentation of a valid bill of purchase. Also, refer to the warranty table in the service information at the end of the operating instructions.

- Open the packaging and take out the equipment with care.
- Remove the packaging material and any packaging and/or transportation braces (if available).
- Check to see if all items are supplied.
- Inspect the equipment and accessories for transport damage.
- If possible, please keep the packaging until the end of the guarantee period.

#### Danger!

The equipment and packaging material are not toys. Do not let children play with plastic bags, foils or small parts. There is a danger of swallowing or suffocating!

- Hedge trimmer
- Cutter guard
- Cuttings collector
- Original operating instructions
- Safety instructions

# 3. Proper use

Important. This hedge trimmer is suitable for cutting hedges, bushes and shrubs.

The equipment is to be used only for its prescribed purpose. Any other use is deemed to be a case of misuse. The user / operator and not the manufacturer will be liable for any damage or injuries of any kind caused as a result of this.

Please note that our equipment has not been designed for use in commercial, trade or industrial applications. Our warranty will be voided if the machine is used in commercial, trade or industrial businesses or for equivalent purposes.

#### 4. Technical data

NA - Common Discours	000 0401/ 5011
Mains voltage:	220-240 V ~ 50 Hz
Power input:	600 W
Idling speed:	1400 min <sup>-1</sup>
Cutting length	550 mm
Cutter rail length	610 mm
Tooth spacing	26 mm
Max. cutting thickness	16 mm
Cuts/min	2800
Protection class:	II / 🗖

#### Danger!

#### Sound and vibration

Sound and vibration values were measured in accordance with EN 62841.

L <sub>DA</sub> sound pressure leve	el 86,12 dB(A)
K <sub>nA</sub> uncertainty	3 dB
L <sub>wa</sub> sound power level	94,12 dB(A)
K <sub>wa</sub> uncertainty	3,47 dB

#### Wear ear-muffs.

The impact of noise can cause damage to hearing.

Total vibration values (vector sum of three directions) determined in accordance with EN 62841.

Vibration emission value  $a_h \le 2.5 \text{ m/s}^2$ K uncertainty = 1.5 m/s<sup>2</sup> The stated vibration emission levels and stated noise emission values were measured in accordance with a set of standardized criteria and can be used to compare one power tool with another.

The stated vibration emission levels and stated noise emission values can also be used to make an initial assessment of exposure.

#### Warning:

The vibration and noise emission levels may vary from the level specified during actual use, depending on the way in which the power tool is used, especially the type of workpiece it is used for.

# Keep the noise emissions and vibrations to a minimum.

- Only use appliances which are in perfect working order.
- Service and clean the appliance regularly.
- Adapt your working style to suit the appliance.
- Do not overload the appliance.
- Have the appliance serviced whenever necessary.
- Switch the appliance off when it is not in use.
- Wear protective gloves.

#### Caution!

#### Residual risks

Even if you use this electric power tool in accordance with instructions, certain residual risks cannot be rules out. The following hazards may arise in connection with the equipment's construction and layout:

- Damage to hearing if no suitable ear protection is used.
- Health damage caused by hand-arm vibrations if the equipment is used over a prolonged period or is not properly guided and maintained.

# 5. Before starting the equipment

Before you connect the equipment to the mains supply make sure that the data on the rating plate are identical to the mains data.

#### Warning!

Always pull the power plug before making adjustments to the equipment.

# Fitting the cuttings collector (Figure 3a-3d)

For horizontal cutting we recommend that you install the cuttings collector. This enables you to remove the cuttings easily. The surface of the hedge thus remains clear (Fig. 3a/3b).

Position the cuttings collector (9) on the cutter rail (Figure 3c). Then push the cuttings collector as far as possible towards the tip of the cutter rail and secure it with the fastening screws (8) (Figure 3d).

## 6. Operation

The hedge trimmer is equipped with a two-handed safety switch. The equipment works only when the switch on the steady grip (Figure 4 / Item A) is pressed with one hand and the switch on the handle (Figure 4 / Item B) is pressed with the other hand. If either switch is released, the cutters will stop moving.

Please watch out for the cutters as they slow down to a standstill.

- Please check that the cutters work properly.
   The twin-bladed cutters rotate in opposite directions, thus guaranteeing high cutting performance and smooth operation.
- Before use, fasten the extension cable in the stress-relief clip (see Fig. 4).
- When working outdoors, use extension cables that are approved for the purpose.

## Notes on working practice

- A hedge trimmer can be used to cut shrubs and bushes as well as hedges.
- To obtain the best cutting results, hold the hedge trimmer so that the cutter teeth are at an angle of approx. 15° in relation to the hedge (see Figure 5).
- The twin-bladed cutters rotate in opposite directions, thus enabling cutting in both directions (see Figure 6).
- It is recommended to tie a guide line of string or the like along the hedge so that you cut the

- hedge to a level height. Cut off all branches which protrude beyond the guide line (see Figure 7).
- Cut the sides of the hedge with curve-shaped movements from the bottom up (see Figure 8)

## 7. Replacing the power cable

#### Danger

If the power cable for this equipment is damaged, it must be replaced by the manufacturer or its after-sales service or similarly trained personnel to avoid danger.

# 8. Cleaning, maintenance and ordering of spare parts

#### Danger!

Always pull out the mains power plug before starting any cleaning work.

#### 8.1 Cleaning

- Keep all safety devices, air vents and the motor housing free of dirt and dust as far as possible. Wipe the equipment with a clean cloth or blow it with compressed air at low pressure.
- We recommend that you clean the device immediately each time you have finished using it.
- Clean the equipment regularly with a moist cloth and some soft soap. Do not use cleaning agents or solvents; these could attack the plastic parts of the equipment. Ensure that no water can seep into the device. The ingress of water into an electric tool increases the risk of an electric shock.

#### 8.2 Maintenance

- The cutters should be cleaned and lubricated at regular intervals in order to ensure best performance at all times. Remove deposits with a brush and apply a thin film of oil (see Figure 9).
- There are no parts inside the equipment which require additional maintenance.

# 8.3 Ordering replacement parts:

Please quote the following data when ordering replacement parts:

- Type of machine
- Article number of the machine
- Identification number of the machine
- Replacement part number of the part required For our latest prices and information please go to www.Einhell-Service.com

# 9. Disposal and recycling

The equipment is supplied in packaging to prevent it from being damaged in transit. The raw materials in this packaging can be reused or recycled. The equipment and its accessories are made of various types of material, such as metal and plastic. Never place defective equipment in your household refuse. The equipment should be taken to a suitable collection center for proper disposal. If you do not know the whereabouts of such a collection point, you should ask in your local council offices.

# 10. Storage

Store the equipment and accessories in a dark and dry place at above freezing temperature. The ideal storage temperature is between 5 and 30 °C. Store the electric tool in its original packaging.



For EU countries only

Never place any electric power tools in your household refuse.

To comply with European Directive 2012/19/EC concerning old electric and electronic equipment and its implementation in national laws, old electric power tools have to be separated from other waste and disposed of in an environment-friendly fashion, e.g. by taking to a recycling depot.

#### Recycling alternative to the return request:

As an alternative to returning the equipment to the manufacturer, the owner of the electrical equipment must make sure that the equipment is properly disposed of if he no longer wants to keep the equipment. The old equipment can be returned to a suitable collection point that will dispose of the equipment in accordance with the national recycling and waste disposal regulations. This does not apply to any accessories or aids without electrical components supplied with the old equipment.

Please note that batteries and lamps (e.g. light bulbs) must be removed from the tool before it is disposed of.

The reprinting or reproduction by any other means, in whole or in part, of documentation and papers accompanying products is permitted only with the express consent of the Einhell Germany AG.

Subject to technical changes

# **Service information**

We have competent service partners in all countries named on the guarantee certificate whose contact details can also be found on the guarantee certificate. These partners will help you with all service requests such as repairs, spare and wearing part orders or the purchase of consumables.

Please note that the following parts of this product are subject to normal or natural wear and that the following parts are therefore also required for use as consumables.

Category	Example
Wear parts*	Blade guide, Carbon brushes
Consumables*	Blade
Missing parts	

<sup>\*</sup> Not necessarily included in the scope of delivery!

In the effect of defects or faults, please register the problem on the internet at www.Einhell-Service.com. Please ensure that you provide a precise description of the problem and answer the following questions in all cases:

- Did the equipment work at all or was it defective from the beginning?
- Did you notice anything (symptom or defect) prior to the failure?
- What malfunction does the equipment have in your opinion (main symptom)?
   Describe this malfunction.

# **Warranty certificate**

Dear Customer.

All of our products undergo strict quality checks to ensure that they reach you in perfect condition. In the unlikely event that your device develops a fault, please contact our service department at the address shown on this guarantee card. You can also contact us by telephone using the service number shown. Please note the following terms under which guarantee claims can be made:

- These guarantee terms apply to consumers only, i.e. natural persons intending to use this product neither for their commercial activities nor for any other self-employed activities. These warranty terms regulate additional warranty services, which the manufacturer mentioned below promises to buyers of its new products in addition to their statutory rights of guarantee. Your statutory guarantee claims are not affected by this guarantee. Our guarantee is free of charge to you.
- 2. The warranty services cover only defects due to material or manufacturing faults on a product which you have bought from the manufacturer mentioned below and are limited to either the rectification of said defects on the product or the replacement of the product, whichever we prefer. Please note that our devices are not designed for use in commercial, trade or professional applications. A guarantee contract will not be created if the device has been used by commercial, trade or industrial business or has been exposed to similar stresses during the guarantee period.
- 3. The following are not covered by our guarantee:
  - Damage to the device caused by a failure to follow the assembly instructions or due to incorrect installation, a failure to follow the operating instructions (for example connecting it to an incorrect mains voltage or current type) or a failure to follow the maintenance and safety instructions or by exposing the device to abnormal environmental conditions or by lack of care and maintenance.
  - Damage to the device caused by abuse or incorrect use (for example overloading the device or the use or unapproved tools or accessories), ingress of foreign bodies into the device (such as sand, stones or dust, transport damage), the use of force or damage caused by external forces (for example by dropping it).
  - Damage to the device or parts of the device caused by normal or natural wear or tear or by normal use of the device.
- 4. The guarantee is valid for a period of 24 months starting from the purchase date of the device. Guarantee claims should be submitted before the end of the guarantee period within two weeks of the defect being noticed. No guarantee claims will be accepted after the end of the guarantee period. The original guarantee period remains applicable to the device even if repairs are carried out or parts are replaced. In such cases, the work performed or parts fitted will not result in an extension of the guarantee period, and no new guarantee will become active for the work performed or parts fitted. This also applies if an on-site service is used.
- 5. To make a claim under the guarantee, please register the defective device at: www.Einhell-Service.com. Please keep your bill of purchase or other proof of purchase for the new device. Devices that are returned without proof of purchase or without a rating plate shall not be covered by the guarantee, because appropriate identification will not be possible. If the defect is covered by our guarantee, then the item in question will either be repaired immediately and returned to you or we will send you a new replacement.

Of course, we are also happy offer a chargeable repair service for any defects which are not covered by the scope of this guarantee or for units which are no longer covered. To take advantage of this service, please send the device to our service address.

Also refer to the restrictions of this warranty concerning wear parts, consumables and missing parts as set out in the service information in these operating instructions.

<i>CF</i> ———		FU
D Konformitätserklärung: Wir erklären Konformität gemäß EU-	HR	IZJAVA O SUKLADNOSTI potvrđuje sljedeću usklađenost prema
Richtlinie und Normen für Artikel		smjernicama EU i normama za artikl
GB Declaration of conformity: We declare conformity in accordance with the EU directive and standards for article	ce <b>BIH</b>	IZĴAVA O SUKLADNOSTI potvrđuje sljedeću usklađenost prema smjernicama EU i normamaza artikl
F Déclaration de conformité : Nous déclarons la conformité conformité : Nous déclarons la conformité conformité :	for- RS	DEKLARACIJA O USUGLAŠENOST potvrđuje sledeću
mément aux directives et normes UE pour l'article  Dichiarazione di conformità: dichiariamo la conformità second	iola TR	usklađenost prema smernicama EZ i normama za artikal Uygunluk Deklarasyonu: AB direktifi ve ürün standartları uyarınca
direttiva UE e le norme per l'articolo	- "- DUO	uygunluğunu beyan ederiz
DK Overensstemmelseserklæring: Vi attesterer overensstemmels EU-direktiv samt standarder for artikel	se iht. RUS	Заявление о соответствии товара: Настоящим удостоверяется, что следующие продукты соответствуют
S Försäkran om överensstämmelse: Vi förklarar följande överen stämmelse enl. EU-direktiv och standarder för artikeln	is- EE	директивам и нормам EC Vastavusdeklaratsioon: Tõendame toote vastavust EL direktiivile ja
CZ Prohlášení o shodě: Prohlašujeme shodu podle směrnice EU	a	standarditele
norem pro výrobek SK Vyhlásenie o zhode: Vyhlasujeme zhodu podľa smernice EÚ a	LV a	Atbilstības deklarācija: Mēs apliecinām atbilstību ES direktīvai un standartiem tālāk minētajām precēm
noriem pre výrobok	LT	Atitikties deklaracija: deklaruojame, kad gaminys atitinka ES
NL Conformiteitsverklaring: wij verklaren conformiteit conform EU richtlijn en normen voor artikel	)- PL	direktyvą ir standartus Deklaracja Zgodności - deklarujemy zgodność wymienionego
E Declaración de conformidad: declaramos la conformidad a ter	nor	poniżej artykułu z następującymi normami na podstawie
de la directiva y normas de la UE para el artículo FIN Standardinmukaisuustodistus: Me vakuutamme, että EU-direk	ktiivin <b>BG</b>	dyrektywy EU Декларация за съответствие: Ние декларираме съответствие
ja standardien vaatimukset täyttyvät tuotteelle SLO IZJAVA O SKLADNOSTI potrjuje sledečo skladnost s smernic		на Директивите и нормите (EC) за изделия Декларація відповідності: ми заявляємо про відповідність
in standardi za izdelek		згідно з Директивою ЄС та стандартами стосовно артикула
H Konformitási nyilatkozat: Az EU-irányvonal és normák szerinti konformitást jelentjük ki a cikkekhez	MK	Изјава за сообразност: Изјавуваме сообразност со регулативата и со нормите на ЕУ за артикли
RO Declarație de conformitate: Declarăm conformitate conform	N	Samsvarserklæring: Vi erklærer samsvar i henhold til EU-direktiv
directivei şi normelor UE pentru articolul  GR Δήλωση συμμόρφωσης: Δηλώνουμε συμμόρφωση σύμφωνο	ıus IS	og standarder for artikkel Samræmisyfirlýsing: Við útskurðum samræmi við EU-reglugerð og
Οδηγία Εε και πρότυπα για τα προϊόντα		stöðlum fyrir vörutegund
P Declaração de conformidade: Declaramos a conformidade de acordo com a diretiva CE e normas para o artigo	9	
Elektro-Heckenschere* GC-EH 6055/1 (Einhell)		
2014/29/EU X 2006/42	P/FC	
	ed Body:	
<b>(EU)2015/1188</b> Reg. №	No.:	
2014/35/EU X 2000/14	1/EC_2005/8	8/EC
☑ 2006/28/EC X Anne	ex V	
X 2014/30/EU	ex VI	
Noise Noise		= 94,12 dB (A); guaranteed L <sub>wA</sub> = 98 dB (A)
	,6 kW; L = 55 cr	n
	ed Body:	
	5/EU_(EU)20	16/1628
(EU)2016/426 Notified Body:	No.:	
(EU)2016/425		
∑ 2011/65/EU_(EU)2015/863		
<u> </u>		
Standard reference	o. EN 629/	11 1. EN 62941 4 2:
EN IEC 55014-1; EN IEC 550		•
ISC GmbH · Eschenstraße 6 · D-94405 La	ndau/Isar	
^	,	0 - 0 -1
<i>(/ )</i>	/	010000
Landau/Isar, den 20.03.2023	-	Sloot of
Andreas Weichselgartber/	General-Manager	Shao Wei/Product-Management
First CE: 2017		Archive-File/Record: NAPR029536
ArtNo.: 34.033.20 INo.: 11016		Documents registrar: Thomas Fischer
Subject to change without notice		Wiesenweg 22, D-94405 Landau/Isar

GB Electric hedge trimmer - FTaille-hales électrique - / Cesole per siepi elettriche - DK/N Eldreven hækkeklipper - S Elektrisk häcksax - CZ Elektrické piotové růžky - SK Elektrické záhradnícke nožnice - NL Elektrische heggenschaar - Е Tijeras recortasetos eléctricas - FIN Sahkokáyttöiset pensassakset - SLO Električne škarje za živo mejo - H Elektromos-kerti olió - RO Foarfece prritru gard viu electric - GR Hakstrpico, Bequivostrm; - P Corta-sebes eléctrico - HR/BIH Električne škara za živicu - RS Električne makaze za živicu - PL Elektryczne nożyce do zywopiotu - TR Elektriki içit makasi - RUS - Овентрические оровове можимы. - EE Elektrišnie hekilőikur - LV Elektriskás dzivžogu šķéres - LT Elektrinés sodo žirídés - BG Електрическа градинска ножица - UK/R Електричні садові ножиці - MK Електро-ножица за жива ограда



# 

We, Einhell UK Ltd

Champions Business Park, First Floor Unit 10, Arrowe Brook Rd, Upton, Wirral CH49 0AB, United Kingdom

declare the conformity to UK standards and legislation was assessed for:

Electric Hedge Trimmer GC-EH 6055/1 (Einhell)		
UK legislation		
Simple Pressure Vessels (Safety) Regulation	X Electromagnetic Compatibility Regulation	
Electrical Equipment (Safety) Regulation	Measuring Instruments Regulation	
Radio Equipment Regulation	Pressure Equipment (Safety) Regulation	
Personal Protective Equipment Regulation		
The Ecodesign for Energy-Related Products and Energy	gy Information Regulation	
X The Restriction of the Use of Certain Hazardous Subst	ances in Electrical and Electronic Equipment Regulation	
X Noise Emission in the Environment by Equipment for u		
X Annex V	· ·	
Annex VI Noise: measured $L_{WA}$ = 94,12 dB (A); guaranteed $L_{WA}$ = 98 d P = 0,6 kW; L = 55 cm UK Approved Body:	B (A)	
X Supply of Machinery (Safety) Regulation		
Annex IV UK Approved Body:		
UKTE Certificate No.:		
	41-1; BS EN 62841-4-2; ; BS EN IEC 61000-3-2; BS EN 61000-3-3	
Wirral, 2023.03.20 Tom Chambers, Managing Director Einhell UK Ltd.		
Article Number: 34.033.20 INo.: 11016 Subject to change without notice	Archive-File/Record: NAPR029536 Documents registrar: Thomas Fischer Wiesenweg 22, 94405 Landau/Isar, Germany	

EH 04/2023 (01)