

正面



User Manual

Keesmile Modern Double Side Lighting Floor Lamp

Troubleshooting

- 1. Can't found the device 'KS05-XXXXXX' in the keepsmile app**
- a. Check if the lamp is powered on, try disconnecting and re-powering.
 - b. Check if Bluetooth on the smartphone is enabled, or try connecting with another smartphone.
 - c. Make sure the app is the latest version
 - d. When connecting for the first time, ensure the smartphone is near the lamp.
 - e. If still can't find the device, go to "Forgotten Device" on "My Device" in the app, find the device 'KS05-XXXXXX' if there is, click "Unlock" then re-connect it.
- 2. The remote control does not work**
- a. Check if the remote control battery has power
 - b. Reset the remote control, then re-pair it.
- Reset the remote control:** Continuously off/on-off/on-off/on(6 times). When the lamp bulb fast flashes, all the remote pair procedures on the lamp would be cleared successfully.
- Re-pair:** Power on the floor lamp, long press the RGB on/off button (on remote) for 2 seconds to pair them. The remote indicator light flashes on when entering the pair procedure. Within 10-30 seconds, the lamp pairs with remote after detecting the remote signal. The indicator light on the remote flashes when they paired successfully.
- 3. Why the app need permissions for location, bluetooth, microphone, storage, camera, etc.**
- a. Location permissions: Android system requires location to scan for bluetooth devices and connect. It's not "Keesmile" app needs the buyer's location information, it's the Android system that needs it. IOS system does not require location permissions
 - b. Bluetooth permissions: Allow bluetooth to connect to use the app
 - c. The recording, storage, and camera permissions are optional (Optionally close). They are only required when using some functions.
- Storage: When using the music mode, need to read the music in the mobile phone
- Microphone: When using the mic mode, you need to grab the surrounding sound
- Camera: When uploading profile pictures
- d. We do not record and sove any buyer's location and other information. You can set all permissions to allow only while app in use.

- 4. Other issues.**
- Please call or email us, we will provide you with a satisfactory solution


Packing List

Lamp Head	1
Iron Poles	5
Lamp Base	1
Power Adapter with Cable	1
Remote Controller	1
User Manual	1


Installation

Step1:
Check if all the parts are completely. Place them neatly to avoid wires twisting. Connect the power adapter to check if floor lamp can work normally

Warning
Be sure to test before installing. Any questions, please feel free to contact us by email or phone




- Step2:**
Assemble the Floor Lamp in the order of ①-⑨ (As illustrated)
1. Connect the Base with the Iron pole by spinning clockwise. (① and ②)
 2. Connect all Iron poles and Lamp Head in order (②-⑦) by spinning clockwise
 3. Connect Power Cable and Power Adapter (⑧ and ⑨)



背面

Control Manner

Control Button




APP Control

Keesmile APP Control


1. Scan the below QR code or search and download Keesmile app from Apple Store or Google play.



2. Turn on the Bluetooth on your phone



3. Don't connect it on Bluetooth, after turn on the Bluetooth, please open straight to the keepsmile app. Select 'Floor Lamp'



- mark means sucessfully connected.
- mark means Bluetooth unconnected, please tap this mark to make it connected

Specification

Input Voltage	100-240VAC 50/60Hz
Color Temperature	2700K~6500K
Max Luminous Flus	2600LM
Controlled by	APP/IR remote/Switch
Height	69in
Beam Angle	360 degree
Material	Iron+Plastic
Wattage	24W

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.



WARNING:

1. Indoor use only.It is non-waterproof.
2. Please use the packaged adapter to meet the working power requirement.
3. Power off before installation, cleaning and idle.
4. Please do not use it in humid environments or at high temperatures
5. Please do not use it while exceeding the voltage , the proper voltage of US is AC110-120V , 50-60Hz.
6. Please do not plug or unplug the power cord with wet hands , keep it in a dry environment.
7. Please stop using it if there are any defective issues found in the product.

FCC COMPLIANCE STATEMENT:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement
This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provide with antenna installation instructions and transmitter operating conditions for satisfying RF exposure