

User Manual

Compatible with:
Surface 13-inch Tablet




TABLE OF CONTENTS

OVERVIEW 1

CONNECT TO YOUR DEVICE 1-2

FUNCTION KEYS 3

TOUCHPAD FUNCTION 4

CHARGING 4


TROUBLESHOOTING 5

TECHNICAL SPECS 5

FCC CAUTION 6

OVERVIEW

Keyboard is set in **Windows** mode as default.



(Package contents: Keyboard case, Type-C charging cable, user manual)

CONNECT TO YOUR DEVICE

A) First time pairing:


- 1. Turn on keyboard's Bluetooth.
 - 1.1. Press the + keys to turn on the Bluetooth.




- 1.2.1. Keyboard will identify Bluetooth signal automatically for your 1st device.
- 1.2.2. For your 2nd device, press the + button to turn keyboard's Bluetooth on (the Bluetooth light will blink in blue)

2. Turn on your tablet's Bluetooth and connect;


2.1 On your tablet, go to Settings>Devices>Bluetooth & other devices;



2.2 Turn on the Bluetooth>Add Bluetooth or other devices;




2.3 Choose "Bluetooth" under "Add a device", and tap "Keyboard 5.0" to pair, the pairing process is considered complete after the "Connected" indicator appears (see picture below).



B) Future pairings:

After [successful first-time pairing](#), your tablet will automatically remember the keyboard. To connect again, please [turn on Bluetooth](#) on both tablet and keyboard. Device should automatically connect. If it does not, please tap it in [Other devices](#) list to establish connection.

FUNCTION KEYS



Shortcut Keys

Fn

+

Touchpad ON/OFF

Fn

+

Connect/Disconnect

Fn

+

Change Backlit Colors

Fn

+

Change Backlit Colors

Fn

+

Battery Status

Ctrl

+

A

Select All

Ctrl

+

C

Copy

Ctrl

+

V

Paste


About function of Fn key

1.When you need to use shortcut of Win System, please use Fn Key
Or Press “Fn” to lock Fn key, the Pair light will flash once Fn key is locked.

For instance, if you need to use F5 key to refresh the page, you could press combo keys “Fn” + “F5”, or press “Fn” to lock Fn key, the Pair light will flash once Fn key is locked, then press “F5” to refresh the page


TOUCHPAD FUNCTION

Notice: Make sure bluetooth connected and touchpad function turned on !




One Finger Tap Mode

Action 1: Tap one time while on main interface;
Function: Mouse cursor manipulation.
Action 2: Action 2: Hold and slide;
Function:Select or Move the icon;
Jump out of the mode: Refer to the right instruction




Two Fingers Tap Mode

Action 3: Tap the pad one time;
Function: Show the context menu




Two Fingers Scroll

Action 4 : Slide fingers up or down;
Function: Scroll web page or file up/down or write in writing mode
Action 5: Slide fingers left or right
Function: Turn the page to the left or right




Two Fingers Zoom

Action 6: Two fingers slide for zooming in or out.
Function: Can only be used on the websites or spreadsheets.



Three Fingers Swipe Up


Action 7: Swipe Up
Function: Switch to the previous program or page.



Three Fingers Swipe Down

Action 8: Swipe Down
Function: Switch to the Main interface

CHARGING



1. Move switch to the **"ON"** position (see a diagram above for **ON/OFF** switch location). If charging indicator is **flashing red** , please charge the keyboard.
2. Plug the charging cable (included) into the keyboard and power adapter (not included, tablet or phone power adapter recommended);
 - a) Battery indicator turns red when keyboard is charging;
 - b) Battery indicator turns blue when charging is complete.

TROUBLESHOOTING

Part.1

If the keyboard is not working correctly, please check the following:

- 1.The Bluetooth function on the tablet (or other Bluetooth devices) is enabled;
- 2.The Bluetooth keyboard is within 33 feet;
- 3.The Bluetooth keyboard is charged.

Part.2

- 1.Make sure the keyboard is turned on (the battery indicator is illuminated);
- 2.Ensure the keyboard is fully charged;
- 3.Make sure the Bluetooth in your device (eg tablet, iPad, table pc) is turned on;
- 4.Press the key "FN"+"C" and check the Bluetooth status;
- 5.Make sure a keyboard has already paired via Bluetooth.

If failed to connect with Bluetooth, please try the following steps:

- Remove device on your tablet;
- Switch off the Bluetooth function on your tablet;
- Reboot the tablet;
- Turn on the Bluetooth on your tablet;
- Switch the keyboard off and on;
- Repeat the steps described on page 1 and 2 to pair the keyboard;

TECHNICAL SPECS

- Transmit Range: up to 10m
- Battery Life: 100++ working hours
- Standby mode: up to 300 days
- Operating Voltage: 3.7V DC
- Operation current: < 5mA
- Standby current: 1.0mA
- Sleep current: < 0.1mA

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning for Portable device:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.