



| Original                                                                              | Replacement | Original                                                                              | Replacement            |
|---------------------------------------------------------------------------------------|-------------|---------------------------------------------------------------------------------------|------------------------|
|      | Power       |      | Power                  |
|      | Mute        |      | Mute / Dimmer          |
|      | 1           |      | 1                      |
|      | 2           |      | 2                      |
|      | 3           |      | 3                      |
|      | 4           |      | 4                      |
|      | 5           |      | 5                      |
|      | 6           |      | 6                      |
|      | 7           |      | 7                      |
|     | 8           |     | 8                      |
|    | 9           |    | 9                      |
|    | Source      |    | AV / Input / RDS       |
|    | 0           |    | 0                      |
|    | Info        |    | Info / Angle           |
|    | DMP         |    | D.Menu / Top           |
|    | Up          |    | Up                     |
|    | EPG         |    | Guide / EPG / -/-      |
|    | Left        |    | Left                   |
|    | Enter       |    | OK                     |
|    | Right       |    | Right                  |
|    | Menu        |    | Menu / Home            |
|    | Down        |    | Down                   |
|    | Exit        |    | Exit / Cancel / Clear  |
|    | Vol +       |    | Vol+                   |
|    | List        |    | Smart / List           |
|    | CH +        |    | CH+ / Page+            |
|   | Vol -       |   | Vol-                   |
|  | CH -        |  | CH- / Page-            |
|  | Fav         |  | Fav / Marker / PC      |
|  | Sleep       |  | Sleep / Timer          |
|  | Index       |  | Display / Media        |
|  | Recall      |  | Back / Return          |
|  | Red / <<    |  | Red / Netflix / Search |
|  | Red / <<    |  | << / Tune-             |







| Original                                                                              | Replacement | Original                                                                              | Replacement            |
|---------------------------------------------------------------------------------------|-------------|---------------------------------------------------------------------------------------|------------------------|
|      | Power       |      | Power                  |
|      | Mute        |      | Mute / Dimmer          |
|      | 1           |      | 1                      |
|      | 2           |      | 2                      |
|      | 3           |      | 3                      |
|      | 4           |      | 4                      |
|      | 5           |      | 5                      |
|      | 6           |      | 6                      |
|      | 7           |      | 7                      |
|      | 8           |      | 8                      |
|      | 9           |      | 9                      |
|    | [≡?]/Source |    | AV / Input / RDS       |
|    | 0           |    | 0                      |
|    | [≡i]/Info   |    | Info / Angle           |
|    | DMP         |    | D.Menu / Top           |
|    | Up          |    | Up                     |
|    | EPG         |    | Guide / EPG / -/--     |
|    | Left        |    | Left                   |
|    | Enter       |    | OK                     |
|    | Right       |    | Right                  |
|    | Menu        |    | Menu / Home            |
|    | Down        |    | Down                   |
|    | Exit        |    | Exit / Cancel / Clear  |
|    | Vol+        |    | Vol+                   |
|    | List        |    | Smart / List           |
|    | CH+         |    | CH+ / Page+            |
|    | Vol-        |    | Vol-                   |
|    | CH-         |    | CH- / Page-            |
|  | ♥           |  | Fav / Marker / PC      |
|  | Sleep       |  | Sleep / Timer          |
|  | Index       |  | Display / Media        |
|  | Back        |  | Back / Return          |
|  | Red         |  | Red / Netflix / Search |
|  | <<          |  | << / Tune-             |



