

IQOS

User Guide

IQOS 2.4 PLUS

How to use your IQOS™



1. TURN ON


Press and hold the Pocket Charger Power Button until lights switch on.



2. CHARGE HOLDER

Press Lid Opening Button to open. Insert the Holder into the Pocket Charger, then close the Lid to charge. Fully charged when Holder Battery Status Light is solid white.

IQOS 2.4 Plus Pocket Charger



How to use your IQOS



3. INSERT TOBACCO STICK

Insert and gently press the tobacco stick to the line on filler.



4. START HEATING

Press Heating Button until the Holder vibrates and light pulses white.

IQOS 2.4 Plus Holder



How to use your IQOS



5. BEGIN USE

Start using once the light is solid white.




6. NEARLY COMPLETE


To signal the last 30 seconds, the Holder will vibrate and the light pulses white.



Power Adaptor



Charging Cable



IQOS Cleaning Tool



IQOS Cleaning Sticks

How to use your IQOS



7. REMOVE TOBACCO STICK

Slide Cap upward, remove used tobacco stick then slide Cap back again. Insert the Holder back in the Pocket Charger to recharge.



TO CLEAN

Slide Cap upward and remove completely. Insert IQOS Cleaning Tool and rotate gently. Clean daily for optimal experience.

ENGAGE WITH IQOS

For further instructions and Customer Care support visit www.iqos.com

Download the IQOS Connect App on Google Play*



*Google Play and the Google Play logo are trademarks of Google LLC.

*IQOS Connect App may not be available in your country.

Pairing your device



PAIRING MODE

Press the Bluetooth Button for 3 seconds then release. Bluetooth Status light will blink during 30 seconds indicating pairing mode is active. Select pairing on your smartphone.




PAIRED

IQ05 is paired with your smartphone when Bluetooth Status light remains solid during 3 seconds.



SWITCH OFF

To switch-off Bluetooth press the Bluetooth Button for 6 seconds.



STATUS

Tap the Bluetooth Button to show current status.

Quick Tips



TO CHECK BATTERY STATUS

Tap the Pocket Charger Power Button to check battery level.



TO RESET

Simultaneously press the Bluetooth and Pocket Charger Power Buttons for 10 seconds, then release. Pocket Charger Battery Status lights will switch on, then blink twice to confirm a reset.



RED LIGHT ON HOLDER

1/ Holder needs to be recharged. Place in Pocket Charger and make sure it is switched on. 2/ If the light remains red after a recharge, try a reset as indicated above.



RED LIGHT ON POCKET CHARGER

Try resetting IQ25. If the red light persists, please contact Customer Care.

IQOS



This symbol indicates
that caution is required
when operating the product.

SAFETY WARNINGS AND INSTRUCTIONS

PLEASE READ ALL SAFETY WARNINGS AND INSTRUCTIONS BEFORE USE TO AVOID INJURY.

These safety warnings and instructions cannot cover all possible conditions that could occur, and users should exercise care and caution.

Keep these safety warnings and instructions for future reference as they contain important information.

Intended Users

- IQOS® and tobacco sticks are for adult use only.
- IQOS and tobacco sticks are intended for use by current adult smokers who would otherwise continue to smoke.
- Children and adolescents should never use IQOS or tobacco sticks under any circumstances.
- IQOS or tobacco sticks should not be used by people with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning their use and understand the risks involved.

Tobacco and Nicotine

- Tobacco sticks contain nicotine, which is addictive.
- IQOS and tobacco sticks are not risk-free. The best way to reduce tobacco-related health risks is to quit tobacco and nicotine use altogether.
- Some users of IQOS and tobacco sticks reported experiencing discomforts such as chest pain, choking sensation, cough, difficulty breathing, dizziness, dry mouth, dry throat, gingivitis, hoarseness, irritation, nasal stuffiness, nausea, mouth irritation, pharyngitis, throat irritation, and vomiting.
- Nicotine-containing products should not be used by people who have or are at risk of heart disease, are pregnant, are smokers, or are experiencing anxiety.
- Nicotine-containing products should not be used during pregnancy or while breastfeeding. If you are pregnant, breastfeeding, or think you may be pregnant, you should quit tobacco and nicotine use altogether.
- Stopping smoking or switching to IQOS and tobacco sticks or other nicotine-containing products may require the adjustment of the dosage of certain medicines (e.g. theophylline, tricyclic antidepressants).
- If you have questions about whether you should use IQOS and tobacco sticks given an existing health condition, consult a health care professional.

▲ IMPORTANT SAFETY INFORMATION

▲ WARNING: CHOKING AND INGESTION HAZARD

Keep IQOS and tobacco sticks out of reach of children at all times.

- **CHOKING HAZARD** — IQOS accessories and tobacco sticks contain small parts.

• **SMOKING HAZARD:** — If a battery pack is swallowed, seek medical attention immediately due to risk of chemical ingestion.

 ELECTRONIC AND BATTERY HAZARDS

Electronic Risks

Failure to follow these Safety Warnings and Instructions could result in fire, explosion, electric shock, injury, or damage to the product or other property:

- Only Intended Users should use IQOS.
- Only charge the IQOS Pocket Charger with the approved IQOS Power Adaptor model supplied in the box or available from your local or online IQOS stores for charging purposes. See the Technical Data section of this User Guide for a list of approved IQOS Power Adaptor models.
- Do not use third-party accessories with IQOS.
- Only charge the IQOS Pocket Charger using Safety Extra Low Voltage. See the Technical Data section of this User Guide for details on voltage.
- Do not use IQOS where the use of electronic devices is prohibited.
- Only charge the IQOS Pocket Charger indoors as indicated by the symbol .
- Do not use IQOS or charge the IQOS Pocket Charger and/or IQOS accessories if they are damaged, tampered with, or broken.
- Do not use IQOS if its batteries appear to be leaking.
- Do not use, charge, or store IQOS in places with high temperature (such as inside a car in summer, or near heat sources such as radiators or fireplaces).
- Do not use IQOS where flammable materials, liquids and gases are present.
- Never immerse or put IQOS or its accessories in contact with water and/or other liquids. Do not touch IQOS and/or its accessories if they become wet or immersed in any liquid.

- Never dispose of IQOS and/or its accessories with other household waste, as it may come into contact with water and/or other liquids.
- Clean the USB charging port on the IQOS Pocket Charger periodically to avoid accumulation of foreign matters (such as dust particles).
- Disconnect IQOS and/or its accessories from any source of power if it overheats, fumes, ignites, or burns while charging.
- Do not touch IQOS and/or its accessories if they do overheat, fume, ignite, or burn.
- Handle with care. Do not drop IQOS or subject it to strong shock.
- Do not attempt to open, service, modify, or repair any component of IQOS, or to replace any of the components or batteries.
- Only use IQOS in ambient temperatures between 10° and 50° C.

Battery Wicks

IQOS is powered with sealed lithium-ion 3.7V battery. Under normal conditions of use, the battery is sealed.

- If fluid from leaking battery is swallowed, seek medical attention immediately. Do not induce vomiting or ingest food or drink.
- If fluid from leaking battery liquid is inhaled, get fresh air and seek medical attention.
- If fluid from leaking battery is in contact with skin, wash hands and do not touch eyes.
- If fluid from leaking battery comes into contact with eyes, immediately flush with running water for at least 15 minutes and seek medical attention immediately.

⚠️ DANGER! THERMAL BURN RISK

Failure to follow these Safety Warnings and instructions could result in thermal burns.

- Store IQOS and tobacco sticks in a clean, dry, cool place.
- Do not expose IQOS and tobacco sticks to high humidity conditions or direct sunlight.
- Do not use tobacco sticks that have been exposed to excessive heat or moisture.
- Do not remove a tobacco stick while in use.
- Never attempt to touch the IQOS heating bowl.

⚠️ DANGER! ALLERGIC REACTION RISK

- Using IQOS and tobacco sticks could cause an allergic reaction, such as swelling of the face, lips, tongue, gums, throat, or hoarseness, difficulty breathing, or wheezing.
- Stop using IQOS and tobacco sticks and seek medical attention immediately if you experience any of the symptoms listed above, as they may indicate a serious allergic reaction.

EXCLUSIVE USE OF TOBACCO STICKS

- Only purchase IQOS and tobacco sticks from your local or online IQOS store or other authorized retailers.

- Only use IQOS with tobacco sticks. Never use IQOS with a cigarette or similar products that are not approved for use with IQOS. Doing so may result in injury.
- Do not modify tobacco sticks in any way or add any substance to tobacco sticks. Doing so may result in injury.

Reporting of adverse experiences:

- If you experience any unwanted health effect when using IQOS and/or tobacco sticks, consult a health care professional.
- You can report any adverse experience or incident directly by contacting your local Call Centre. Details can be found in the Customer Care & Warranty booklet. By reporting adverse experience or incidents, you can help provide more information on the safety of the product.
- For more information, please go to www.iqos.com

INFORMATION FOR DISPOSING OF IQOS

Valid across European Union and EEA



This symbol on the product or on its packaging indicates that this product and its individual parts, including batteries, must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste appropriately taking it to a designated collection point for the recycling of waste of electrical and electronic equipment. Waste batteries can be returned free of charge at the point of sale.

The separate collection and recycling of your waste equipment including batteries at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. Shipping of waste equipment as unsorted municipal waste (e.g. by water incinerator or landfilling) can have negative effects on the environment and human health.

TECHNICAL DATA

Model:
IQOS 3.4P Pocket Charger
Battery type:
Li-ion rechargeable battery
Input: 5.7V 1.5A

Pocket Charger:
IQOS 3.4P MUSA0100
Battery type:
Li-ion rechargeable battery
Input: 5V 2A
Bluetooth® 4.2

The IQOS 3.4P Pocket Chargers are marked with the symbol followed by "Power", which indicates the IQOS 3.4P Pocket Chargers can only be charged using one of the approved Power Adapter models listed below.

IQOS all Power Adapter:
Model: S000L, S0140C, S0400, S010AM, S0400L, S0140P
Input: 100V-240V-50-60Hz 0.5A
Output: 5.7V 2.0A
Output power: 10.9W
Average active efficiency: 72.9%
No-load power consumption: <0.05 W

USB Type-C Cable

BATTERY REMOVAL INSTRUCTIONS (FOR DISPOSAL AND RECYCLING)

Battery must not be removed by the consumer. At end of product life, only an authorized repairer may safely remove batteries by using the following steps:

QC05 2-AP Pocket Charger (A15011)

Step 1: Open QC05 Pocket Charger and remove QC05 Module.

Step 2: Insert a small tool into left top side of QC05 Pocket Charger plastic cover, unlock and remove.

Step 3: Disconnect all battery connectors from PCB.

Step 4: Unscrew 2 x PCB securing screws and remove plastic frame.

Step 5: Remove battery and dispose according to local regulations.

Notably, Philip Morris Products S.A. declares that QC05 2-AP is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The official Declaration of Conformity may be found at: www.pmc.com/usa/cigarettes/machines/conformity

QC05 2-AP Model A15011 operates within the 2.402 – 2.483GHz frequency band with a maximum Wi-Fi output power below 100 mW.

Designed and manufactured under the authority of Philip Morris Products S.A., Quai Jonckheere 3, 2000 Neuchâtel, Switzerland.

Bluetooth

The Bluetooth word mark and logo are registered trademarks owned by the Bluetooth SIG, Inc. and are used at your choice by Philip Morris Products S.A. and its affiliates in order to market other trademarks and trade names as being of their respective owners.