


105MM

105MM

# Goodmans

## DAB / FM RADIO




148MM

DAB / FM RADIO  
Model: 363306



105MM


## GETTING STARTED:



- a Connect the power cable to the DAB DIGITAL/FM Radio and mains supply, or insert 4 x 1.5V AA batteries (not included) into the battery compartment.
- b Raise and extend the aerial.

105MM

## DO YOU KNOW? DAB OPERATION



- a Slide the OFF/ON switch to the ON position on the back of your DAB radio to power up the DAB radio, it will start up in DAB mode. It will automatically scan for available radio stations.
- b In DAB mode, the Prev and Next buttons allow you to navigate between different stations. Press the OK button to choose the one you want to listen to.

148MM