


- 1 Install the wire connection
- 2 Fix the support at the desired depth
- 3 Fix the adaptor with the clip
- 4 Fix the wall bracket the adaptor (wall brackets included with the speaker)



For technical queries contact your supplier, distributor or complete the contact form on our website, in Support/Technical requests.

Motors, 166-168 - 08038 Barcelona - Spain Tel. (+34) 932238400 | information@ecler.com | www.ecler.com