

The expert for robots in your home

With one click to the online shop







myRobotcenter





iFetch Instructions:

Now It's Playtime!

Congratulations! You are now a proud owner of an iFetch ballslot machine. This Quick Start Guide helps you with the start-up. If you need additional information such as training tips, please visit the website www.goifetch.com. More iFetch balls can be ordered in our online shop.

In the event of a warranty claim, please contact us via e-mail at office@myrobotcenter.eu or call our hotline +43 5523 55 655

Quick start guide:

- 1. Insert the plug (110-240 volts AC) or insert 6 C-batteries
- 2. Press the button on the iFetch and adjust the throw distance (3m, 6m, 9m)
- 3. Put a ball into the iFetch. Sit back and enjoy the game.

Training:

You and your dog will be having great fun to play together with iFetch. In order to guide your dog to play alone, you can take a look to following video: www.goifetch.com/training-tips

Safety:

The iFetch used miniature tennis balls (40 mm diameter). Please only use iFetch balls or balls with similar form and similar weight. An adult should always supervise children, who are playing with iFetch.

Troubleshooting:

Go for advice and solutions to the FAQ section on the iFetch website www.goifetch.com
If the problem can not be resolved, you can contact us via e-mail at office@myrobotcenter.eu or call our hotline +43 5523 55 655