

AVAMIX

COMMERCIAL BLENDERS



High Power Commercial Blenders

928BX2000T
Toggle Controls

928BX2100E
Digital Controls

928BX2000V
Variable Speed


05/2018

SAFETY

- 1. READ AND SAVE ALL INSTRUCTIONS.**
- 2. Do not immerse the blender in water or other liquid.**
Doing so can result in electrical shock.
- 3. Always unplug from outlet prior to handling or cleaning.**
- 4. Avoid contact with moving parts while operating the blender.**
- 5. CAUTION: Blades are sharp. Handle carefully.**
- 6. This blender is not intended for use by children or individuals with impaired mental and/or motor skills. Individuals who lack experience operating a blender need supervised during use.**
- 7. Never remove parts or clean the blender unless it is unplugged from the electrical outlet.**
- 8. Secure the lid before turning the blender on.**
- 9. Do not use the blender if the cord or plug is damaged.**
Contact the nearest authorized service agency for repair.
- 10. Do not use outdoors.**
- 11. Keep the power cord on the counter in which the blender is being used.**
Do not allow it to hang over the counter or come in contact with liquids or hot surfaces.
- 11. Do not place hands or utensils in the blender jar while it is operating.**
Doing so can cause severe personal harm and/or damage to the blender.
- 12. When blending hot liquids (anything over 100°F), remove the center piece of the jar and start on the lowest speed setting. Do not stand directly over the blender while in use.**
- 13. Ear protection is recommended if blending for long periods of time.**
- 14. Never leave blender unattended while operating.**
- 15. Ensure you are using this blender on a properly grounded outlet.**
This blender comes with a 120V NEMA 5-15P plug.
If unsure of your electrical configuration, contact a professional electrician before operating.

OPERATION INSTRUCTIONS

928BX2000T Toggle Controls



1. Ensure the blender is in the off position and place the container on the blender base. Make sure the blender is fully seated so that the drive coupling is in contact with the container and the base. Plug the blender into a 120V outlet.
2. Put the ingredients into the container and place the lid on. Push the lid down as far as it can go on to the container.
3. **Speed Settings:** This blender has 2 speed settings- High and Low. Use the toggle switch to select the desired speed and the blender will begin working. Use the High option to crush ice quickly.
4. **Pulse:** This blender is also equipped with a pulse feature, which is engaged by holding down the "Pulse" button. The blender will run on high speed until the button is released. It will then return to the current speed setting.
5. Always allow the motor to stop completely before adding or removing the container from the base. Not following this warning could cause damage to the blender which may void the warranty if it is deemed misuse is the cause of the malfunctions.
6. Do not operate the blender without a lid.
7. Always hold the blender container with one hand by the top of the lid to ensure the container remains secure atop the base.
8. Wash and dry the container after each use.

OPERATION INSTRUCTIONS

928BX2000V Variable Speed Controls



1. Ensure the blender is in the off position and place the container on the blender base. Make sure the blender is fully seated so that the drive coupling is in contact with the container and the base. Plug the blender into a 120V outlet.
2. Put the ingredients into the container and place the lid on. Push the lid down as far as it can go on to the container.
3. **Speed Settings:** This blender has adjustable speed settings using a dial knob. The dial knob can be used to adjust the speed from low to high during blending allowing for ultimate user control.
4. **Pulse:** This blender is also equipped with a pulse feature, which is engaged by holding down the "Pulse" button. The blender will run on high speed until the button is released. It will then return to the current speed setting.
5. Always allow the motor to stop completely before adding or removing the container from the base. Not following this warning could cause damage to the blender which may void the warranty if it is deemed misuse is the cause of the malfunctions.
6. Do not operate the blender without a lid.
7. Always hold the blender container with one hand by the top of the lid to ensure the container remains secure atop the base.
8. Wash and dry the container after each use.

OPERATION INSTRUCTIONS

928BX2100E Digital Controls



1. Ensure the blender is in the off position and place the container on the blender base. Make sure the blender is fully seated so that the drive coupling is in contact with the container and the base. Plug the blender into a 120V outlet.
2. Put the ingredients into the container and place the lid on. Push the lid down as far as it can go on to the container.
3. This blender has digital controls that feature an adjustable timer, 3 speeds, pulse, and one touch start.
4. You can blend using either the timer and a speed selection, or just choose a speed setting. If blending by time, use the up and down arrows to set the time, which can be seen on the LCD display.
5. Speed Settings: Select your speed from the 3 settings:
1: 15,000 RPM
2: 20,000 RPM
3: 30,000 RPM
6. **Pulse:** This blender is also equipped with a pulse feature, which is engaged by holding down the “Pulse” button. The blender will run on high speed until the button is released. It will then return to the current speed setting.
7. **One Touch Start:** This feature allows you to use the most recent blending settings without having to re-program them. Once you’ve secured the container back on the blender base, simply press the start button and the unit will activate using the most recent time and speed settings.
8. **Timer:** Time can be set in increments of 30 seconds up to 15 minutes.
9. Always allow the motor to stop completely before adding or removing the container from the base. Not following this warning could cause damage to the blender which may void the warranty if it is deemed misuse is the cause for the malfunctions.
10. Do not operate the blender without a lid.
11. Always hold the blender container with one hand by the top of the lid to ensure the container remains secure atop the base.
12. Wash and dry the container after each use.

CLEANING & SANITIZING

Wash, rinse, sanitize and dry the container prior to initial use. Blender containers should be cleaned after EVERY use to prevent residue build up around the blade assembly.

1. Remove the container from the base.
2. Thoroughly clean the container using water, sponge and a dish soap such as Noble Chemical Sunbright (147SUNBRIGHT). Rinse the container in water.
3. Sanitize the outside of the container and the base with a soft cloth and a sanitizing solution such as Noble Chemical QuikSan (147QUIKSAN).
4. Fill container with sanitizing solution such as Noble Chemical Sani-512 (147SANI512). Place the container on top of the base and secure the lid. Turn the blender on to high speed to allow the sanitizing solution to work its way into the blade assembly and around the jar. Dump the solution into a sink and allow the container to air dry.
5. Allow the lid to soak in the sanitizing solution for at least 2 minutes and then allow it to air dry.
6. Ensure all parts of the blender are dried thoroughly before the next use.

REPLACEMENT PARTS

PART NAME	REPLACEMENT PART ITEM #
Blade Assembly	928PBA1
Drive Coupling	928PDC1
Foot	928PFOOT1 (BX2000V & BX2000T only)
Blender Jar Pad	928PJARPAD
Blender Jar - 64 oz.	928BLJAR64P
Blender Jar Lid	928PLID1
Motor - 120V, 1800W	928PMTR1800

WARRANTY

All new Avamix Blenders used for commercial purpose are warranted against defects in materials and workmanship under normal use and maintenance. This warranty runs for 2 years from the date of purchase and is for the original purchaser only. All other warranties, expressed or implied, statutory or otherwise, including without limitation any implied warranty of merchantability for fitness for purposes are excluded. The seller shall in no event be liable for direct, indirect or consequential damages in connection with Avamix.

All new Avamix Replacement Polycarbonate Blender Jars used for commercial purpose are warranted against defects in materials and workmanship under normal use and maintenance. This warranty runs for 90 days from the date of purchase and is for the original purchaser only. All other warranties, expressed or implied, statutory or otherwise, including without limitation any implied warranty of merchantability for fitness for purposes are excluded. The seller shall in no event be liable for direct, indirect or consequential damages in connection with Avamix.

Exclusions - The following conditions are not covered by warranty:

- Equipment damage or equipment failure occurs because of accident, carelessness, lack of proper set-up, supervision when required, or if the equipment is installed or operated in any manner contrary to the installation and operating instructions.
- Equipment damage or equipment failure due to improper installation, improper utility connection or supply.
- Equipment that has not been used appropriately, or has been subject to misuse, neglect, abuse, accident, alteration, negligence, damage during transit, delivery or installation, fire, flood, or act of God.
- Equipment that has the model number or serial number removed or altered.
- Equipment that has been changed, altered, or modified or repaired by other than an authorized service agency. Avamix shall not be held liable for any damages to any person or property which may result from the use of the equipment thereafter.
- This warranty does not apply to, and Avamix is not responsible for any warranty claims on products sold or used outside of the contiguous United States.
- This equipment is intended for commercial use only. Warranty is void if equipment is installed in non-commercial applications.