


# Marshall

EMBERTON – PORTABLE LOUDSPEAKER

USER MANUAL





## DEVICE LAYOUT

## ENGLISH

### ① CONTROL KNOB

#### I. POWER ON/OFF

Push and hold for 2 seconds

#### II. PLAY/PAUSE

Push once

#### III. SKIP FORWARD/BACK

Push to the right or the left

#### IV. FAST FORWARD/REWIND

Push to the right or left and hold

#### V. TURN UP/DOWN THE VOLUME

Push upwards or downwards

### ② BLUETOOTH® PAIRING BUTTON AND INDICATOR

Push the Bluetooth® button until the indicator above starts blinking to initiate Bluetooth pairing mode.

### ③ BATTERY INDICATOR

The 10 segment battery indicator shows the battery charge.

### ④ USB PORT FOR CHARGING

Connect the speaker to a power source via the included USB cable to charge the battery.

The battery is fully charged when the battery indicator stops blinking.

### GETTING STARTED

01. Push the control knob for 2 seconds. The speaker turns on and is in pairing mode.
02. Select **EMBERTON** from your audio device's Bluetooth list.