



Customer Self Repair Instructions



Lubrication Felts Kit

HP Latex 700 & 800 Printer Series


HP Latex R530, 730 & 830 Printer Series




HP Latex 700 & 800 Printer Series Lubrication Felts Kit




9



10



11




12



13



14




15




16





19



20



21



22



HP Latex R530, 730 & 830 Printer Series

Lubrication Felts Kit

1



2



3



4



5



6



7



8



9



10



11




12



13




14



15



16




17



18



19



20



21



22



23



24

