

USER MANUAL



8+
AGES

REMOTE CONTROL METAL DUMP TRUCK


Top Race Remote Control
Construction Dump Truck
TOPR-000008



If you have any questions about this product please email us.
support@dollardeal.zendesk.com

Please read these operating instructions carefully before using the TR-212. Failure to follow the directions for proper usage may result in damage to the vehicle or personal injury.


REMOTE CONTROL TRANSMITTER OPERATION



Power light
Turn left ●●● Turn right
Forward
Backward
Light switch
Raise the hopper (Press and hold to lower the hopper)
Sound switch
Power switch
Turn the front wheel to the left
Turn the front wheel to the right
Lower the hopper (Press and hold to raise the hopper)

TR-212

INSTALLING BATTERIES IN THE REMOTE CONTROL




NOTE:
When inserting batteries into the compartment, be sure to pay attention to the battery polarity diagram shown above. Vehicle will not work if batteries are not installed properly!

VEHICLE SAFETY INSTRUCTIONS

1. Use caution when removing or installing the batteries.
2. Never attempt to reconfigure or modify the TR-212.
3. Operate this remote controlled vehicle in dry conditions.
4. Vehicle operates best on a smooth surface.
5. When raising or lowering the hopper, keep your fingers away from pinch points.
6. To avoid damage, do not overload the hopper.
7. If the TR-212 is not going to be used for an extended period of time, remove the batteries from the device.

TR-212

INSTALLATION OF RECHARGEABLE BATTERY PACK



NOTE:
When inserting batteries into the compartment, be sure to pay attention to the battery polarity diagram shown above. Vehicle will not work if batteries are not installed properly!

SAFETY INSTRUCTIONS

1. Using a Phillips screwdriver, remove the battery compartment screw as shown. (Pic.1)
Twist the cover buckle to open compartment.
2. Connect the TR-212 power port to the rechargeable battery pack port. (Pic.2)
3. Place the battery pack into the compartment, close the buckle and replace the screw and tighten it. (Pic.3)


TR-212

CHARGING THE BATTERY PACK


Charging methods

Connect the battery port to the Intelligent USB charging port, as shown. Make sure they are connected securely! Next, plug the USB port to a USB charging adapter to begin charging.


Intelligent USB Charging Cable (Included)



7.4V BATTERY SET (Included)



USB Charge Options



Mode 1
Connect to your computer USB port

Mode 2
Connect to a USB adapter

Mode 3
Connect to a mobile charging unit

BATTERY SAFETY

1. The TR-212 Dump Truck operates using a 7.4V 500mAh Lithium ion battery pack. The remote control transmitter uses (4) 1.5V AA non-rechargeable batteries.
2. Always install batteries using the correct polarity as shown inside of the battery compartment.
3. Never attempt to recharge batteries that are not specified as rechargeable.
4. Always charge batteries under adult supervision.
5. Remove the rechargeable battery pack from the TR-212 before attempting to recharge.
6. Never mix different types of batteries and never use old batteries and new ones.
7. Always charge batteries under adult supervision.
8. Only use the included rechargeable battery pack with the TR-212, and always use (4) 1.5V AA batteries for the transmitter.
9. Never leave drained batteries in the transmitter. Always replace them promptly. If the device is not going to be used for a long period, remove the batteries.
10. Never attempt to revive the charging port on the battery pack. Prior to charging, always inspect the battery pack wires for any signs of damage.
11. Do not store battery pack or batteries near a heat source.
12. If the battery or wires show any signs of damage, replace them immediately.
13. Only use the included Intelligent USB Charging Port to recharge the TR-212 battery pack.

TR-212

PAIRING THE TRANSMITTER TO THE VEHICLE



Press this button to turn on the sound, and press once more to turn it off.


Press this button to turn on the light, and press once more to turn it off.

CONTROLLING LIGHT AND SOUND



During operation, if the TR-212 begins to drift to the left or right, the steering needs to be adjusted. This is accomplished using the two steering adjustment buttons as shown below.

STEERING ADJUSTMENTS



Vehicle drifts to the left


Vehicle drifts to the right

Press this button, and the front wheels will turn right.

Press this button, and the front wheels will turn left.

TR-212

OPERATING INSTRUCTIONS



Forward

Backward

Left stick

Right stick

Push

Pull

Turn left

Turn right

Press this button

Press and hold the button as shown to lower the hopper

Press and hold the button as shown to raise the hopper

TR-212

SAFETY INSTRUCTIONS

Do not attempt to dismantle, modify, or reconfigure this remote-controlled vehicle. If parts fail, replace them using certified replacement parts to maintain the vehicle's structure and safety integrity. Never attempt to operate this vehicle outside of its specified limits or risk permanent damage to the unit.

This product was tested and manufactured to the highest quality standards. This unit has many moving parts and caution must be used during operation to avoid injury. This vehicle is recommended for users 8 years of age and older. Parental supervision is recommended for young operators of this vehicle. This vehicle is intended to be operated in dry conditions on a level surface. Water may damage the electronics so avoid using this vehicle in rain or wet conditions.

TR-212

If you have questions about the TR-212 visit us online at

US RGA Top Race US LLC 801 Barton Springs Road, Austin, TX 78704 Email: support@dollardeal.zendesk.com	CA RGA Ben LLC 801 Barton Springs Road, Austin, TX 78704
--	---

WARNING:
CHOKING HAZARD - small parts.
Not for children under 3 years.

MADE IN CHINA

TR-212

MANUEL



Recommandé à partir de 8 ans

CAMION BENNE EN MÉTAL TÉLÉCOMMANDE

TR-212

TOPR-000008




Si vous avez des questions sur ce produit, n'hésitez pas à nous envoyer un e-mail.
support@dollardeal.zendesk.com

TR-212

Veuillez lire attentivement ce manuel d'utilisation avant d'utiliser le TR-212. Le non-respect des consignes d'utilisation peut entraîner des dommages au véhicule ou des blessures corporelles.


FOCTIONNEMENT DE L'ÉMETTEUR DE LA TÉLÉCOMMANDE



Eclairage
Tourner à gauche ●●● Tourner à droite
Avant
En arrière
Interrupteur d'éclairage
Relever la trémie (abaisser et maintenir pour baisser la trémie)
Interrupteur sonore
Interrupteur d'alimentation
Abaisser la trémie (Maintenir enfoncé pour abaisser la trémie)
Tourner la roue avant vers la gauche
Tourner la roue avant vers la droite

TR-212

INSTALLATION DES PILES DANS LA TÉLÉCOMMANDE




REMARQUE:
Lorsque vous insérez les piles dans le compartiment, veuillez à respecter le diagramme de polarité des piles indiqué ci-dessus. Le véhicule ne fonctionnera pas si les piles ne sont pas installées correctement.

INSTRUCTIONS DE SÉCURITÉ DU VÉHICULE

1. Soyez prudent lorsque vous retirez ou installez les piles.
2. Ne jamais essayer de reconfigurer ou de modifier le TR-212.
3. Utilisez ce véhicule télécommandé dans des environnements secs.
4. Le véhicule fonctionne mieux sur une surface lisse.
5. Lorsque vous levez ou abaissez la trémie, gardez vos doigts loin des points de placement.
6. Pour éviter tout dommage, ne surchargez pas la trémie.
7. Si le TR-212 n'est pas utilisé pendant une période prolongée, retirez les piles de l'appareil.

TR-212

INSTALLATION DE LA BATTERIE RECHARGEABLE



NOTE:
Lorsque vous insérez les piles dans le compartiment, veuillez à respecter le diagramme de polarité des piles indiqué ci-dessus. Le véhicule ne fonctionnera pas si les piles ne sont pas installées correctement.

INSTRUCTIONS DE SÉCURITÉ

1. À l'aide d'un tournevis cruciforme, retirez le vis du compartiment des piles comme indiqué (Pic.1). Tournez la boucle du couvercle pour ouvrir le compartiment.
2. Connectez le port d'alimentation du TR-212 au port du bloc-piles rechargeable (Pic.2)
3. Placez le bloc-piles dans le compartiment; fermez la boucle, remettez le vis en place et serrez-la. (Pic.3)


TR-212

RECHARGE DE LA BATTERIE

Méthodes de recharge

Connectez le port de la batterie au port de charge USB intelligent, comme indiqué. Assurez-vous qu'ils sont bien connectés. Branchez ensuite le port USB sur un adaptateur de charge USB pour commencer la charge.


Câble de recharge USB intelligent



BATTERIE DE 7.4 V



Options de chargement USB



Mode 1
Connexion au port USB de votre ordinateur

Mode 2
Connexion à un adaptateur USB


Mode 3
Connexion à un chargeur mobile

SÉCURITÉ DE LA BATTERIE


1. Le camion benne TR-212 fonctionne à l'aide d'un parc de batteries Lithium-ion de 7.4V 500mAh. L'émetteur de la télécommande utilise (4) piles non rechargeables AA de 1.5V.
2. Toujours installer les piles en respectant la borne polarité comme indiquée à l'intérieur du compartiment à piles.
3. N'essayez jamais de recharger des piles qui ne sont pas spécifiées comme étant rechargeables.
4. Chargez toujours les piles sous la surveillance d'un adulte.
5. Retirez le bloc de piles rechargeables du TR-212 avant de tenter de le recharger.
6. Ne laissez jamais des piles échauffées dans l'émetteur. Remplacez-les toujours rapidement. Si l'appareil n'est pas utilisé pendant une longue période, retirez les piles.
7. N'utilisez que le bloc-piles rechargeable fourni avec le TR-212, et utilisez toujours 4 piles AA de 1.5V pour l'émetteur.
8. Ne laissez jamais des piles échauffées dans l'émetteur. Remplacez-les toujours rapidement. Si l'appareil n'est pas utilisé pendant une longue période, retirez les piles.
9. N'essayez jamais de recabler le port de charge du bloc-piles. Avant la charge, inspectez toujours les fils du bloc-piles pour détecter tout signe de dommage.
10. Ne tentez jamais de recharger le bloc-piles s'il devient déformé ou difforme.
11. Ne stockez pas le bloc-piles ou les piles à proximité d'une source de chaleur.
12. Si la batterie ou les fils présentent des signes d'endommagement, remplacez-les immédiatement.
13. Utilisez uniquement le port de charge USB intelligent fourni pour recharger le bloc-piles TR-212.

TR-212

APPARIEMENT DE L'ÉMETTEUR AU VÉHICULE



REGLAGE DE LA DIRECTION




Deviation vers la gauche

Deviation vers la droite

TR-212

INSTRUCTIONS D'UTILISATION



Avant

Manette gauche

Manette droite

Appuyez sur ce bouton

Appuyez sur ce bouton

Appuyez et maintenez le bouton comme indiqué pour relever la trémie

Appuyez et maintenez le bouton comme indiqué pour baisser la trémie

La trémie se lève

La trémie s'abaisse

TR-212

INSTRUCTIONS DE SÉCURITÉ

N'essayez pas de démonter, de modifier ou de reconfigurer ce véhicule télécommandé. Si des pièces tombent en panne, remplacez-les en utilisant des pièces de rechange certifiées afin de maintenir la structure du véhicule et l'intégrité de la sécurité. N'essayez jamais d'utiliser ce véhicule en dehors de ses limites spécifiées, sous peine d'endommager définitivement l'unité.

Ce produit a été testé et fabriqué selon les normes de qualité les plus élevées. Cet appareil comporte de nombreuses pièces mobiles et il convient de faire preuve de prudence lors de son utilisation pour éviter toute blessure. Ce véhicule est recommandé pour les utilisateurs âgés de 8 ans et plus. Le surveillance parentale est recommandée pour les jeunes utilisateurs de ce véhicule. Ce véhicule est destiné à être utilisé dans des conditions sèches sur une surface plane. L'eau peut endommager les composants électroniques; évitez donc d'utiliser ce véhicule sous la pluie ou dans des conditions humides.

TR-212

Si vous avez des questions sur le TR-212, visitez notre site Internet :

US RGA Top Race US LLC 801 Barton Springs Road, Austin, TX 78704 Email: support@dollardeal.zendesk.com	CA RGA Ben LLC 801 Barton Springs Road, Austin, TX 78704
--	---

AVERTISSEMENT:
Risque d'étouffement - petites pièces.
Ne pas laisser jouer les enfants.

FABRIQUÉ EN CHINE

TR-212

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :

(1) Cet appareil ne doit pas provoquer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in distance 0mm between the radiator & your body without restriction.

L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé dans la distance 0mm entre le radiateur et votre corps sans restriction.